## **Vigorvan Pop Up Folding Camper Cover**





# Vigorvan Pop Up Folding Camper Cover Owner's Manual

Home » Vigorvan » Vigorvan Pop Up Folding Camper Cover Owner's Manual



#### **Contents**


- 1 Vigorvan Pop Up Folding Camper Cover
- **2 Important Instructions**
- **3 INSTALLATION INSTRUCTIONS**
- **4 INSTALLATION**
- **5 Cleaning and Storage**
- **6 WARRANTY**
- 7 Documents / Resources
  - 7.1 References



# **Vigorvan Pop Up Folding Camper Cover**



#### Instructions for the Following RVs



#### **WARNING:**

- Do not run the RV engine with the cover on.
- Installation and removal are safer and easier when done by two people.
- Never install on a windy day or when your RV roof is slippery.
- Please take care when you are on a ladder or on the roof.
- Be sure that your helper does not pull the cover while you are on top of the RV.




## **INSTALLATION INSTRUCTIONS**

#### Preparation:

Please Read the Instructions Thoroughly Before Using Your Cover.


- Wash and dry your RV completely, making sure to remove all of the dirt, leaves or pine needles from the top of the RV since sliding a cover across debris can scratch your roof.
- Besides, this can also start you off with a clean RV in the next camping season.
- Cover or tape any sharp edges on your RV that may wear against your cover.
- Be sure to lower any roof antennas.
- Locate the gutters (small extending spouts at the ends of your RV gutter) on the top corners of your RV and cover them with the gutter guards provided.
- Fold the extended mirrors to ensure proper fit and prevent tears.
- Do not touch hot surfaces, such as exhaust systems will damage the cover.
- Check all the electrical items inside your RV are turned off.




	Travel Trailer Cover	5th Wheel Cover	Class A Cover	Folding Camper Cover
Trailer Cover	1	1	1	1
Storage Bag	1	1	1	1
Tire Cover	4	4	4	х
Toss Buckle	1	1	1	1
Tongue Jack Cover	1	х	х	х
Reinforced straps	2	2	2	2
Adhesive Repair Patch	1+1	1+1	1+1	1+1
Pearl cotton gutter protector	4	4	4	4
Plastic sleeve bags	4	4	4	4
Non-woven Sleeve Bags	4	4	4	4
Side Buckle Straps < 13ft	4	12	8	3
Side Buckle Straps < 24ft	6	12	8	3
Side Buckle Straps > 24ft	8	12	8	3


## **INSTALLATION**

- STEP1. With another person lift the cover to the roof.
- STEP2. Carefully climb up on the roof and take your cover out of its storage bag, to identify the FRONT or REAR of the RV cover, you need to unroll the cover and find out FRONT and REAR sewing labels on the bottom of the front and rear panels (Fig.1).






• STEP3. Place the rolled-up cover at the front centre of the roof and unroll down the centre of the RV toward the back (Fig. 2).




• STEP4a. Starting at the front, unfold your cover from the centre outwards. Continue unfolding the cover as you work toward the back. Make sure the corners of the cover are at the corners of your RV. Letting it fall over the sides of your RV (Fig. 3).



• STEP4b. For travel trailers, 5th wheel RVs finish by zipping all the panels closed on your cover and then pulling the elasticized corners down over the bumper(s) of your RV.


#### • STEP5a. For class A


From the ground, use a stepladder and work from front to back to pull the cover down over the sides of the RV. Finish by zipping all the panels closed on your cover then pull the elasticized corners down over both bumpers of your RV (Fig. 4).



#### · STEP5b. For 5th wheel RVs


Connect the Hoot and loops that fold in on either side just under the nose of your 5th wheel (Fig. 6). Adjust and tighten straps as necessary for a snug fit.






#### STEP6. For all RVs.


Each cover comes with a toss buckle strap together with two iron bars, to help you attach the straps under your RV. Begin it by filling your toss buckle strap pocket with the iron bar (Fig 7). Clip the toss buckle strap to the buckle strap attached to the tension panel (Fig 8). Now toss the strap pocket bar under your RV to the buckle on the opposite side (Fig 9). Unclip the toss buckle strap and buckle the toss buckle to the next strap. Repeat with the remaining straps.







• STEP7. Zip all the panels on your RV cover then pull the elasticized corners down over both bumpers of the RV (Fig. 10). Attach all of the male straps/buckles to the corresponding female strap/buckles. Adjust all of the tension straps of your cover for a snug fit. Don't over-tighten. The sides of your cover can be unzipped for access to the doors. The panels can be rolled up and held in place with the rip-and-grip straps toward the top of each panel.



## **Cleaning and Storage**

- To clean your RV cover: We suggest lightly cleaning spots with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes. Pls do not wash your RV cover in the washing machine, as it may cause premature wear of the cover.
- To store your RV Cover: A handy storage bag is provided. To make the RV cover fit into a storage bag, fold your cover and roll the cover tightly rather than stuffing it. Never store a wet cover in the storage bag or confined area.
- PATCH KITS: The patch kits fix holes and protect the cover from wear damage. The adhesive patch material matches your cover and does not require ironing.

#### **WARRANTY**

**WARRANTY:** 2 Years Limited Warranty

#### **WARRANTY DOES NOT COVER DAMAGE FROM:**

- · High Winds or Acts of Nature
- Tears from Sharp Objects on your RV
- · Customer Modifications or Abuse
- Normal wear, weather soiling, or stains from environmental pollution.

- The warranty is not transferable and is also voided if the cover is modified in any way by the purchaser.
- Trailering or towing your cover will also invalidate the warranty.

## **Documents / Resources**



Vigorvan Pop Up Folding Camper Cover [pdf] Owner's Manual

Pop Up Folding Camper Cover, Pop Folding Camper Cover, Folding Camper Cover, Camper Cover, Ver

## References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.