





VIMC BS-8008 Rechargeable Trimmer User Manual

Home » Support » VIMC BS-8008 Rechargeable Trimmer User Manual 1

Contents

- 1 VIMC BS-8008 Rechargeable Trimmer
- 2 Introduction
- 3 Specifications
- 4 What's in the Box
- **5 Key Features**
- 6 How to Use
- **7 Safety Precautions**
- 8 Maintenance
- 9 FAQs
- 10 Video- VIMC BS-8008 Rechargeable

Trimmer

- 11 References
- **12 Related Posts**



VIMC BS-8008 Rechargeable Trimmer



Introduction

The VIMC BS-8008 Rechargeable Trimmer is a versatile grooming tool designed to help you achieve a precise and clean trim for various facial and body hair grooming needs. With its rechargeable battery, multiple attachments, and user-friendly features, this trimmer provides an effective and convenient way to maintain your personal grooming preferences.

Specifications

• Brand: VIMC

• Product Dimensions: 4.1 x 2.5 x 3.1 inches; 6.31 Ounces

• Model: BS-8008

• Power Source: Rechargeable battery

• Batteries : 1 Lithium Ion batteries required. (included)

• Charging Time: Varies by model (refer to user manual)

• Usage Time: Varies by model (refer to user manual)

• Blade Material: Stainless steel

• Additional Attachments: Beard trimmer, nose trimmer, precision trimmer, and more

• Voltage: Varies by model (refer to user manual)

What's in the Box

The VIMC BS-8008 Rechargeable Trimmer typically includes:

- 1. Rechargeable trimmer main unit
- 2. Various trimming attachments (e.g., beard trimmer, nose trimmer, precision trimmer)

- 3. Charging cable or dock
- 4. Cleaning brush
- 5. User manual and instructions

Key Features

1. **Rechargeable:** Powered by a rechargeable battery, eliminating the need for disposable batteries.



- 2. **Multiple Attachments:** Comes with various attachments designed for specific grooming needs, such as beard trimming, nose hair trimming, and precision trimming.
- 3. Adjustable Settings: Adjustable trimming settings allow you to achieve the desired hair length and style.
- 4. Stainless Steel Blades: Durable stainless steel blades ensure a sharp and precise trim.
- 5. Ergonomic Design: Designed for comfortable and easy handling during grooming.
- 6. Portable: Compact and portable design allows for easy storage and travel.

How to Use

1. The indicator light is green and flashing (without charging). Unlocking by pressing and holding for 3 seconds is due to the travel lock feature. Travel locks typically require specific unlocking methods to ensure luggage security. Pressing and holding for 3 seconds can be one of the unlocking methods.

2.

- 3. The indicator light is displaying red (charging). The battery is running low. Please charge it.
- 4. Read the user manual thoroughly to understand the device's operation, charging process, and attachment usage.

- 5. Charge the trimmer according to the recommended charging time specified in the user manual.
- 6. Choose the appropriate attachment for your grooming needs (e.g., beard trimmer, nose trimmer).
- 7. Turn on the trimmer and select the desired trimming length or setting using the adjustable settings.
- 8. Gently move the trimmer over the area you wish to groom, following the direction of hair growth.
- 9. After use, turn off the trimmer and clean the attachments and blades as instructed in the user manual.

Safety Precautions

- Follow the manufacturer's safety guidelines and recommendations provided in the user manual.
- Keep the trimmer and attachments out of reach of children.
- Use caution when trimming sensitive areas to avoid cuts or irritation.

Maintenance

• Cleaning: After each use, clean the trimmer blades and attachments to remove hair and debris. Use the included cleaning brush to access hard-to-reach areas. Ensure the trimmer is turned off and unplugged during cleaning.



- Attachment Care: If your trimmer comes with multiple attachments, clean them thoroughly after each use. Wash detachable attachments with mild soap and water and allow them to dry completely before reattaching them to the trimmer.
- Blade Lubrication: Depending on the manufacturer's recommendations, you may need to apply a small
 amount of blade oil (usually included with the trimmer) to the blades to keep them lubricated and sharp. Refer

to the user manual for specific instructions on lubricating the blades.

- Charging: Follow the manufacturer's instructions regarding charging. Overcharging or leaving the trimmer
 plugged in for extended periods may affect battery life. Charge the trimmer as needed and unplug it when fully
 charged.
- **Storage:** Store the trimmer in a clean, dry, and safe place. Keep it away from moisture and direct sunlight. To prevent damage, store the trimmer with its protective cap or attachment covers in place.

Troubleshooting

Issue: Trimmer Not Turning On

- 1. **Check Battery:** Ensure that the trimmer has sufficient charge. If the battery is completely depleted, it may take some time to charge before it can be turned on.
- Charging: Confirm that the trimmer is properly connected to the charger or charging dock and that the power source is functioning.
- 3. **Safety Lock:** Some trimmers have a safety lock feature to prevent accidental activation. Check if the trimmer has a safety lock and disengage it if necessary.

Issue: Poor Trimming Performance

- 1. **Blade Maintenance:** Clean the blades and attachments thoroughly to remove any hair or debris that may be affecting cutting performance. Lubricate the blades if recommended by the manufacturer.
- 2. **Attachment Compatibility:** Ensure that you are using the correct attachment for your grooming needs and that it is securely attached to the trimmer.
- 3. **Blade Dullness:** If the blades have become dull over time, you may need to replace them. Consult the user manual for information on obtaining replacement blades.

Issue: Trimmer Overheating

- Cooling Break: If the trimmer becomes excessively hot during extended use, allow it to cool down for a few
 minutes before resuming grooming.
- 2. **Environmental Factors:** Ensure that you are using the trimmer in an environment with a suitable temperature range. High temperatures can contribute to overheating.
- 3. **Attachment Maintenance:** Check if the attachment being used is clogged with hair or debris, which can increase heat generation. Clean the attachment as needed.

FAQs

What is the battery life of the VIMC BS-8008 Rechargeable Trimmer?

The VIMC BS-8008 Rechargeable Trimmer offers a robust battery life, allowing for up to 2 hours of continuous use on a single charge, making it convenient for both home and travel use.

Can the VIMC BS-8008 Rechargeable Trimmer be used for both beard and hair trimming?

Absolutely, the VIMC BS-8008 Rechargeable Trimmer is versatile enough to be used for both beard and hair trimming, making it a convenient all-in-one grooming tool.

How ergonomic is the design of the VIMC BS-8008 Rechargeable Trimmer?

The VIMC BS-8008 Rechargeable Trimmer features an ergonomic design that ensures comfortable handling and ease of use during extended grooming sessions.

What is the voltage compatibility of the VIMC BS-8008 Rechargeable Trimmer?

The VIMC BS-8008 Rechargeable Trimmer supports a universal voltage range, making it suitable for use in various countries without the need for a voltage converter.

How do I clean the VIMC BS-8008 Rechargeable Trimmer?

Cleaning the VIMC BS-8008 Rechargeable Trimmer is straightforward. Simply detach the blades and rinse them under water. Use the included cleaning brush to remove any trapped hair.

Is the VIMC BS-8008 Rechargeable Trimmer waterproof?

Yes, the VIMC BS-8008 Rechargeable Trimmer is designed to efficiently cut through all hair types, providing a smooth trimming experience for everyone.

How many trimming lengths does the VIMC BS-8008 offer?

The VIMC BS-8008 Rechargeable Trimmer offers multiple trimming length options, thanks to its various comb attachments, catering to a wide range of styling preferences.

What accessories come with the VIMC BS-8008 Rechargeable Trimmer?

The VIMC BS-8008 Rechargeable Trimmer comes with several accessories including different size trimming combs, a cleaning brush, and a charging cable, providing everything needed for a complete grooming experience.

Is the VIMC BS-8008 Rechargeable Trimmer waterproof?

The VIMC BS-8008 Rechargeable Trimmer is water-resistant, making it easy to clean under running water but it is not fully waterproof, so it should not be submerged in water.

What kind of blades does the VIMC BS-8008 Rechargeable Trimmer have?

The VIMC BS-8008 Rechargeable Trimmer is equipped with stainless steel blades that are self-sharpening, ensuring a precise and clean cut every time.

Can the VIMC BS-8008 be used while charging?

Yes, the VIMC BS-8008 Rechargeable Trimmer can be used while it is plugged in and charging, providing uninterrupted trimming sessions.

Video- VIMC BS-8008 Rechargeable Trimmer

> 00:00 00:0

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.