

[Skip to content](#)

Manuals+

User Manuals Simplified.



vimitty OTH-AB202MAX Max Pro Detachable Wireless Remote Selfie Tripod Stand User Manual

[Home](#) » [vimitty](#) » vimitty OTH-AB202MAX Max Pro Detachable Wireless Remote Selfie Tripod Stand User Manual

Contents [hide](#)

[1 vimitty OTH-AB202MAX Max Pro Detachable Wireless](#)

[Remote Selfie Tripod Stand](#)

[2 Product Introduction](#)

[3 Product Parameters](#)

[4 Detach/attach Remote Controller & Charging](#)

[5 How To Use](#)

[5.1 How to close](#)

[6 Additional Features](#)

[7 Connect Bluetooth](#)

[8 LED Indicator](#)

[9 Documents / Resources](#)


[10 Related Posts](#)

vimitty

vimitty OTH-AB202MAX Max Pro Detachable Wireless Remote Selfie Tripod Stand




Product Introduction



Product Parameters

Model	OTH-AB202MAX+
Weight	342 g /12.06 oz
Battery Capacity	50mAh
Remote Distance	10m(33ft)
Remote Button Lifespan	20,000 times
Input	5V/110mAh
Folded Size	1.57×1.41×11.45 in
Extended length without tripod activated	Approx. 11.45-57.08 in
Extended length with tripod activated	Approx. 12-56.88 in
Compatible Device	IOS 7.0/Android 5.0 and above
Device width	Approx. 2.16-3.42 in
Material	Aluminum+ABS+PC

Detach/attach Remote Controller & Charging



Detach Remote Controller:

Attach Remote Controller:

Charging port

When battery is low, detach the remote controller and charge with the Micro USB included in the package.

Detach Remote Controller:


Lift and pull out the remote controller.

Attach Remote Controller:

Insert top of the remote controller first and press down until a click sound is heard.


How To Use**Step 1:**

Press the triangle button on the bottom of the tripod to release tripod legs.


**Step 2:**

Hold the handle sleeve with one hand and the pull handle of the phone holder with the other hand to pull out the telescopic rod. Adjust to desired height.

Tripod legs will open automatically as the telescopic rod being pulled out.

**Step 3:**


Widthwise set your phone inside the smartphone holder by releasing the top cap.



Note: please avoid stuck the button of your phone.

Attention


- Do not pull legs to open tripod.
- Push the handle sleeve all the way down so that the tripod legs are fully opened and stable.



How to close


Step 1:

Remove your mobile phone by releasing the top cap.




Step 2:

Hold the handle sleeve and use the other hand to push the aluminum alloy telescopic arm back from the top cap.




Step 3:

If the tripod legs are not fully closed, press it by hand again.






NOTE: if you open the tripod, the tripod will close automatically when push back the aluminum alloy telescopic arm. Manual operation is prohibited.



Additional Features




Dual-Cold Shoe Mount

Vimitty selfie stick tripod is equipped with two additional cold shoe mount, which can be installed with fill lights, flashes, microphone and other devices to expand more usage scenarios, suitable for night video recording, live broadcast, Selfie, etc.



Multi-rotation Angle Support


Vimitty selfie stick is super adjustable which provides a 180° vertical rotation angle of bracket and a 270° horizontal rotation angle of phone holder



Connect Bluetooth

Step 1:


Press button on remoter controller for 35, green light flashes into pairing mode.




Step 2:

Active Bluetooth function on your device.

Select “vimity” for pairing The blue light goes out after connected.

**Step 3:**

Press the button once to take pictures when connected smartphone is in camera mode.

**LED Indicator**

Status	Light Type	Description
Switch On	Green light flashing	Press and hold on to the camera button for 3s into pairing mode
Switch Off	LED light off	Press and hold on to the camera button for 3s to turn off remote
Standby	LED light off	Remote will standby after 10 minutes without operation. Press the button once to active, green light will flash, please reconnect with phone again.
Low Power	Red light flashing	Charging with Micro-USB cable included
Charging	Red light on	Charge for 2 hours
Fully Charged	LED light off	Remove USB cable and keep it
Connected	Green light on	Press button once to take pictures

NOTE: Bluetooth will automatically disconnect when the distance is greater than or equal to 10 meters.

Web: www.vimitty.com

Email: support@vimitty.com

Made in China

Documents / Resources



[vimitty OTH-AB202MAX Max Pro Detachable Wireless Remote Selfie Tripod Stand](#) [pdf] User Manual

OTH-AB202MAX, OTH-AB202MAX Max Pro Detachable Wireless Remote Selfie Tripod Stand, Max Pro Detachable Wireless Remote Selfie Tripod Stand, Detachable Wireless Remote Selfie Tripod Stand, Wireless Remote Selfie Tripod Stand, Remote Selfie Tripod Stand, Tripod Stand

[Manuals+](#),

- [home](#)
- [privacy](#)