

Vinton

Vinton XS BOOKCASE
Compact Bookshelf
with Multiple Shelves



Vinton XS BOOKCASE Compact Bookshelf with Multiple Shelves Instruction Manual

[Home](#) » [Vinton](#) » Vinton XS BOOKCASE Compact Bookshelf with Multiple Shelves Instruction Manual 

Contents

- 1 Vinton XS BOOKCASE Compact Bookshelf with Multiple Shelves
- 2 Product Usage Instructions:
- 3 Where should you start?
- 4 Panel quantity
- 5 What's in the hardware bag?
- 6 How do the dowels and Minifix system work?
- 7 Minifix system
- 8 Let's start assembling!
- 9 How much weight does my cabinet resist?
- 10 Cabinet panels
- 11 WARRANTY POLICY
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

Vinton

Vinton XS BOOKCASE Compact Bookshelf with Multiple Shelves



Specifications:

- **Product Name:** XS Bookcase
- **Mounting:** Must be fixed to the wall
- **Warning:** Children safety – must be secured to the wall

Product Usage Instructions:

What will you need?

Hi! my name is Armando, and I'll be with you while you assemble this cabinet.

- Phillips head screwdriver
- Flat head screwdriver
- Hammer
- A flat, smooth surface (cardboard of the box or a rug)
- An electric screwdriver (optional)

Where should you start?

This is so IMPORTANT!

Ensure all panel and hardware content is correct and in good condition before starting assembly. There's no warranty once the cabinet is assembled.

What's in the hardware bag?

- Dowel x8
- Drywall screw x8
- Wall anchor + screw x2
- Nail-on glide x4
- Rear Panel Clamp x3
- Minifix cam x12
- Spreading bolt x12
- Nail x23
- Shelf support x12
- Cover caps x8, x14

How do the dowels and Minifix system work?

Wood dowels:

1. Put in the dowel inside the indicated hole and softly hit it until it's fully inside when joining two panels together.

Minifix system:

1. Insert the Minifix cam with the arrow pointing towards the drilling on the panel's edge.
2. Secure the joint with the spreading bolt.

Let's start assembling!

You can see the last page of this manual to have a full look of the panels of this cabinet.

FAQ:

- **Q: Why is it important to secure the furniture to the wall?**

A: Securing the furniture to the wall prevents tip-overs, reducing the risk of serious injury or death, especially for children.

- **Q: Can I use an electric screwdriver for assembly?**

A: While not necessary, an electric screwdriver can make the assembly process easier and faster.

ASSEMBLY INSTRUCTIONS

XS BOOKCASE

THIS FURNITURE MUST BE FIXED TO THE WALL


WARNING

Children have died from furniture tip over. To reduce the risk of tip over:


- ALWAYS secure this furniture to the wall using a wall anchor. NEVER allow children to stand, climb, or hang on drawers, doors or shelves.
- Do not defeat or remove the drawer interlock system.
- Place heaviest items in the lowest drawers.
- NEVER put a TV on this furniture.

To ensure the safety of those using this cabinet, it is crucial to properly secure it to the wall using a wall anchor . This product includes the necessary items for fixing the furniture to the wall. However, it is important to note that incorrect installation or failure to use the tip-over device can result in serious injury or even death. For this reason, we highly recommend that a professional installer handle the installation of the cabinet to the wall.

What will you need?



Hi! my name is Armando, and I'll be with you while you assemble this cabinet.



A flat, smooth surface. You can use the cardboard of the box or a rug.



An electric screwdriver isn't necessary, but it can make the work much easier

Where should you start?

This is so IMPORTANT!

Over the next few pages is the panel and hardware content for this cabinet.












Please make sure that the quantity of each one is correct, and that everything is in good shape.

(When the cabinet is already assembled there's no warranty for this)

Panel quantity

A – x1	B – x1	C – x1	D – x1
E – x1	F – x1	G – x3	H – x1
I – x1	J – x1	K – x2	L – x2

What's in the hardware bag?

 Dowel x8	 2" Drywall screw x8	 2 1/2" Wall anchor + screw x2	 Nail-on glide x4
 Rear Panel Clamp x3	 Minifix cam x12	 Spreading bolt x12	 Nail x23
 Shelf support x12	 Cover caps x8	 Cover caps x14	

Be careful!, try not to lose anything from this bag, its content is necessary for assembling your cabinet.


How do the dowels and Minifix system work?

This is so important too!


Everytime you're using one of these connectors during the assembly, you should follow these same steps.

Wood dowels

They are little wooden cylinders.




Put in the dowel inside the indicated hole and softly hit it until it's fully inside




When joining two panels together, don't forget to gently hit the panels to adjust the joint.

Minifix system

It's a joint compound of two parts: a spreading bolt and a Minifix cam.



- This is a Minifix cam.
It has a little arrow on its upper surface.
- You should insert these cams with the little arrow pointing towards the drilling on the panel's edge (shown on the left).
-




This is a spreading bolt.



You should put it with the black plastic part facing down.



- After joining two panels together you should turn the cams 180° with a phillips head screwdriver to adjust and secure the joint.



Let's start assembling!



You can see the last page of this manual to have a full look of the panels of this cabinet.
























Drywall
screw 2"


Insert part J first
and then screw in




16




17



18



Make sure that the perforation of the rear panel does not remain between the union of the pieces K-L, so that they do not separate.



Fix your cabinet to the wall



On the wall, measure and mark the points shown below.




Drill on the markings with a 5/16" drill bit.



Insert the wall anchors inside the drillings.





Place the cabinet and secure it with the screws.



Measurements in cm

* Measurements in inches




After adjusting all the Minifix cams, cover them up with the cover caps.



After finishing the assembly, lift off all the adhesive letters.

How much weight does my cabinet resist?



*weight in pounds

Congratulations !It's done

But don't go yet!

There are some recommendations left for you to take care of your cabinet correctly from now on.


SUPER IMPORTANT!

We suggest fixing the cabinet to the wall, so we can avoid the cabinet tipping and harming anyone. Be specially careful with the kids.

Taking care of your cabinet:

- Do not paint the cabinet.
- The cabinet it's exclusively for indoor spaces. Do not expose it to the direct sun.
- Clean the metallic hardware with a dry cloth.
- DO NOT overload the cabinet (see suggested loads)
- Do not hit or hammer the cabinet (only when indicated here).
- Clean it with thinner, a soft soap solution or simply a damp cloth.
- Don't drag the cabinet, lift it up with other people.
- Avoid direct contact with water, fire or exposing it to high heat.

Cabinet panels



WARRANTY POLICY

Furniture has a 1 year warranty coverage in wooden parts and hardware pieces since its manufacturing date, which you can see in the lot number printed on the product box and the assembly instructions leaflet. Warranty covers materials and workmanship imperfections which impair the assembly or correct functioning of the cabinet.

This warranty is not valid if the defects or imperfections are caused by the incorrect following of the assembly instructions, warnings and recommendations, misuse, intentional damage, fire or flood, or after modifications or any kind of alteration, or repaired by someone not authorized, when it's been assembled 3 months after the date of purchase. These defects MUST be reported before the warranty coverage period ends. Once the product has

been assembled, the company will not be responsible for defective and/or damaged parts.

This warranty is ONLY valid for the ORIGINAL purchase, it doesn't apply if the product has been resold, rented, etc.

Furniture will take no liability for incidental or consequential damages caused to or by the product (This may not apply in your state).


To make this warranty valid you must write to our customer service email describing the product defect, lot number and submitting your sales receipt or proof of purchase, or contact us at our customer service line.

Replaced parts will be under the product's original warranty coverage period.

Damaged parts will become property of the company.

There are no other warranties applicable to this product.

Documents / Resources

	<p>Vinton XS BOOKCASE Compact Bookshelf with Multiple Shelves [pdf] Instruction Manual XS BOOKCASE Compact Bookshelf with Multiple Shelves, XS BOOKCASE, Compact Bookshelf with Multiple Shelves, Bookshelf with Multiple Shelves, Multiple Shelves, Shelves</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.