



VISION AUDIO VISUAL TC3 Control Module Instructions

[Home](#) » [VISION AUDIO VISUAL](#) » VISION AUDIO VISUAL TC3 Control Module Instructions 

VISION AUDIO VISUAL TC3 Control Module Instructions




Contents

- [1 Instructions](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Instructions

A new code transmission method means TC3-CTL **CANNOT** learn codes from the remote.

By default this TC3-CTL has these new Epson codes assigned:



To change or set codes you **MUST** now use the codes in the software library.

VS Program Button set

Button Name

1

Buttons Backlights

☒ Option A: When pressed light flashes briefly.


☐ Option B: Light stays on all the time and turns off briefly when pressed.

☐ Option C: When pressed light stays on until an associated button is pressed.

Command	Control Type	Brand	Model	Function	Code
☒ 1	IR	Epson	new2021	Select	
☐ 2	RS-232	Select		Select	
☐ 3	RS-232	Select		Add New	
☐ 4	RS-232	Select		A/V MUTE	
☐ 5	RS-232	Select		COMPUTER	
				DOWN	
				ESC	
				HDMI	
				HOME	
				LAN	
				LEFT	
				MENU	
				POWER	
				RIGHT	

The software can be downloaded from vav.link/tc3-ctl
 Connect the TC3-CTL via USB to the PC to save the commands to the device.

Documents / Resources

	VISION AUDIO VISUAL TC3 Control Module [pdf] Instructions TC3 Control Module, Control Module, TC3 Module, Module
---	---