




Contents [[hide](#)]

- [1 VIZULO Pine Connect LED Linear Luminaire](#)
- [2 Safety instructions](#)
- [3 Mounting instructions](#)
- [4 Maintenance and repair](#)
- [5 Dimensions](#)
- [6 Install the diffuser only in a clean room using gloves!](#)
- [7 Mounting dimensions](#)
- [8 Module mounting](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

vizULO

VIZULO Pine Connect LED Linear Luminaire



Safety instructions

Any actions with the luminaire must be performed by a qualified person, who is certified according with national regulations and requirements.

- To prevent any accidents person installing the luminaire must follow national safety requirements and following instructions:
- The label containing technical parameters of the luminaire has to be studied before the work on it has begun.
- Any luminaire build or design changes are prohibited.
- The luminaire must be used in good technical condition and according with these instructions.
- Only VIZULO authorized spare parts and accessories can be used to repair the luminaire.
- The repair of luminaire has to be performed by a qualified and certified person.

Terms of use and maintenance

Before luminaire is turned on, it should be mounted according with these mounting instruction or any other applicable regulations.

Mounting instructions

Mounting of luminaire must be performed by a qualified person according to following instructions:

- The warranty of luminaire does not apply, if the mounting of the luminaire has been performed in precipitation (rain, snow, hail).
- The warranty of luminaire does not apply, if an unauthorized control system by VIZULO or an inapplicable LED driver has been used to drive the luminaire.
- The warranty of luminaire does not apply, if it has been used in an unsuitable ambient temperature or has been supplied by voltage outside of the specified range.
- The warranty of luminaire does not apply, if the LED driver program has been changed in any way.
- The warranty of the luminaire does not apply, if the logged history data of the LED

driver has been deleted without the permission of VIZULO.


- The warranty of luminaire does not apply, if it has been mounted an unspecified angles or upside down (luminaire glass directed up), or it has been completely submerged under water.

Maintenance and repair

Luminaire has to be disconnected from electrical grid before it is opened and/or repaired!

- The person working with the luminaire must follow national regulations and legislation that apply to maintenance and testing of electrical or electronic appliances.
- The luminaire may need to be cleaned depending on its environment. Only a damp cloth or a sponge may be used to clean the luminaire. Use only household detergents diluted by water.
- Only VIZULO authorized spare parts may be used for the luminaire.
- Instruction for changing spare parts must be requested from VIZULO and studied before the repair is attempted.
- LED modules, lens and LED drivers can be changed on an installed luminaire, but it is advised to perform this task indoor to avoid water entering the luminaire.
- Spare parts (lens, LED modules and drivers) should be ordered from the information available on the luminaire label.


Dimensions




Install the diffuser only in a clean room using gloves!

Diffuser cover may accumulate small electrostatic charges that make it susceptible to dust and other small particles.


It should only be cleaned using dry microfiber cloth or compressed air duster.





Remove all protective before installing the device!






Mounting dimensions




Module mounting






WARNING!

- Do not touch LED modules!
- Do not put any tools or other items on LED modules!
- In case any LED is physically damaged (example shown below) the warranty is void.



Energy efficiency class of contained light source(s)



FAQ


- **Q: What should be done before turning on the luminaire?**

A: The luminaire should be mounted according to the mounting instructions or any applicable regulations.

- **Q: Who should perform actions with the luminaire?**

A: Any actions with the luminaire must be performed by a qualified person certified according to national regulations.

Documents / Resources

| | |
|---|--|
|  | <p>VIZULO Pine Connect LED Linear Luminaire [pdf] Instruction Manual</p> <p>Gen2, Pine Connect LED Linear Luminaire, Connect LED Linear Luminaire, LED Linear Luminaire, Linear Luminaire, Luminaire</p> |
|---|--|

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.