vocolinc FL2201 Floor Lamp User Guide

Home » vocolinc » vocolinc FL2201 Floor Lamp User Guide 🖫

Contents

- 1 vocolinc FL2201 Floor Lamp
- **2 Product Overview**
- 3 What's Included
- 4 Features
- **5 Power / Reset Button**
- 6 FL2201 Floor Lamp Status
- **7 System Requirements**
- 8 Specifications
- 9 Safety Warnings
- **10 FCC Declaration**
- 11 IC Declaration
- 12 EU declaration of conformity
- 13 Installation Steps
- 14 Documents / Resources
 - 14.1 References
- **15 Related Posts**



vocolinc FL2201 Floor Lamp



Product Overview

Handsfree voice control and with over 16 million colors, the FL2201 Smart Floor Lamp is here to make your home truly yours. Utilizing the latest in Wi-Fi technology, FL2201 Smart Floor Lamp enable you to set the color temperature and intensity of any area via VOCOlinc app. With countless uses and applications, an all-new colorful world awaits you with the VOCOlinc FL2201. You can customize your personal lighting from anywhere with an active internet connection. It also supports for segment control and you can set it to a variety of effective mode in different segments of it. With VOCOlinc APP, the light syncs to music and sound. Floor Lamp changes color and flashing speed with rhythm and melody.



What's Included

- Floor Lamp
- Smart Wi-Fi Controller
- AC/DC Adapter
- User Manual

Features

- 16 million colors
- · Works with Apple HomeKit
- · Works with Amazon Alexa
- · Works with the Google Assistant
- Remote Access

Power / Reset Button

- · Quick press to switch on/off
- Press & hold for about 10 seconds to FACTORY RESET.

Note: All connection data will be cleared after reset. The FL2202 Floor Lamp must be removed from the app and then add it back again.

FL2201 Floor Lamp Status

Status		FL2201
Turning on the firs t time	Searching Wi-Fi	White light at 5% brightness
Pairing		White light at 5% brightness
Device added successfully		White light at 50% brightness
Identifying the light strip		White light at 5% brightness blinks quickly 3 times
Firmware update completed		Blinks twice

^{*}If you set the brightness to 0% before turning off the light switch, the smart light strip will resume to 100% brightness as soon as you turn on the light switch again to indicate that it is in good shape.

System Requirements

- Mobile device running the latest version of iOS and Android 4.3 or above Existing Wi-Fi network
- Stable Internet with good signal strength

Specifications

Input: 100-240VAC, 50/60HzOutput: 12V 1.5A (SELV)

• Plug type: US/EU

• LED color range: 16 million colors with cool to warm whites Wattage: 18W max

Operation frequency band(s): 2412~2472MHz

• Max. transmitted RF power: 17dBm

Safety Warnings

• WARNING: RISK OF ELECTRIC SHOCK OR BURNS. DO NOT install this product with wet hands or standing

on wet or damp surfaces

- Not suitable for use with standard in-wall dimmers. Dimmable via the app only
- Suitable for use in operating environment between 0°C and 40°C (32°F and 104°F)
- The adapter, controller and Floor Lamp must be used in conjunction with full set of FL2202 Floor Lamp
- Please do not mix with other model of products, otherwise there is a risk of product damage
- This device is not intended for use with emergency exit luminaires
- NOT FOR EMERGENCY LIGHTING
- DO NOT disassemble
- · DO NOT clean with liquid

FCC Declaration

Caution

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter

IC Declaration

Caution:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to ithe following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, ncluding interference that may cause undesired operation of the device.

In order to avoid the possibility of exceeding the ISEDC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

EU declaration of conformity

Hereby, Felion Technologies Company Limited declares that the radio equipment ColorFlux

Light Strip is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.vocolinc.com

Installation Steps

- 1. Assemble the Lamp pole
- 2. Attach the silicone strip light to the top end, then press the strip light from the middle outwards to the two ends.
- 3. Insert the Cap into the Lamp Pole
- 4. Assemble the 2 Bars into the Lamp Base. Use the Screws (already in the Holes) and the spanner provided to tighten and secure the Bars to the Lamp Base.
- 5. Connect the female header of the WI-FI controller to the male header on the silicone strip light.
- 6. Connect the Adapter to the socket of the WI-FI controller and plug the adapter into a power outlet. Enjoy the Smart Floor Lamp now.







Documents / Resources



vocolinc FL2201 Floor Lamp [pdf] User Guide
FL2201, 2AXT8-FL2201, 2AXT8FL2201, FL2201 Floor Lamp, Floor Lamp, FL2201 Lamp, Lamp
p

References

• VOCOlinc, a smart home devices brand.

Manuals+,