

VOLLRATH 74704D Drop in Induction Retherm Installation Guide

Home » VOLLRATH » VOLLRATH 74704D Drop in Induction Retherm Installation Guide 🖺



VOLLRATH 74704D Drop in Induction Retherm Installation Guide



Mirage® Drop-in Induction Warmer/Rethermalizer Gasket Installation

Purpose

This document is a supplement to the Operator's Manual. It explains how to install the gasket onto the rim of the Mirage ® Drop-in Induction Warmer and Rethermalizer. Install the gasket before performing the installation procedure in the Operator's Manual.

NOTICE: Gasket installation is mandatory. Failure to install the gasket will void the warranty.

- 1. Turn the equipment so the bottom is facing up.
- 2. Set the equipment on a stable surface, such as a countertop.
- 3. Lubricate the gasket with a small amount of liquid dish soap or water.
- 4. Carefully press the groove of the gasket onto the underside edge of the rim. Take care to evenly press the

gasket as you feed it onto the rim, without stretching it.



- 5. If needed, use a scissors to trim the gasket to the proper length.
- 6. Continue with the installation procedure in the Operator's Manual.



Outperform every day.

www.vollrath.com

The Vollrath Company, L.L.C.

1236 North 18th Street Sheboygan, WI 53081-3201 U.S.A.

Main Tel: 800.624.2051 or 920.457.4851 Main Fax: 800.752.5620 or 920.459.6573

Customer Service: 800.628.0830

Canada Customer Service: 800.695.8560

Technical Services

techservicereps@vollrathco.com

Induction Products: 800.825.6036

Countertop Warming Products: 800.354.1970

All Other Products: 800.628.0832

Contents

1 Documents / Resources

1.1 References

Documents / Resources



<u>VOLLRATH 74704D Drop in Induction Retherm</u> [pdf] Installation Guide 74704D, 26237-1, 74704D Drop in Induction Retherm, 74704D, Drop in Induction Retherm, Induction Retherm, Retherm

References

- V Commercial Foodservice & Kitchen Equipment | Vollrath Foodservice
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.