



Vorago BCS-201 Barcode Reader User Manual

[Home](#) » [Vorago](#) » Vorago BCS-201 Barcode Reader User Manual 

Vorago BCS-201 Barcode Reader User Manual



Contents

- [1 CORRECT ANGLE FOR SCANNING](#)
- [2 CONNECT YOUR USB SCANNER](#)
- [3 SETTING](#)
- [4 Language Settings](#)
- [5 DATA SHEET](#)
- [6 Safety warnings](#)
- [7 Limited product warranty](#)
- [8 Responsibilities](#)
- [9 How to obtain warranty support](#)
- [10 Exclusions](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)

CORRECT ANGLE FOR SCANNING


Maintain a beveled angle between the scanner and the barcode for optimal reading.

Trying to scan a code at 90 degrees has the possibility of an error.


The scanner must completely cover the barcode otherwise errors may occur.

The ideal reading distance is up to 15 centimetres from the printed code.


- Correct way to read




- Correct way to read



- Wrong way to read



- Wrong way to read



CONNECT YOUR USB SCANNER

When turned on, the reader will detonate a double beep, indicating that it is ready to scan. It will turn on the LED light at the top. Pressing the trigger (click) will activate the scanner in search mode. Once the information is found, it will make a beep and turn on the upper LED light again.

SETTING

- USB KEYBOARD WEDGE



READING MODE

- DEFAULT MODE



- CONTINUOUS SCAN



BUZZER

- ON



- OFF



Add Code ID

- No code ID



- Send code ID



- Send code ID



-

Language Settings

- English



- French Canada



- Spanish



- Argentina(Latin)



- Danish



- British English



- Dutch



- Italian



- Portuguese



- French



- German



- Norway



- Swedish, Finnish



- Portugal portuguese



- Turco-F



- Czech



- German, French



- Belgium Dutch



- Polaco 214



- Turco-Q



- Japanese



- Croatian



- Hungarian



- Russian



- Arab



DATA SHEET

Adapter	
Voltage: 5V cc 1A	
Connector: USB	
Light source: Laser 650mm	
Resolution: 4,000	
Scanning distance: 10 mm-600 mm	
Material: ABS+PVC+PC	
Useful life: 100000 times	
Weight: 121g	
Size: 167 x 65 x 97mm	Cable length: 170 comes
Speed: 100 readings/second	
Compatibility: EAN/JAN-13, JAN-8, EAN/GSL/UCC-128 Auto, Coding 25 intercalate, standard, Código 39, Full ASCII, Código 32, Código 93 Full ASCII, Código 128, Coda bar, MSI, UPC-A, UPCEO, Código 11.	



Safety warnings

Do not use the product with a damaged cord, this could cause malfunction or cause electric shock.

- Be careful not to spill liquids on the product, as this could cause it to malfunction or produce an electric shock.
- Use of this device in conditions other than normal may cause electric shock.

Limited product warranty

Vorago equipment and/or accessories are covered by a limited warranty for the time indicated in the annexed validity table, counting from the date of acquisition, against any manufacturing and operation defect, provided they have been used under normal conditions of use during the warranty period and for which it was manufactured. Vorago warranty the buyer the absence of anomalies regarding the materials.

Products	Validity
PC, tablets, e-mobility, audio, keyboards, mouse, networks and accessories	12 Months
LCD Monitor * Except in panel (screen display) for which it will only be 12 months.	36 Months*
Computer equipment 3 years including Minibar Except computer equipment where the processor is integrated on the mother board it will only be 12 months.	36 Months *

Important warranty policy: Please read and complete this warranty policy and seal it in the store when purchasing the product.

Product: 1D Barcode Reader	
Model: BCS-201	Dealer stamp
Brand: Virago	
Serial number:	
Invoice number:	
Delivery date:	

Responsibilities

The total responsibility of Vorago will be to repair or replace the product, including labor and parts, at no cost to the buyer when it is returned to the point of sale, presenting this warranty policy properly completed and stamped by the establishment where it was purchased. The product or copy of the receipt or receipt or invoice, in which data of the product the date of purchase is specified, to verify the times within the warranty. Vorago may use new parts, restored or used in good condition to repair or replace any product, at no additional cost to the consumer. In the case of equipment and / or accessories that can not be repaired, the change will be generated by a similar product or with superior characteristics. This warranty covers the transportation expenses of the product derived from its fulfillment; which will be directly attributable to the supplier of the product. In all replacement products, the original warranty period will be renewed. Vorago is governed by international standards for the manufacture of products.

How to obtain warranty support

Warranty claims are processed through the point of sale, during the first 15 days after the purchase, as long as they meet the requirements. Guarantee claims that can not be processed through the point of sale and any concerns related to the product purchased should be sent with the prepaid guide by Vorago to the address of the Vorago headquarters in Francisco Villa No. 3, Col. San Agustín, CP 45645, Tlajomulco de Zúñiga, Jalisco, Mexico.

Except in situations of force majeure or fortuitous event, the repair time in no case will be greater than 30 calendar days from the date of receive of the equipment in Vorago.

Exclusions

This warranty is has valid in the following cases:

- a) When the product had been used in conditions other than normal.
- b) When the product has not been operated in accordance with the instructions for use.
- c) When the product has been altered or repaired by unauthorized persons by Vorago.

Vorago does not offer any other express warranty for this product. To make the warranty valid, as well as the acquisition of parts, components, consumables and accessories

To validate a warranty, the following information must be sent to the email: garantias@voragolive.com

1. Model and color
2. Product failure
3. Ticket or purchase invoice (digitised)
4. Your address with CP, telephone and full Name.

Available in the establishment where the product was purchased and / or in our central offices:


Returns

In the case of product return, it will only be the place of purchase by the end customer. Subject to the return policies established by the same seller.

Vorago, S.A. de C.V.
Francisco Villa No. 3
Col. San Agustín, C.P. 45645
Tlajomulco de.
Tel. (33) 3044 6666



Documents / Resources

	Vorago BCS-201 Barcode Reader [pdf] User Manual BCS-201 Barcode Reader, BCS-201, Barcode Reader, Reader
-------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.