

# Vortex Cellular HotSpot II Smartphone User Manual

Home » Vortex Cellular » Vortex Cellular HotSpot II Smartphone User Manual



### **Contents**

- 1 Vortex Cellular HotSpot II Smartphone User **Manual**
- 2 Quick User Guide
- 3 Lock and Unlock
- **4 Basic Functions**
- 5 Browse
- 6 Settings
- 7 Device
- **8 KEYBOARD & INPUT METHODS**
- 9 About phone
- 10 FCC ID:2ADLJHOTSPOTII
- 11 References
- **12 Related Posts**



**Vortex Cellular HotSpot II Smartphone User Manual** 



# **Quick User Guide**

#### Power On/Off

In the power-off mode, long press the [Power] key, and it will power on; otherwise. In the power-on, long press the [Power] key, and choose Power off, it will power off. If you set up a SIM lock or phone lock, please input the code per the requirements.

### Turn On /Off Screen

Please short press [Power] to turn off the screen to save power.

### **Turn On Screen**

When the screen is off, please short press [Power] to wake up the screen.

### **Lock and Unlock**

### Lock

In the idle screen please press [Power] to lock this screen to prevent some unexpected operations.

# Unlock

After the screen is off, please press any key to wake up the screen, and then press \* and # to unlock the screen

# **Hot Buttons**

On the shortcut bar, Press the dial button and enter the Dialer interface Press the people button to enter Contacts Press the messaging button to enter the Messages interface Press the music button to enter the music list.

### Main Menu

In the Main Menu interface, you can press the [Menu] key to browse all the applications. Press and choose one, you can enter and run this application.

#### **Status Bar**

On the LCD top of the idle interface, is the Status Bar. You can't operate the status bar, it displays some relevant information, including WLAN, Bluetooth, Battery power, System time, etc.

### **Bluetooth Connection**

This device supports Bluetooth 2.0, you can listen to music with Bluetooth earphones. For Bluetooth settings and operations, please refer to the section on Bluetooth in System Settings.

**Prompt:** Bluetooth function and operations are based on the real product.

#### **WLAN Connection**

This device supports "WIFI 802.11 b/g/n". You can access the local network through WIFI. About WIFI settings and operations, please refer to the WIFI section in System Settings.

# Keyboard



## **Basic Functions**

### Cursor

Long press 0 can turn on or off cursor function. When you turn on the cursor function, you can move the cursor anywhere on the screen by the navigation key.

Prompt: When you turn on the cursor function you can not page screen

### **Alarm**

You can switch on or off the alarm. You can customize clock time and ringtone to alert the user.

# Calculator

On the Main menu, enter the calculator. It supports four arithmetic operations such as "+", "-","\*" and "/".

## **World Clock**

You can select different cities to display the corresponding time zone

Prompt: You must use the cursor to choose which city clock you want to display

### Stopwatch

A timepiece that can be started or stopped for exact timing

### **Notes**

You can use this application to record events.

#### To-do list

You can record the schedule or other things whatever you want.

### **Torch**

Turn on or Turn off the Torch

### **Unit conversion**

The length and weight can be converted to different units by this application

#### **Ebooks**

You can view the .txt document by eBooks.

#### Calendar

On the Main menu, enter Calendar. You can check the date by navigation key

### Contact

- 1. The People include contacted and favorites and Group.
- 2. You can store new contact to a SIM or phone
- 3. You can view the contact information including name, phone, email, address, etc.
- 4. If you want to add the contact to your favorites. You can follow these step
- 5. Press the contact icon that you want to add to your favorites to edit the contact details.
- 6. Press the five-pointed star icon. And you can see the contact in the favorites
- 7. You can create groups to save different class contact

#### Music

The music player supports various audio formats, including MIDI, MP3, and wav, etc

#### **Facebook**

Log into Facebook to start sharing and connecting with your friends, family, and people you know. Prompt: The highlighted icon can't be displayed in some widget. You must use the cursor to select the widget

# File Manager

On the Main menu, you can open files or fold in a phone or SD card. You can operate the following operations: Delete, copy, cut, and view detail.

# **FM Radio**

On the Main menu, enter the FM Radio interface, insert the headset then you can listen to the FM radio. Prompt: When the battery of your cell is insufficient, you may not run FM Radio.

# Gallery

In the folders list, choose a photo folder to enter, press the up/down/left/right button to choose the picture, and press the OK button to enter its view.

### History

The call log is separated to All call, Miss call, dial Call, and Received call. You can view the call time and the date time. You can press the call icon to dial the number in the call log.

#### Camera

On the Main menu, enter Camera.

#### Camera

Press the center key or to take photos. Press to switch between Camera or Video recorder, and Press to preview the photos. Press the setting icons to display the parameters box. Press the flash icon to open or close flash.

# Video Recorder

After switching to Video Recorder, press Begin to camcorder; Press to stop. The other operations refer to the Camera.

### Messaging

Press the messaging icon into the messaging menu. You can view all the messages from different contacts. If you want to write a message to other people you can follow these steps

- 1. Press the top right corner icon.
- 2. choose new message
- 3. Input the phone number in the input field or press the contact icon to choose the phone number.
- 4. input the information into the Text field
- 5. If you want to send files you can press the add icon to choose what you want to insert to the mms.
- 6. Press the send icon
- 7. Prompt: You must use the cursor to select the attachment if you want to send mms

#### **Browse**

You can use this application to view the internet. When you use this application after you use the mobile for the first time, you must install the Opera Mini application to access the Wi-Fi or sim usage Press [ Menu ] to display the options menu, and operate the following: Refresh, stop, Home, Save to bookmark, Close etc.

#### **Phone**

You can input a phone number and then dial the button to make a phone call

### **Sound Recorder**

On the Main menu, enter Sound Recorder. The format of recording files is .3gpp, the recording length depends on the size of the T-Flash card. Press to record, Press to stop recording, and Press to play the recording file in the list. Choose and long-press a recording file to delete.

### **Tethering**

Share your phone's mobile data connection via USB or as a portable WIFI hotspot.

### **Videos**

Video player supports various video formats, including Mp4, Avi, etc.

Prompt: You must use the cursor to move the progress bar

#### WhatsApp

Log into WhatsApp to start sharing and connecting with your friends, family, and people you know. Prompt: The highlighted icon can't be displayed in some widget. You must use the cursor to select the widget

### **Dialer Interface**

Press the dialer key enter Dialer interface.

# Dial a Call

# **Calls Category**

Emergency Call You can directly dial an emergency service call without SIM card. Different network uses different emergency numbers, please consult your network operations company for more details.

#### **Normal Call**

Enter a phone number and press dial key to make a phone call. If you're making a long-distance call, please add the area code before the telephone number.

#### **Answer a Call**

When an incoming call arrives, the phone will give out the corresponding prompt (such as vibration, ringtone, etc.); if network support, the phone screen will show the name and telephone number of the caller, press answer this call.

### Refuse a Call

When a call is coming in, press , refuse this call.

### **End a Call**

After finishing a call, click to end this call.

# **Call Operation**

During a call, press the buttons to operate the following:

Add Call: Click, enter a phone number, add another call.

Dial pad: Click to display the Dial pad interface.

Mute: Click to set this call mute.

Speaker: Click, switch call voice to Speaker; click it again to switch the call voice to the Receiver.

End Call: When finishing a call, press \_\_\_\_\_to end call.

# **Settings**

In settings, you can perform: Wireless controls, Sound settings, Display settings, Security & location, Applications, SD Card and Local disk, Date and time, Accessibility, Speech synthesis, About phone, etc.

# Wireless & networks

In wireless network control, you can set WIFI, Bluetooth, Networks, VPN settings, Airplane mode, etc.

### sim management

In the menu, you can view the sim card information and set sim card default setting

# Wi-Fi

Press "WIFI" to switch between "On" and "Off".

**Note:** Please turn off WIFI to save power when not using. You can view Wi-Fi that your mobile can scan Choose one Wi-Fi you want to connect. Then input the password if it is necessary and press connect key The mobile will connect the Wi-Fi If you input the password is correct or don't need password The mobile connect with the selected Wi-Fi automatically When you restart your mobile Wi-Fi in the meantime the Wi-Fi devices is available

# Bluetooth On/Off

Press "Bluetooth" to switch between "On" and "Off".

**Note:** To save power, please turn off Bluetooth when not in use.

# **Bluetooth settings**

You can set Bluetooth On or off, Device name, Discoverable, Scan for devices, and list the scanned devices.

Bluetooth On/Off: Press "Bluetooth" to switch between "On" or "Off".

Device Name: It displays the factory device name, Press this item to edit its name.

Visible: Press "visible" to switch between "On" or "Off". If it is "On", The Bluetooth devices nearby can detect this device.

Visibility timeout: Set how long the device will be discoverable.

Search for devices: Press this item to search the Bluetooth devices nearby.

Bluetooth devices List: When this device finds other Bluetooth devices nearby, it will display them in this list, you can click one and then input a PIN for matching and connection.

### Data usage

Activate or disable data access over Mobile network.

Prompt: You must use the cursor to operate some widget.

### Airplane mode

Press "Airplane Mode" to switch between "On" and "Off". If the Airplane mode is On, all the wireless networks will be disconnected automatically in this mode.

**Warning:** Even if airplane mode is activated, it is forbidden to use (on) in a plane or in some special labs or under hospital equipment, other special environments, etc., to prevent the intervention of electronic equipment to the communication or this device, you are advised to power off this device in such environments.

# **Tethering & portable hotspot**

Share your phone's mobile data connection via USB or as a portable WIFI hotspot.

### **Mobile Networks**

In Mobile Networks, you can set Data enabled or Data Roaming or Access Point Names or Network Operators.

### **Device**

### **Audio profiles**

In sound settings, you can set Silent Mode, Ringer Volume, Media Volume, Notification Ringtone, Audible Selection, Feedback etc.

### **Display Settings**

In display settings, you can perform such operations as "Brightness", "Wallpaper", "Sleep", etc.

#### **Storage**

Phone Storage View the capacity of ROM.

# **SD Card**

View The capacity of the SD card.

#### Battery

Check the electricity consumed by each application.

#### Persona

Location You can set the Mode as you need, and manage your application through this function.

### Security

You can set up a screen lock.

None: Disable screen unlock security.

Key: when you turn on your mobile screen you must Press the \* key and then press the #key to unlock the screen If you turn on this option.

# Owner info

Show text to display on the lock screen.

### Language & input

Language You can select a language, the default language is English.

### **KEYBOARD & INPUT METHODS**

You can check the Android keyboard input method. Meanwhile, you can choose which input method is the default.

### Backup & reset

It includes backup of my data, backup account, Automatic restore, DRM reset, and Factory data reset.

### **System**

Date & Time

#### Automatic date & time

Press this item to switch between "On" and "Off". If it is set as "On", it updates the date and time automatically. This function is based on the services provided by the network.

Note: When this item is initiated, "Set Date", "Select Time Zone" and "Set Time" are not available.

#### **Automatic**

Use network-provided time zone Set date With time updating "Off", Press it to display the dialog box of Date Setting.

#### Set time

With time updating "Off", Press it to display the dialog box of Time Setting, and set system time.

### Use 24-hour format

Press this item to switch between "On" and "Off". If it is "On", system time is in a 24-hour format, otherwise, it is in a 12-hour format.

#### Choose a date format

Select one item to set the date format.

#### Select time zone

Press this item to enter "Select Time Zone", Press and select any one of the world cities, and set it as a system time zone. The default time is Beijing time.

### Scheduled power on & off

Set the automatic switch machine on or off.

# **About phone**

# Status

You can check and view "Battery status", "Battery level", "SIM status", "IMEI information", "Wi-Fi MAC address", "Bluetooth address", "IP address", "Serial number", "Uptime".

# Legal information

Check the open-source license.

### Model number

Display the device number.

### **Android version**

Display its Android version.

### Baseband version.

Display its Baseband version.

#### Kernel version

Display its kernel version

### **Build number**

Display its device build number.

# **Custom build version**

Display its software version.

# FCC ID:2ADLJHOTSPOTII

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

www.vortexcellular.com twitter.com/vortexcellular facebook.com/vortexcellular instagram.com/vortexcellular

Download PDF: Vortex Cellular HotSpot II Smartphone User Manual

### References

• User Manual

Manuals+,