



Voyager VCAHD140LWT Security Camera Owner's Manual

[Home](#) » [Voyager](#) » Voyager VCAHD140LWT Security Camera Owner's Manual 

Voyager VCAHD140LWT Security Camera Owner's Manual



Contents


- [1 NTSC SYSTEM VCAHD140LWT/VCAHD140RWT](#)
- [2 Specifications](#)
- [3 Camera to bracket hardware](#)
- [4 Installation](#)
- [5 Bracket Mtg Hole Dimensions](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

NTSC SYSTEM VCAHD140LWT/VCAHD140RWT

VCAHD140LWT/VCAHD140RWT Features:

- High Performance CMOS Sensor
- IR LED Low Light Enhancement
- Waterproof (IP69K)
- Compact Size

Installation and Pin Out



Specifications


Mounting Type	External Type
Image Sensor	1/3 CMOS
Resolution	700 TV Lines
Min Illumination	0 Lux (with IR LED ON)
Waterproof Rate	IP69K
View Angle	115(H), 90(V), 150(D)
Dimension	69.9(W) * 36.1(H) * 43.6 mm 2.74(W) * 1.42(H) * 1.72(D) Inch
Working Temperature	-40C ~ +85C
Weight	Approx. 0.8kg/1.76lbs

Camera to bracket hardware

Specifications	QTY
 Tapping Screw M3*8mm stainless	1
 Flat Head self tapping screw M3*12mm	4


Installation

Pre-drill holes with a 1/8" bit



*When using spacer, be sure to use liquid sealant around spacer to prevent water intrusion into the verhicle


Braket Mtg Hole Dimensions



Unit: mm



Documents / Resources

	Voyager VCAHD140LWT Security Camera [pdf] Owner's Manual VCAHD140LWT Security Camera, VCAHD140LWT, Security Camera, Camera
---	---

Manuals+.