#### **Skip to content**

#### Manuals+

User Manuals Simplified.



# Voyager VOM73MMT 7" COLOR TFT LCD 3 CAMERA SPLIT MIRROR MONITOR Owner's Manual

Home » Voyager » Voyager VOM73MMT 7" COLOR TFT LCD 3 CAMERA SPLIT MIRROR MONITOR Owner's Manual

Voyager VOM73MMT 7" COLOR TFT LCD 3 CAMERA SPLIT MIRROR MONITOR Owner's Manual



#### Contents hide

- **1 VOM73MMT Features**
- **2 Installation Location**
- **3 PACKING CONTENTS**
- **4 CONTROLS AND OPERATION**
- **5 MENU**
- **6 Installation Instructions**
- **7 TYPICAL SYSTEM CONNECTION**
- **8 PRODUCT STRUCTURE**
- 9 Documents / Resources
- **10 Related Posts**

#### **VOM73MMT Features**

- High Performance Automotive Grade 7" Color LCD Panel
- 3 Camera Inputs with Split Display
- Mechanical Button
- Built-In Audio Speaker
- · Compatible with Voyager Standard Camera

#### **Camera-Monitor Warnings!**

- 1. Camera/monitor system aids in the use of, but does not replace vehicle side/rear-view mirrors.
- 2. Objects in camera/monitor view are closer than they appear. When backing up, proceed cautiously and be prepared to stop.

#### Important! - Please Read This Manual Before Installing!

Congratulations on your purchase of a Voyager VOM73MMT LCD Observation Monitor. With proper installation and use, your VOM73MMT LCD is designed to provide you with years of trouble-free operation. Please read this manual thoroughly before beginning.

All Voyager Observation products are strictly intended to be installed as supplement aid to standard rear-view mirror systems that may already exist in your vehicle. Voyager Observation products are not intended for use as substitutes for-view mirror devices, or for any other standard motor vehicle equipment required to be installed on vehicles by law.

While Voyager observation products contribute to improving the vehicle operator's field of view, these products are no substitute for proper defensive driving techniques and observance of traffic laws and motor vehicle safety regulations.

#### Warnings!

RED POWER WIRE MUST BE CONNECTED TO ACCESSORY TO AVOID CURRENT DRAW IN THE KEY OFF POSITION.

#### **Installation Location**

It is unlawful in most jurisdictions for a person to drive a motor vehicle equipped with a television viewer or screen located at any point forward of the back of the driver's seat or in any location that is visible, directly or indirectly, to the driver while operating the vehicle. The vom73mmT product is designed to be used primarily as a rear observation device in conjunction with closed circuit camera. In any installations where the VOM73MMT is used to display television broadcasts or recorded video, playback, installation location must adhere to local laws and regulations.

#### **Tampering**

To prevent electrical shock, **DO NOT OPEN THE MONITOR CASE.** There are potentially harmful voltages inside the monitor. If evidence of tampering is detected, the warranty will be considered void and all parts will be non serviceable. There are no user serviceable parts inside the warranty will be considered void.

#### **Moisture**

While it will withstand short periods of exposure to moisture, this product does contain sensitive electronic components and exposure should be limited by the user/installer. This product is not designed for locations where constant exposure to moisture or immersion can be encountered. This unit should NEVER be cleaned with a power washer or used where direct power washer spray may be encountered.

#### Depth of view


OBJECT VIEWED MONITOR ARE CLOSER THAN APPEAR.

#### **PACKING CONTENTS**

LCD MONITOR QTY.1



CABLE QTY.1




• METAL BRACKET QTY.1



• MACHINE SCREW QTY.4 (M3X7mm)



# **CONTROLS AND OPERATION**



1. POWER ON/OFF



- · Press once to turn on unit
- Press again to turn off unit

#### 2. MENU



#### **Primary Function Enter System Menu**

Press 'MENU button to enter the System Menu

# Secondary Function Return to previous menu

• While in menu modes, the 'MENU' button is used to return to previous menu.

#### **Third Function: AUTO SCAN function**


Press the 'MENU' button for 3 seconds to achieve the auto scan function.

#### 3. SELECT



#### **Primary Funtion Input Source Select**

• Press to switch camera channels, switch order as below:



# **Secondary Function Menu Option Selection**

• While in menu mode, the 'SELECT' button is used to select the highlighted function or option setting.

#### 4. & 5 1 UP/DOWN




### **Primary Function**


- Pressing 'UP' button increase brightness, contrast, color, tint, volume or sleep.
- Pressing 'DOWN' button decrease brightness, contrast, color, tint, volume or sleep.


#### **Secondary Function**

While in menu modes, the 'UP' DOWN' are used to select the option setting.

#### **MENU**







#### **Installation Instructions**

#### **BEFORE YOU BEGIN INSTALLATION:**

Before drilling be sure that no cable or wiring is on the other side. Clamp all wires securely to reduce the possibility of them being damaged during installation and use. Keep all cables away from hot or moving parts, and electrically noisy components.

#### Wiring Definitions:

· Power connection:

Pin 1 POWER IN DC (12V)-Red Pin

2 GROUND -Black Pin

3 CHANNEL 1 TRIGGER -Blue Pin

4 CHANNEL 2 TRIGGER -Brown Pin

5 CHANNEL 3 TRIGGER -Green

· Camera 1 input:

4-Pin Connection for camera or camera extension cable

· Camera 2 input:

4-Pin Connection for camera or camera extension cable

· Camera 3 input:

4-Pin Connection for camera or camera extension cable

LCD panel: General:

13-Pin Large DIN cable connection to monitor

#### General:

- 1. Choose the monitor and camera locations.
- 2. Install all required cables in vehicle. A 3/4"(19mm) hole should be drilled for passing camera cables through vehicle wall, barriers, etc. Install split grommets where applicable. If additional cable protection is required install convoluted tubing over the cable.
- After cable/wiring has been routed and components in place, temporarily make all system connections and perform a system function check. If system does not operate properly, see the troubleshooting section regarding cable.
- 4. Make sure all cables are routed away from hot or moving parts, and away from sharp edges. Secure cables with wire ties.


#### Backup (Rear) Camera

• Rear-mounted camera used for monitoring while backing up must be connected to the CAMi input. Triggerl must be connected to the reverse gear light circuit.

#### Side Camera

• The side mounted camera should be connected to the CAM2 and CAM3 inputs. Trigger lines 2 and 3 should be connected to the vehicle's turn signal circuits.

#### TYPICAL SYSTEM CONNECTION



# **POWER/TRIGGERWIRE FUNCTIONS**

REF#	WIRE COLOR	DESCRIPTION
1	RED	POWER IN 12VDC
2	BLACK	GROUND
3	BLUE	TRIGGERI (CAM1)
4	BROWN	TRIGGER2 (CAM2)
5	GREEN	TRIGGERI (CAM3)

# **PRODUCT STRUCTURE**

# **LCD PANEL SPECIFICATIONS**

Size/Type 7"(Digital) TFT LCD

**Brightness** 400 cdirre (typ)

Contrast Ratio 500

View Angles Top (12 O'clock) 40° (typ)

Bottom (6 O'clock) 60° (typ)

(@CR≥10)

Horizontal 60" (typ)

15ms

**Response Time** 

20ms

Back Light Type LED

Back Light Life 50,000 hrs (min)

Operation Temperature Range: -20° C 70° C
 Storage Temperature Range: -30° C -80° C

• Max Humidity: 85%

Operation Voltage Range: 12VDC
 Current Draw (typical): 337mA©12VDC
 Signal system: NTSC or PAL (Auto detection)

• Video Aspect Ratio: 16:9 Input Level: 1Vp-p 750

Audio Input Level: 150mV(Max)

• Product Dimensions: 10.04W x 4.72H x 1.24D (Inches)

• Product Weight: 2.65 lbs/1200g



**Documents / Resources** 



<u>Voyager VOM73MMT 7" COLOR TFT LCD 3 CAMERA SPLIT MIRROR MONITOR</u> [pdf] Owner's Manual

VOM73MMT, 7 COLOR TFT LCD, COLOR TFT LCD 3 CAMERA, SPLIT MIRROR MONITOR

# Manuals+,

- home
- privacy