



## vtech 2-Line Answering System with Dual Caller User Guide

[Home](#) » [vtech](#) » vtech 2-Line Answering System with Dual Caller User Guide




### Quick start guide DS6151/DS6151-11/DS6151-2


#### Install the telephone base

Follow the figures below to install the telephone base as shown below:

##### Figure One: Installation with 2-line jack



##### Figure Two: Installation with separate line jacks




**NOTE:** Use only the power adapter and battery supplied with this VTech telephone. For complete feature instructions, please refer to your user's manual.


### Battery installation and charging

Install the battery as shown below. After installing the battery, you might be able to make and receive short calls. For best performance, charge the handset battery for at least 16 hours before use.


1. If the battery compartment cover is on the handset, press the indentation and slide the cover to remove it.




2. Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label.




3. Place the battery with the label **THIS SIDE UP** facing up and the wires inside the battery compartment.



4. Align the cover flat against the battery compartment, then slide it towards the center of the handset until it clicks into place.




5. Charge the handset by placing it in the telephone base or charger. The CHARGE light is on when the handset charges.



**Make, answer and end a call Using the handset:**

**Make a call**



1. Press , , or .
2. Enter the telephone number.

**Predial a call**

1. Enter the telephone number.

2. Press , , or .

**Answer a call**

Press  or  to answer.

**End a call**

Press OFF or return the handset to the telephone base to hang up.

**Using the telephone base:**

**Make a call**

1. Press **LINE 1** or **LINE 2**.
2. Enter the telephone number.

**Predial a call**

1. Enter the telephone number.
2. Press **LINE 1** or **LINE 2**.

### Answer a call

Press LINE 1 or LINE 2 to answer.


### End a call









Press LINE 1 or LINE 2.

### Turn the answering system on or off



You must turn on the answering system for answering and recording messages.

**To turn on or off with the telephone base:**



1.  Press /ON/OFF LINE 1 and/or  /ON/OFF LINE 2 to turn on the corresponding answering system. The telephone base announces and shows, "Calls will be answered." The  /ON/OFF LINE 1 light and/or  /ON/OFF LINE 2 light will be on respectively.
2. Press  /ON/OFF LINE 1 and/or  /ON/OFF LINE 2 to turn off the corresponding answering system. The telephone base announces and shows, "Calls will not be answered." The  /ON/OFF LINE 1 light and/or  /ON/OFF LINE 2 light will be off respectively.

**To turn on or off with a handset:**

1. Press the **MENU** softkey when the handset is not in use.
2. Press the SELECT softkey to select ANSWERING SYS.
3. Press **▲** or **▼** to select **Mailbox 1** or **Mailbox 2**, then press the SELECT softkey. The corresponding icon,  1 or  2, flashes on the screen.
4. Press **▲** or **▼** to select **Ans sys setup**, then press the SELECT softkey.
5. Press **▲** or **▼** to select Answer ON/OFF, then press the SELECT softkey.
6. Press **▲** or **▼** to select On or Off, then press the SET softkey to confirm your setting, or press the BACK softkey to exit to the previous menu without making any changes.
7. The screen displays or when the AnS1 ON AnS ON2 answering system of line 1 or line 2 is turned on respectively. The screen displays when the answering systems of both lines 1 and 2 are turned on. AnS1 ON.


AnS1 ON or AnS ON2

AnS ON2  
displays



when the answering systems of both lines 1 and 2 are turned on.

## Outgoing announcement

The telephone is preset with a greeting that answers calls with “Hello, please leave a message after the tone.” You may use this preset announcement, or replace it with your own. Use the telephone base to record your own announcement:

1. Press **•/REC** while the telephone base is not in use.
2. Press **▼/CID** or **▼/DIR** to select
3. Press **▼/CID** or **▲/DIR** to select Mailbox 1 or Mailbox 2, then press the SELECT softkey. The corresponding icon, 1 or 2,  2 lashes on the screen.
4. The telephone base announces, “Record after the tone. Press 5 when you are done.” After the tone, speak towards MIC (microphone) of the telephone base. Press 5 or the STOP softkey when finished recording.
5. The answering system automatically plays back the newly recorded announcement. Press 5 to stop the playback at any time.

## Use a handset to record your own announcement:

1. Press the MENU softkey menu when the handset is not in use.
2. Press the SELECT softkey to select ANSWERING SYS.
3. Press **▲** or **▼** to select **Mailbox 1** or Mailbox 2, then press the SELECT softkey corresponding icon,  1 or  2, flashes on the screen.
4. Press **▲** or **▼** to select Ans sys setup, then press the SELECT softkey.
5. Press **▲** or **▼** to select Announcement, then press the SELECT softkey.
6. The handset announces, “**To play, press 2.** To record, press 7.” Press 7 to record and the screen shows Recording announcement..., or press the BACK softkey to exit to the previous menu.
7. The handset announces, “Record after the tone. Press 5 when you are done.” After the tone, speak towards the microphone of the handset.
8. Press 5 or the STOP soft key when finished recording.
9. The answering system automatically plays back the newly recorded announcement. Press 5 to stop the playback at any time; 2 to replay the recorded announcement, or 7 to record again if desired.
10. Press the BACK softkey to exit to the previous menu.

## To play messages with the telephone base:

Press **▶/■/MAILBOX LINE 1** for line 1 or **▶/■/MAILBOX LINE 2** for line 2 to listen to messages.

### Options during playback:

- Press **▼/VOL/▲** to adjust the speaker volume.
- Press **▶/SKIP** to skip to the next message.
- Press **◀/REPEAT** to repeat the message currently playing. Press **/REPEAT** twice to listen to the previous message.
- Press **X/DELETE** to delete the current message. The system advances to the next message.



- Press ►/■/MAILBOX LINE 1 for line 1 or ►/■/MAILBOX LINE 2 for line 2 to stop listening to messages.
- Press CANCEL to exit to the previous menu.

#### To play messages with a handset:

1. Press the MENU softkey when the handset is not in use.
2. Press the SELECT softkey to select ANSWERING SYS.
3. Press or to select Mailbox 1 or Mailbox 2. Press the SELECT softkey.
4. Press or to select Play messages, then press the SELECT softkey.

#### Options during playback:

- Press ▼/VOL/▲ to adjust the speaker volume.
- Press 6 to skip to the next message.
- Press 4 to repeat the message currently playing. Press 4 twice to listen to the previous message.
- Press 3 to delete the current message.
- The system advances to the next message.
- Press 5 to stop.
- Press the BACK softkey to exit to the previous menu.

#### IMPORTANT!

If your product is not working properly:

Refer to the Troubleshooting section of the user's manual.

Visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [www.vtechcananda.com](http://www.vtechcananda.com) or dial 1 (800) 267-7377.

#### Disclaimer and Limitation of Liability

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.

Company: VTech Communications, Inc.

Address: 9020 SW Washington Square Road

– Ste 555 Tigard, OR 97223, United States

Phone: 1 (800) 595-9511 in the

U.S. or 1 (800) 267-7377 in Canada



Specifications are subject to change without notice.

© 2020 VTech Communications Inc.

All rights reserved. 06/20. DS6151\_QSG\_V4.0

Document order number: 96-007197-040-100

#### Contents [ [hide](#) ]


#### [1 Documents / Resources](#)

#### [1.1 References](#)

#### [2 Related Posts](#)



## Documents / Resources

	<p><a href="#">vtech 2-Line Answering System with Dual Caller</a> [pdf] User Guide DS6151, DS6151-11, DS6151-2, 2-Line Answering System with Dual Caller</p>
---	--

## References

- [v VTech Cordless Phones Official Site | Best Home Office & Business Phones](#)