

vtech 552303 Spidey Learning Book Instruction Manual

Home » vtech » vtech 552303 Spidey Learning Book Instruction Manual



Instruction Manual





© MARVEL

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds, and colours

Per-School

Interactive toys to develop their imagination and encourage la age development


I am ...

- .. responding to colours, sounds, and textures
- ..understanding cause and effect
- ...learning to touch, reach, grasp, sit up, crawl and t oddle

I want...

- ..to get ready for school by starting to learn the alphabet and ting
- ..my learning to be as fun, easy, and exciting as can be
- ..to show my creativity with drawing and music so my whole b develops





To learn more about this and other VTech® products, visit www.vtech.co.uk

Contents

- 1 INTRODUCTION
- **2 INCLUDED IN THE PACKAGE**
- **3 GETTING STARTED**
- **4 IMPORTANT: BATTERY INFORMATION**
- **5 PRODUCT FEATURES**
- 6 GAMES
- **7 CARE & MAINTENANCE**
- **8 TROUBLESHOOTING**
- 9 CONSUMER SERVICES
- 10 PRODUCT WARRANTY/CONSUMER

GUARANTEES

- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**

INTRODUCTION

Thank you for purchasing the Spidey Learning Book. The Spidey Learning Book features 14 illustrated interactive pages and four fun-packed learning modes. Listen to Spidey team adventure stories as you learn about letters and words. Press the light-up buttons to join in with Spidey's search operation, or jam drum sounds into music like Gwen. Spidey's voice introduces the team and encourages you throughout the journey!



- 1. Spidey Button
- 2. 14 Book Pages
- 3. Power Button
- 4. Volume Button
- 5. Character Buttons
- 6. Mode Buttons

INCLUDED IN THE PACKAGE


- One Spidey Learning Book
- · One Quick Start Guide

WARNING: All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords, and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.

Removing the Packaging Locks




- 1. Rotate the packaging locks 90 degrees anti-clockwise.
- 2. Pull out the packaging locks.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

- 1. Make sure the unit is turned OFF.
- 2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw. Then, remove the cover.
- 3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
- 4. Install 3 new 'AA' (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).
- 5. Replace the battery cover and tighten the screw to secure it.



WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- · Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates

they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd, or Pb, were marked, indicating that the battery contains more than the specified value of mercury (Hg), cadmium (Cd), or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech®-cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electrical collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

PRODUCT FEATURES

1. Power Button

Press the Power Button to power on the unit. Press the button again to power off the unit.




2. 14 Book Pages

Turn the pages to explore different stories.




3. Spidey Button

Press the Spidey button to hear some of Spidey's catchphrases.



4. Mode Buttons

Press one of the four Mode buttons to choose a playing mode.



5. Character Button

Press a Character button to learn about that character's ability.



6. Volume Button

Press the Volume button repeatedly to adjust the volume (3 levels).



7. Automatic Shut-off

To preserve battery life, the Spidey Learning Book will automatically turn off after 1 minutes without input. The unit can be turned on again by pressing the Power Button.

GAMES



Letter Mode

Press the light up buttons to learn letters and vocabulary.



Music Mode

Turn the pages to choose from a variety of melodies. Press the light up buttons to add drum sounds into the music.



Story Mode

Turn the page to listen to different stories. Press the light up buttons to explore more about the story.



Quiz Mode

Press the light up buttons to answer the questions.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit ON. The unit should now be ready to play with again.
- 5. If the unit still does not work, install a brand new set of batteries.

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers: Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers: Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED - CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to wtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au



TM & © 2022 VTech Holdings Limited.
All rights reserved.
IM-552300-000
Version:0



vtech 552303 Spidey Learning Book [pdf] Instruction Manual 552303 Spidey Learning Book, 552303, Spidey Learning Book

References

- © Support : VTech Electronics
- ▼ Electronic Learning Toys | Best Learning Toys | VTech UK
- ■ Electronic Learning Toys | Best Learning Toys | VTech UK
- V Electronic Learning Toys | Best Learning Toys | VTech UK
- VTech Toys Australia Electronic Learning Toys Best Learning Toys VTech Australia and New Zealand

Manuals+,