



VTech 561000 Kiddie Cat Cassette Player Instruction Manual

[Home](#) » [vtech](#) » VTech 561000 Kiddie Cat Cassette Player Instruction Manual 



561000 Kiddie Cat Cassette Player Instruction Manual




Contents

- 1 INTRODUCTION
- 2 INCLUDED IN THE PACKAGE
- 3 GETTING STARTED
- 4 PRODUCT FEATURES
- 5 ACTIVITIES
- 6 MELODIES
- 7 CARE & MAINTENANCE
- 8 TROUBLESHOOTING
- 9 Supplier's Declaration of Conformity
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

INTRODUCTION

Thank you for purchasing the **Kiddie Cat Cassette Player™**

This cassette player provides different styles of music for learning and singing fun. Press the buttons to see the kitty move and to hear fun phrases, sounds and sing-along songs.



NOTE

This is a toy and not an actual cassette tape player.

INCLUDED IN THE PACKAGE

- Kiddie Cat Cassette Player™
- Quick Start Guide

WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE


Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks

1. Rotate the packaging locks 90 degrees counterclockwise.
2. Pull out the packaging locks and discard.

**GETTING STARTED****Battery Removal and Installation**

1. Make sure the unit is turned Off.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.



4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION




- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. On/Off/Volume Selector

To turn the unit On, slide the **On/Off/Volume Selector** to the Low volume  or the High volume  position. You will hear a playful song, a cute phrase and sounds. To turn the unit Off, slide the On/Off/Volume Selector to the **Off**  position.



2. Automatic Shut-Off

To preserve battery life, the Kiddie Cat Cassette Player™ will automatically shut off after approximately 45 seconds without input. The unit can be turned on again by pressing any button.


NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Play Button

Press the Play Button to see the Kitty move from side to side and hear fun musical phrases, songs, short tunes and melodies in three different styles. The light will flash with the sounds and the Cassette Tape will turn forward.



2. Next Button

Press the Next Button to see the Kitty move up and down and play the next phrase, song, short tune or melody. The light will flash with the sounds and the Cassette Tape will turn backward.



MELODIES

1. Rockin' Robin
2. Looby Loo
3. Aiken Drum
4. Hickory, Hickory, Dock
5. Little Miss Muffet
6. Polly, Put the Kettle On
7. Toy land
8. Bingo
9. Oh Where Has My Little Dog Gone?

10. Old King Cole
11. Take Me Out to the B
12. Yankee Doodle
13. For He's a Jolly Goo
14. Good Morning, Merry
15. Itsy, Betsy Spider
16. Old MacDonald
17. On Top of Old Smoke
18. Skip to My Lou

SONG LYRICS

Song 1

Hey! I'm a happy kitten, and I love to sing.

Sing, sing, sing, sing, sing with me!

Song 2

A B C D E F G, H I J K L M N O P, Q R S, T U V, W X Y and Z

Song 3

Let's have fun, You and me!

Let's sing and jam together all day long!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

IMPORTANT NOTE

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-877-352-8697 in Canada, or by going to our website vtechkids.com and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against 11115555 harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name:	VTech
Model:	5610
Product Name:	Kiddie Cat Cassette Player
Responsible Party:	VTech Electronics North America, L.L.C.
Address	1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004
Website	vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-003(B)/NMB-003(B)

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com

vtechkids.ca

Read our complete warranty policy online at

vtechkids.com/warranty

vtechkids.ca/warranty




TM & © 2022 VTech Holdings Limited.

All rights reserved.

IM-561000-000

Version: 0

Documents / Resources

	<p>VTech 561000 Kiddie Cat Cassette Player [pdf] Instruction Manual 561000 Kiddie Cat Cassette Player, 561000, Kiddie Cat Cassette Player, Cat Cassette Player, Cassette Player</p>
---	---

References

- [!\[\]\(1207edb9a08751d3d55970560645ed23_img.jpg\) VTech Canada | Official Electronic Learning Toys & Games for Kids](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36_img.jpg\) VTech Canada | Official Electronic Learning Toys & Games for Kids](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9_img.jpg\) Best Kids Tech Toys | Electronic Learning Toys | VTech America](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec_img.jpg\) Best Kids Tech Toys | Electronic Learning Toys | VTech America](#)

Manuals+.