

# vtech 562600 2-in-1 Roll and Discover Roller Drum Instruction Manual

Home » vtech » vtech 562600 2-in-1 Roll and Discover Roller Drum Instruction Manual



# **Contents**

- 1 562600 2-in-1 Roll and Discover Roller
- 2 2-in-1 Roll & Discover Roller Drum™
- 3 Getting started
- **4 INTRODUCTION**
- **5 PRODUCT FEATURES**
- **6 ACTIVITIES**
- **7 SONG LYRICS**
- **8 CARE & MAINTENANCE**
- 9 TROUBLESHOOTING
- 10 Documents / Resources
- 10.1 References
- 11 Related Posts



562600 2-in-1 Roll and Discover Roller Drum



### 2-in-1 Roll & Discover Roller Drum™

The 2-in-1 Roll & Discover Roller Drum™ is an interactive toy that helps children strengthen their muscles and develop their motor skills. It features different activities such as tapping, rolling, pressing, spinning and turning, accompanied by songs and music. The toy also introduces animals and numbers with playful phrases, and includes a variety of melodies to keep children entertained.

# Included in the package:

- 2-in-1 Roll & Discover Roller Drum™
- · Battery cover screwdriver

# **Getting started**

#### To remove and install batteries:

- 1. Make sure the unit is turned off.
- 2. Use a screwdriver to loosen the screw on the battery cover located at the back of the unit, and then open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- 4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.
- 5. Replace the battery cover and tighten the screw to secure.

# **Product features**

- 1. **On/Off/Volume Selector:** To turn the unit on, slide the On/Off/Volume Selector to the Low volume position or the High volume position. To turn the unit off, slide the On/Off/Volume Selector to the Off position.
- 2. **Interactive Roller:** Roll the Roller to play sounds and music. When a melody is playing, roll the Roller or press the Drum Button to add fun sounds to the music. The lights will flash with the sounds.

3. **Automatic Shut-Off:** To preserve battery life, the 2-in-1 Roll & Discover Roller Drum™ will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing the Piano Keys or Drum Button.

#### **Activities**

1. Light-Up Piano Keys: Pressing the light-up

Piano Keys introduces animals and numbers with songs and playful phrases. The lights will flash with the sounds.

- 2. Turn, Slide & Spin: Strengthen little muscles with Gears, Rollers, Beads and a Ladybug Slider.
- 3. **Drum Button:** Tap on the Drum Button to hear drum sounds and watch the beads roll. The lights will flash with the sounds.

# Song lyrics:

Song 1

Tap the drum and play the piano, Switch it any way you like. One, two, tap, tap, tap. Three, four, clap, clap, clap. Five, six, just like that! We're going to have some fun!

### **Melody list:**


- 1. Mary Had a Little Lamb
- 2. Hickory, Dickory, Dock
- 3. The Bear Went Over the Mountain
- 4. Rockin' Robin
- 5. One, Two, Buckle My Shoe
- 6. Here We Go' Round Round the Mulberry Bush
- 7. The Alphabet Song
- 8. Bingo
- 9. Skip to My Lou
- 10. London Bridge
- 11. Three Little Kittens
- 12. Hey, Diddle, Diddle
- 13. Wheels on the Bus
- 14. Pat-A-Cake
- 15. Hot Cross Buns
- 16. Do You Know the Muffin Man?
- 17. Oh Where, Oh Where Has My Little Dog Gone?
- 18. Pease Porridge Hot

Note: If the unit powers down or if the light fades out during play, please install a new set of batteries.

# INTRODUCTION

Thank you for purchasing the 2-in-1 Roll & Discover Roller Drum™.

Tap, roll, press, spin and turn! Little ones will love to move with this interactive toy. From tummy time to sitting to crawling, kiddos can strengthen muscles as they hear songs, music and first words for animals and numbers.





# **INCLUDED IN THE PACKAGE**

- 2-in-1 Roll & Discover Roller Drum™
- · Quick Start Guide


# **WARNING**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

# **NOTE**

Please save this Instruction Manual as it contains important information.

# **Unlock the Packaging Locks**




- 1. Rotate the packaging locks 90 degrees counterclockwise.
- 2. Pull out the packaging locks and discard.

### **GETTING STARTED**

Battery Removal and Installation

- Make sure the unit is turned Off.
  Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw, and then open the battery cover.
- 2. Remove old batteries by pulling up on one end of each battery.
- 3. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
- 4. Replace the battery cover and tighten the screw to secure.



WARNING: Adult assembly required for battery installation. Keep batteries out of reach of children.

# **IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- · Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.

- · Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


### **RECHARGEABLE BATTERIES**

- Remove rechargeable batteries (if removable) from the toy before charging. Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

# **PRODUCT FEATURES**

### 1. On/Off/Volume Selector

To turn the unit On, slide the On/ Off/Volume Selector to the Low volume position or the High to You will hear sounds, phrases and a song. To turn the unit Off, slide the On/Off/Volume Selector to the Off position.



# 2. Interactive Roller

Roll the Roller to play sounds and music. When a melody is playing, roll the Roller or press the Drum Button to add fun sounds to the music. The lights will flash with the sounds



# 3. Automatic Shut-Off

To preserve battery life, the 2-in-1 Roll & Discover Roller Drum™ will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing the Piano Keys or Drum Button.


### **NOTE**

If the unit powers down or if the light fades out during play, please install a new set of batteries.

# **ACTIVITIES**


# 1. Light-Up Piano Keys

Pressing the light-up Piano Keys introduces animals and numbers with songs and playful phrases. The lights will flash with the sounds.



# 2. Turn, Slide & Spin

Strengthen little muscles with Gears, Rollers, Beads and a Ladybug Slider.



# 3. Drum Button

Tap on the Drum Button to hear drum sounds and watch the beads roll. The lights will flash with the sounds.



# **SONG LYRICS**

# Song 1

Tap the drum and play the piano, Switch it any way you like. One, two, tap, tap, tap.

Three, four, clap, clap, clap. Five, six, just like that!

We're going to have some fun!

# Song 2

Push, spin, roll with me,

Gently left and right!

# • Song 3

Tap, tap, tap

Clap, clap, clap

We tap, we clap.

We make fun beats in a snap!

# Song 4

Good morning, my dear friend. So many things to see,

Like colors, shapes and numbers. Let's see what we can see!

# Song 5

A hippo is big and strong,

Big and strong, big and strong

It loves the water to stay cool, To stay cool, to stay cool.

### Song 6

The zebra runs here and there With black and white stripes, One long tail and spiky mane And loves to play a lot!

# Song 7

Oh the king of the savanna,

Is the lion, is the lion!

Its fluffy mane and loud roar

Is recognized by all!

# **MELODY LIST**

- 1. Mary Had a Little Lamb
- 2. Hickory, Dickory, Dock
- 3. The Bear Went Over the Mountain
- 4. Rockin' Robin
- 5. One, Two, Buckle My Shoe
- 6. Here We Go' Round Round the Mulberry Bush
- 7. The Alphabet Song
- 8. Bingo
- 9. Skip to My Lou
- 10. London Bridge
- 11. Three Little Kittens
- 12. Hey, Diddle, Diddle
- 13. Wheels on the Bus
- 14. Pat-A-Cake
- 15. Hot Cross Buns
- 16. Do You Know the Muffin Man?
- 17. Oh Where, Oh Where Has My Little Dog Gone?

### **CARE & MAINTENANCE**

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries if the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.

#### **TROUBLESHOOTING**

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Please turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit On. The unit should now be ready to play again.
- 5. If the unit still does not work, install a new set of batteries.

#### IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you. Creating and developing VTech® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

#### CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **NOTE**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®

Model: 5626

**Product Name:** 2-in-1 Roll & Discover Roller Drum™ **Responsible** Party: VTech Electronics North America, L.L.C

Address: 1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004

Website: vechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

### **OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:**

- 1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- 2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

Visit our website for more information about our products, downloads, resources and more. vtechkids.com

vtechkids.ca

Read our complete warranty policy online at: <u>vtechkids.com/warranty</u>, <u>vtechkids.ca/warranty</u>

TM & © 2023 VTech Holdings Limited. All rights reserved. IM-562600-000 Version:0

### **Documents / Resources**



vtech 562600 2-in-1 Roll and Discover Roller Drum [pdf] Instruction Manual 562600 2-in-1 Roll and Discover Roller Drum, 2-in-1 Roller Drum, Roll and Discover Roller Drum, Drum, Roller Drum, Roller Drum, Boller Drum, Discover Roller Drum, 562600 Roller Drum, 562600

# References

- V VTech Canada | Official Electronic Learning Toys & Games for Kids
- V VTech Canada | Official Electronic Learning Toys & Games for Kids
- V Best Kids Tech Toys | Electronic Learning Toys | VTech America
- Best Kids Tech Toys | Electronic Learning Toys | VTech America

Manuals+