



## vtech 562903-OTTER Splashing Fun Otter Instruction Manual

[Home](#) » [vtech](#) » vtech 562903-OTTER Splashing Fun Otter Instruction Manual 

vtech 562903-OTTER Splashing Fun Otter



## Contents

- 1 IMPORTANT INFORMATION
- 2 INTRODUCTION
- 3 INCLUDED IN THE PACKAGE
- 4 INSTRUCTIONS
- 5 IMPORTANT: BATTERY INFORMATION
- 6 PRODUCT FEATURES
- 7 WARNINGS
- 8 ACTIVITIES
- 9 MELODY LIST
- 10 SONG LYRICS
- 11 CARE & MAINTENANCE
- 12 TROUBLESHOOTING
- 13 CONSUMER SERVICES
- 14 Product Warranty/ Consumer Guarantees
- 15 Documents / Resources
  - 15.1 References

## IMPORTANT INFORMATION


VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level ...

<b>Vtech Boy</b> Toys that will stimulate their interest in different textures, sounds and colours	<b>Pre-School</b> Interactive toys to develop their imagination and encourage language development	<b>Electronic learning computers</b> Cool, aspirational and inspiring computers for curriculum related learning
<b>I am ...</b> ... responding to colours, sounds and textures ... understanding cause and effect	<b>I Want...</b> ... to get ready for school by starting to learn the alphabet and counting ... my learning to be as fun, easy and exciting as can be ... to show my creativity with drawing and music so my whole brain develops	<b>I need ...</b> ... challenging activities that can keep pace with my growing mind ... intelligent technology that adapts to my level of learning ... National Curriculum based content to support what I'm learning at school



## INTRODUCTION

Introducing the Splashing Fun Otter by VTech®! Have lots of bath time fun with Otter and his fish pourers! Meet Otter's light up starfish friend who introduces fun responses, melodies and sing-along songs. We can have lots of bath time fun together!



## INCLUDED IN THE PACKAGE

- One Splashing Fun Otter
- One Quick Start Guide
- Three Different Size Fish Pourers

## WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

## NOTE

Please keep this Instruction Manual as it contains important information.


## INSTRUCTIONS

### Battery Removal and Installation

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old battery by pulling up on one end of the battery.
4. Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box. (For best performance,

alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).

5. Replace the battery cover and tighten the screw to secure.



**WARNING:**

Adult assembly required for battery installation. Keep batteries out of reach of children.

**IMPORTANT: BATTERY INFORMATION**

Insert batteries with the correct polarity (+ and -).

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

**RECHARGEABLE BATTERIES:**

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

**Disposal of batteries and product**



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



■ The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation. The solid bar indicates that the product was placed on the market after 13th August, 2005. Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point\* so all of its materials


can be recycled. Learn more at: [www.vtech.co.uk/recycle](http://www.vtech.co.uk/recycle)  
[www.vtech.com.au/sustainability](http://www.vtech.com.au/sustainability)

\* Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

## PRODUCT FEATURES

### 1. On/Off Button

To turn the unit On, press the On/ Off Button. You will hear a sound, phrase and a song. To turn the unit Off, press the On/Off Button again. The unit will shut down after playing a phrase and short melody.



### 2. Automatic Shut Off

To preserve battery life, the Otter will automatically power-down after approximately 45 seconds without input. The Otter can be turned on again by pressing the On/Off Button or Light Up Starfish Button.

#### NOTE:

If the unit powers down while playing, please install a new battery.


## WARNINGS

**The batteries must be changed by an adult.**

- This toy cannot be used in salt water.
- After using this toy, do not leave it in the water for a long time.
- Make sure to empty the water out of all elements of the toy and to rinse them out before drying.
- This toy can be operated in water only when fully assembled in accordance with the instructions.
- This is not a lifesaving device. Do not leave your child unattended while in water.
- Never leave a child unattended or with an older child in the bathroom or in the bath, not even for one minute.
- Always check with a thermometer the temperature of the water coming from the tap before sitting your child in the bath. Children have very sensitive skin and can easily get burnt if the water is too hot.
- When closing the battery cover ensure that the screw is securely tightened. This will avoid any water leakage.
- Only use this unit in water between 10 and 45 degrees centigrade.
- Parents should drain the water from the speaker if the volume decreases too much.

## ACTIVITIES

1. Light Up Starfish Button Press the Light Up Starfish Button to hear playful songs and melodies. The starfish will flash with the sounds.



## 2. Otter

Put the Otter in or out of the water to trigger the water sensor and play fun phrases and sounds. When a song or a melody is playing, take the Otter in or out of the water to hear a fun sound play over the top of the song or melody. The light will flash with the sounds.

## MELODY LIST

1. Alphabet Song
2. A-Tisket A-Tasket
3. Entertainer
4. Flying Trapeze
5. Girls and Boys Come Out to Play
6. Hey Diddle Diddle
7. Hot Cross Buns
8. Humpty Dumpty
9. I'm Forever Blowing Bubbles
10. London Bridge
11. Mulberry Bush
12. Old MacDonald
13. Row, Row, Row Your Boat
14. Sailing Sailing
15. Toyland

## SONG LYRICS

### Song 1

Swimming here and swimming there, My wheel is spinning here and there.  
Splashing, bobbing and floating. I even like to sing, sing, sing.

### Song 2

Bath time is really fun, Let's wash and sing along, Washing is so much fun, We are all getting clean!

### Song 3

I am a little Otter who likes to splash in the water. Let's splash, splash, splash!

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit ON. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you

## CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you. UK Customers:

**Phone:** 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

**Website:** [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

**Australian Customers:**

**Phone:** 1800 862 155

**Website:** [support.vtech.com.au](http://support.vtech.com.au)

**NZ Customers:**

**Phone:** 0800 400 785

**Website:** [support.vtech.com.au](http://support.vtech.com.au)

## Product Warranty/ Consumer Guarantees

**UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

**Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited.

Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

Visit our website for more information about our products, downloads, resources and more.

[www.vtech.co.uk](http://www.vtech.co.uk)

[www.vtech.com.au](http://www.vtech.com.au)

TM & © 2023 VTech Holdings Limited.


All rights reserved. IM-562900-000 Version:0





---

## Documents / Resources

 The image shows the cover of the instruction manual for the Vtech 562903-OTTER Splashing Fun Otter. It features a small illustration of the otter toy and the text "vtech Instruction Manual" and "Splashing Fun Otter".	<p><a href="#">vtech 562903-OTTER Splashing Fun Otter</a> [pdf] Instruction Manual 562903-OTTER Splashing Fun Otter, 562903-OTTER, Splashing Fun Otter, Fun Otter</p>
--	---

## References

- [Support : VTech Electronics](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.