



**5790 Buzz  
and Learn  
Activity Table**



## vtech 5790 Buzz and Learn Activity Table Instruction Manual

[Home](#) » [vtech](#) » vtech 5790 Buzz and Learn Activity Table Instruction Manual 

### Contents

- 1 vtech 5790 Buzz and Learn Activity Table
- 2 INTRODUCTION
- 3 INCLUDED IN THE PACKAGE
- 4 GETTING STARTED
- 5 ASSEMBLY INSTRUCTIONS
- 6 LABEL APPLICATION
- 7 PRODUCT FEATURES
- 8 ACTIVITIES
- 9 SONG LYRICS
- 10 CARE & MAINTENANCE
- 11 TROUBLESHOOTING
- 12 FCC
- 13 CONTACT INFORMATION
- 14 WARRANTY
- 15 FAQs
- 16 Documents / Resources
  - 16.1 References



**vtech 5790 Buzz and Learn Activity Table**



## INTRODUCTION

Thank you for purchasing the VTech® Buzz & Learn Activity Table™! The Buzz & Learn Activity Table™ features seven engaging play zones designed to stimulate visual and tactile development, while enhancing playtime fun. Pressing the buttons and flipping the pages of the animal-themed book reveal delightful phrases, cheerful songs, and exciting sound effects to captivate young learners.



### INCLUDED IN THE PACKAGE

- Buzz & Learn Activity Table™
- Quick Start Guide



3 Panels



1 Panel Base



4 Table Legs




3 Gear Flowers



3 Blocks




1 Beehive



3 Bead Tracks



1 Label Sheet



9 Screws

#### • WARNING

- All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.


#### • NOTE

- Please keep this Quick Start Guide as it contains important information.

### Unlock the Packaging Locks

- (The packaging locks are not included in a sealed box.)

1. Turn the packaging locks counterclockwise several times.
2. Pull out and discard the packaging locks.




**CAUTION:**

- Adult assembly required.
- This package contains small parts.
- For your child's safety, do not let your child play with the toy until it is fully assembled.

**GETTING STARTED****Battery Removal and Installation**

1. Make sure the unit is turned Off.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.

**WARNING:**

Adult assembly required for battery installation. Keep batteries out of reach of children.

**IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.



## RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## ASSEMBLY INSTRUCTIONS

With the Buzz & Learn Activity Table™ safety comes first. To ensure your child's safety, adult assembly is required. For your child's safety, do not let your child play with the toy until it is fully assembled.

### 1. Installing the Panels

- Combine the 3 panels in order according to the numbers marked on the back, and fasten them with nine screws.



### 2. Installing the Beehive

- Align the top of the beehive to the bottom of the beehive and press down to make sure it inserts properly.






### 3. Installing the Flowers

- Insert the 3 gear flowers according to the size of the holes in the panel.




#### 4. Installing the Bead Tracks

- Align the two ends of the three bead tracks with their corresponding holes on the panels and insert them securely.




#### 5. Installing the Table Legs

- Attach the table legs by inserting them into the sockets located at the bottom of each panel.




#### 6. Removing the Table Legs

- To disassemble the table legs, please flip the table over, press up on the designated area and gently pull out the table legs from the back of each panel.






#### LABEL APPLICATION

Please securely stick the labels to the table as indicted below:



## PRODUCT FEATURES

### 1. Off/On/Volume Selector

- To turn the unit On, slide the Off/On/ Volume Selector to the Low volume  or the High volume position . You will hear fun sounds, a phrase and a song. To turn the unit Off, slide the Off/On/Volume Selector to the Off position .



### 2. Automatic Shut-Off

- To conserve battery life, the Buzz & Learn Activity Table™ will automatically power down after a period of inactivity. To reactivate, simply press any button or flip the storybook.



**NOTE** If the unit powers down or if the light fades out during play, please install a new set of batteries.

## ACTIVITIES

### 1. Light-Up Buttons

- Press the Light-Up Buttons to see a fox pop-up, hear sounds, melodies, sing-along songs and fun phrases.



### 2. Storybook

- Flip the page of the Storybook to hear short tunes, animals sounds and phrases.



### 3. Flower Gears

- Turn and see all the Flower Gears spin.



### 4. Beehive Sorter

- Sort the blocks in the Beehive Sorter, then pop them out.



#### 5. Forest Friends Maze

- Slide the Forest Friends back and forth.



#### 6. Wiggly Honey Bear

- Wiggle the honeypot to make Bear dance.



#### 7. Bead Tracks

- Slide the beads on the Bead Tracks from one side to the other.



1. A-Tisket A-Tasket
2. Bingo
3. Diddle, Diddle Dumpling
4. Do You Know the Muffin Man?
5. Hickory Dickory Dock
6. Itsy Bitsy Spider
7. London Bridge
8. Looby Loo
9. Oh Where, Oh Where Has My Little Dog Gone
10. One, Two, Buckle My Shoe
11. Skip to my Lou
12. Frere Jacque
13. Good Morning Merry Sunshine
14. Humpty Dumpty
15. Ten In The Bed

## **SONG LYRICS**

- **Song 1**

- Bees and foxes, bears and deer, Otters too, all gather near, In the woods they play and cheer, Friends both far and near.

- **Song 2**

- Follow the bee, let's go to the forest. So many animal friends, I can't wait to meet!

- **Song 3**

- In the forest, come explore, explore. Find new wonders, so much more, much more.

## **CARE & MAINTENANCE**

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## **TROUBLESHOOTING**

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

## **IMPORTANT NOTE**

If the problem persists, please contact our Consumer Services Department at 1- [800-521-2010](tel:800-521-2010) in the U.S. or 1-[877-352-8697](tel:877-352-8697) in Canada, or by going to our website at [vtechkids.com](http://vtechkids.com) and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## FCC

**NOTE** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## CONTACT INFORMATION

### Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

- **Trade Name:** VTech®
- **Model:** 5790
- **Product Name:** Buzz & Learn Activity Table™
- **Responsible Party:** VTech Electronics North America, L.L.C.
- **Address:** 1156 W. Shure Drive, Suite 200, Arlington Heights, IL 60004
- **Website:** [vtechkids.com](http://vtechkids.com)

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION. CAN ICES(B)/NMB(B)

## WARRANTY

Visit our website for more information about our products, downloads, resources and more.




- [vtechkids.com](http://vtechkids.com)
- [vtechkids.ca](http://vtechkids.ca)
- Read our complete warranty policy online at [vtechkids.com/warranty](http://vtechkids.com/warranty)
- [vtechkids.ca/warranty](http://vtechkids.ca/warranty)

## FAQs

- **Q: What is the recommended age for this product?**
  - A: The Buzz & Learn Activity Table™ is recommended for children aged 6 months and up.
- **Q: What type of batteries does this product require?**
  - A: This product requires 2 AA (AM-3/LR6) batteries for operation. Alkaline or fully charged Ni-MH rechargeable batteries are recommended for best performance.

## Documents / Resources

	<p><a href="#">vtech 5790 Buzz and Learn Activity Table</a> [pdf] Instruction Manual 579000, 5790 Buzz and Learn Activity Table, 5790, Buzz and Learn Activity Table, Learn Activity Table, Activity Table, Table</p>
---	---

## References

- [User Manual](#)

### Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.