



vtech 80-568400 Beep and Go Blocks



Contents [[hide](#)]

[1 INTRODUCTION](#)

[2 INCLUDED IN THE PACKAGE](#)

[3 GETTING STARTED](#)

[4 PRODUCT FEATURES](#)

[5 ACTIVITIES](#)

[6 MELODIES](#)

[7 SONG LYRICS](#)

[8 CARE & MAINTENANCE](#)

[9 TROUBLESHOOTING](#)

[10 CUSTOMER SUPPORT](#)

[11 Documents / Resources](#)


[11.1 References](#)

INTRODUCTION

Thank you for purchasing the Beep & Go Blocks™.

Stack the colorful blocks on the floor or in the back of the truck and roll it around to make special deliveries. Press and explore the learning buttons and learn new words and hear playful sounds and melodies.

It's truckloads of play!



INCLUDED IN THE PACKAGE

- Beep & Go Blocks™
- 4 Blocks
- Quick Start Guide

WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks


1. Rotate the packaging locks 90 degrees counterclockwise.
2. Pull out the packaging locks and discard.



GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned Off.
2. Find the battery cover located on the bottom of the truck, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box.
(The use of new, alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



 **WARNING:**

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES


- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit On, slide the On/Off/ Volume Switch to the Low volume  or High volume  position. You will hear fun sounds, a song and a phrase.

To turn the unit Off, slide the On/Off/ Volume Switch to the Off  position.



2. Automatic Shut-Off

To preserve battery life, the Beep & Go Blocks™ will automatically power down after approximately 35 seconds without input. The unit can be turned On again by pressing any button.

NOTE

This product is in try-me mode in the packaging. To activate normal play, turn the unit Off, then turn the unit back On. If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Light-Up Number Button

Press the Light-Up Number Button to learn about numbers and counting through phrases and a song. The light will flash with the sound.



2. Music Button

Press the Music Button to hear melodies and sung songs. The light will flash with the sound.



3. Zebra Button

Press the Zebra Button to hear phrases to help encourage play. The light will flash with the sound.



4. Truck Buttons

Stack the Blocks on the truck, then press one of the Animals or press one of the Truck Buttons when none of the blocks are on the truck to hear fun sounds and music. The light will flash with the sound.



MELODIES

1. Yankee Doodle
2. Jack Be Nimble
3. London Bridge
4. Skip to My Lou
5. On Top of Old Smokey
6. Here We Go Round the Mulberry Bush
7. A-Ticket, A-Tacket
8. Hickory Hickory Dock
9. Diddle, Diddle, Dumpling
10. Grandfather's Clock
11. Glow Worm
12. Old King Cole

SONG LYRICS

Song 1

The blocks are all different colors, Stack them and you'll discover, Spinning, sliding, peek-a-boo.

Press them to see a surprise!

Song 2

One and two and three and four, Stack up the blocks and see what they do.
Stack them on the truck, one by one, Beep, beep, now we're ready for fun!

Song 3

The truck rumbles down the road.
Delivering loads wherever it goes.
Load the blocks, it's time to go!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please contact our Consumer Services Department at 1-[800-521-2010](tel:8005212010) in the U.S., 1-[877-352-8697](tel:8773528697) in Canada, or by going to our website vtechkids.com and filling out our Contact Us form located under the Customer Support link.

Creating and developing V Tech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to

contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®

Model: 5684

Product Name: Beep & Go Blocks™

Responsible Party: VTech Electronics North America, L.L.C.

Address: 1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004

Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND.
2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES(B)/NMB(B)

CUSTOMER SUPPORT

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com

vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty

vtechkids.ca/warranty

© 2025 VTech Holdings Limited.


All rights reserved.

IM-568400-000

Version:0



Documents / Resources



[vtech 80-568400 Beep and Go Blocks \[pdf\]](#) Instruction Manual
80-568400 Beep and Go Blocks, 80-568400, Beep and Go Blocks, and G
o Blocks, Go Blocks

References

- [User Manual](#)

80-568400, 80-568400 Beep and Go Blocks, and Go Blocks, Beep and Go Blocks, Go Blocks,

vtech vtech

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

[Post Comment](#)

Search:

[Search](#)

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.