




Contents [[hide](#)]

- [1 vtech BC8211 Go Portable Soother](#)
- [2 Product Usage Instructions](#)
- [3 Important safety instructions](#)
- [4 What's in the box](#)
- [5 Technical specifications](#)
- [6 Charge the battery](#)
- [7 Position the soother](#)
- [8 Overview](#)
- [9 Use the soother](#)
- [10 General product care](#)
- [11 Customer service and product warranty](#)
- [12 Customer Support](#)
- [13 FAQ](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)



vtech BC8211 Go Portable Soother






Product Usage Instructions

- Always follow the warnings and instructions on the product.
- An adult setup is required for operation.
- Avoid using the soother near water sources.
- Charging should be done by an adult only with a compatible USB power supply.
- Ensure proper ventilation for the product and avoid blocking any openings.
- Do not place the product on unstable surfaces.
- Regularly check for any damage to components.
- Supervise children when using the product.
- Use and store the product within the recommended temperature range.
- Avoid exposing the product to extreme conditions.
- Keep cords and cables out of children's reach to prevent strangulation hazards.


Important safety instructions

The applied nameplate is located at the bottom of the soother base.

When using your soother, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1. Follow all warnings and instructions marked on the product.
2. Adult setup is required.
3. Do not use this product near water, for example, near to a bath, sink, swimming pool or shower.
4. **CAUTION:** Use only the internal, non-user-replaceable battery fitted to the Soother. There may be a risk of explosion if the wrong type of battery is used for the Soother. The battery cannot be subjected to high or low extreme temperatures and low air pressure at high altitude during use, storage or transportation. Disposal of batteries in fire or a hot oven, mechanically crushing or cutting the battery, can result in an explosion. Subjecting products or batteries to an extremely high temperature environment can result in an explosion or leakage of flammable liquids or gas. Products or batteries subjected to extremely low air pressures may result in an explosion or leakage of flammable liquids, or gas.
5.   Rechargeable battery information: 2.4V 750mAh (29-224075-203-102 (GPI) / 29-224075-208-100 (Corun)) Ni-MH battery
6. Charging should only be done by an adult.
7. Only connect to a USB power supply bearing the following symbol .
8. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
9. Do not allow anything to rest on the power USB cable. Do not install this product where the USB cable may be walked on or damaged.
10. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
11. This product should not be placed in any area where proper ventilation is not provided. Any slots or openings in the back or bottom of this product are provided for ventilation. To protect from overheating, openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat source.
12. Never insert any objects through any apertures or slots in the product as this can be dangerous and cause damage to the battery or other internal parts. Never spill any liquids on the product.
13. To reduce the risk of electric shock, do not disassemble this product, but take it to an

authorised service facility. Disassembling or removing parts of the product other than battery replacement via a battery door (if applicable) may expose dangerous voltages or other risks.

14. Periodically examine all components for damage.
15. Children should be supervised to ensure that they do not play with the product.
16. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
17.  This product is for indoor use only.

SAVE THESE INSTRUCTIONS

Caution

1. Use and store the product at a temperature between 0oC and 40oC.
2. Do not expose the product to extreme cold, heat or direct sunlight. Do not place the product close to a heat source.
3. Warning—Strangulation Hazard—Children have STRANGLED with cords and cables. Keep the supplied USB cable and attachment strap out of the reach of children (more than 0.9m away). Never place the product inside the baby's cot or playpen. Never cover the product with anything such as a towel or a blanket. Do not remove the warning label on the USB cable.



4. Never place the product inside the baby's cot or playpen. Never cover the product with anything such as a towel or a blanket.


Credits:

- The Background Noise sound file was created by Caroline Ford and is used under the Creative Commons license.
- The Stream Noise sound file was created by Caroline Ford and is used under the Creative Commons license.
- The Crickets At Night sound file was created by Mike Koenig and is used under the


Creative Commons license.

- The 20121230_vacuum.cleaner.working.01 sound file was created by dobroide, and is used under the Creative Commons license.
- The Heartbeat 5sec Int sound file was created by Benboncan and is used under the Creative Commons license.


What's in the box




Soothen



Attachment strap



USB cable



Quick Start Guide

Technical specifications

- Power requirements
- Built-in rechargeable 2.4V 750mAh (29-224075-203-102 (GPI) / 29-224075-208-100

(Corun))


- Ni-MH battery
- Charging via USB cable to computer or low power USB power adaptor (Maximum 5V, 0.5A)

Charge the battery

- This portable soother has a built-in rechargeable battery for cordless usage.
- To charge the battery, use the provided USB cable to connect the soother to a power source to a USB port, such as a computer, low-power USB power adaptors (maximum 5V, 0.5A), or a portable low-power USB charger (maximum 5V, 0.5A).

NOTE

- Make sure the soother and the USB cable are out of reach of children while charging.
- The soother battery is fully charged after 12 hours of continuous charging. The battery status light turns on during charging and turns off when the battery is fully charged.
- The USB port is for charging only.




Position the soother

CAUTION

- This is not a toy. Do not let your baby play with the product.
- Keep the soother out of the reach of your baby. Never place or attach the soother inside the baby's cot or playpen.
- You can use the tail on the soother or the additional strap provided to hang and attach the soother to a convenient location, e.g. stroller handle, doorknob, etc.


Using the tail

Use the tail to hook the soother around a convenient object to keep it in position.




Using the additional strap



1. To attach the additional strap provided onto the soother, pinch the end of the string and insert it into the slot on the top of the soother. Insert the other end of the strap through the loop of the string, then pull the strap to tighten it. Note that each side of the strap is 13cm in length.









2. Wrap the velcro strap around a convenient object and secure the tape by pressing the two tape ends against each other.





Overview

1	 Lullaby <ul style="list-style-type: none"> • Press to play or stop the lullaby.
2	vol – <ul style="list-style-type: none"> • Press to decrease the speaker volume.
3	 Auto-off timer <ul style="list-style-type: none"> • Press to turn on a 60-minute timer while playing a lullaby or soothing sound. It will automatically stop the lullaby or soothing sound after playing for 60 minutes.

4	 Skip <ul style="list-style-type: none"> • Press to skip to the next lullaby or soothing sound.
5	Tail <ul style="list-style-type: none"> • Hook the soother on an object.
6	Dimmable soft-glow night light
7	 Soothing sound <ul style="list-style-type: none"> • Press to play or stop the soothing sound.
8	vol + <ul style="list-style-type: none"> • Press to increase the speaker volume.

9	 Dimmable soft-glow night light <ul style="list-style-type: none"> • Press to turn the night light on with a dim light or a bright light.
10	 on/off switch <ul style="list-style-type: none"> • Slide to power on or off the soother.
11	USB port for battery charging only
12	A slot for securing the additional strap
13	Speaker
14	 Auto-off timer light indicator <ul style="list-style-type: none"> • When the auto-off timer feature is turned on. • Off when the auto-off timer feature is turned off.
15	 Battery status light indicator <ul style="list-style-type: none"> • When the battery is being charged. • Flashes when the battery is low and needs charging. • Off when the battery is not being charged, or the battery is fully charged.



Use the soother

Power on or off the soother

- Slide the on/off switch on the right-hand side of the soother to on or off.

NOTE




- Make sure the soother is on before using other features.

Play the lullaby

The soother has five lullabies for you to comfort your baby.

1. Hush Little Baby
2. Brahms' Lullaby
3. Rock a Bye Baby
4. Twinkle Twinkle Little Star

5. Minuet in G, Bach

- Press  to start playing lullabies.
- Press  to skip to the next lullaby.
- While a lullaby is playing, press  again to stop the lullaby.




NOTE

- The soother will play the lullabies continuously until you manually stop the lullabies or turn on the auto-off timer feature.
- When a lullaby ends, the soother automatically skips to the next lullaby. After the soother plays the fifth lullaby, it automatically continues to play from the first lullaby again.

Play the soothing sound

The soother has five soothing sounds for you to comfort your baby.

1. White noise
2. Stream
3. Crickets
4. Vacuum cleaner
5. Heartbeat

- Press  to start playing soothing sounds.
- Press  to skip to the next soothing sound.
- While  a soothing sound is playing, press again to stop the soothing sound.

NOTE

- The soother will play the soothing sounds continuously until you manually stop the soothing sounds or turn on the auto-off timer feature.
- The soother will play the same soothing sound repeatedly until you skip to another soothing sound.

Adjust the speaker volume


- Press vol- or vol+ at any time.

NOTE


- The soother beeps to notify you when the speaker volume is already at the highest or lowest setting while adjusting.

Turn on or off the auto-off timer

While the soother is playing a lullaby or soothing sound, the auto-off timer feature helps you automatically stop the lullaby or soothing sound after playing for 60 minutes.

1. While a lullaby or soothing sound is playing, press  to turn on the auto-off timer feature.
 - The soother starts counting down from 60 minutes. The auto-off timer light indicator on the left-hand side of the soother turns on.
2. After 60 minutes, the soother will automatically stop any lullaby or soothing sound. The auto-off timer feature and the corresponding light indicator will turn off.

NOTE

- You can only turn on the auto-off timer feature when the soother is playing a lullaby or soothing sound.
- The soother will remain on after the 60-minute countdown has expired.
- You can press  again to turn off the auto-off timer feature during the 60-minute countdown.
- If you manually stop the lullaby or soothing sound while the auto-off timer is counting down, the auto-off timer will turn off.

Turn on or off the dimmable softglow night light

When the soother is on, press  repeatedly to choose from below night light options:

- Turn on the night light in dim light mode, or
- Turn on the night light in bright light mode, or
- Turn off the night light.

NOTE

- The night light will automatically turn off after 15 minutes.

General product care

To keep this soother working well and looking good, follow these guidelines:

- Avoid placing near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the product or treating it roughly.
- Clean with a soft damp cloth.
- DO NOT immerse the soother in water and do not clean under running water.
- DO NOT use solvents, household cleaning sprays, or liquid cleaners.
- Make sure the soother is dry before reconnecting to the mains supply.

Storage

When you are not intending to use the soother for some time, store the product and the USB cable in a cool, dry place.

Customer service and product warranty

PRODUCT WARRANTY

Thank you for choosing this quality product from VTech.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase
3. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
4. This warranty is personal to the original purchaser and is not transferable.
5. Breakages to the case is not covered by the warranty.

Email: service-ukbm@vtechphones.eu



VTech Electronics Europe Plc, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane,
West Hallam, DE7 6HE


THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT
CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and only. For products purchased outside the UK and ,
please contact your local distributor or place of purchase.

Declaration of Conformity


- This product is intended for use within Europe and UK.
- This equipment complies with the essential requirements of EU Radio Equipment Directive (2014/53/ EU) and the UK Radio Regulations 2017 on radio systems and telecommunication equipment.
- VTech Telecommunications Ltd. hereby declares that V-Hush™ Go Portable Soother BC8211 complies with the essential requirements and other relevant provisions of EU Radio Equipment Directive (2014/53/EU) and UK Radio
- Equipment Regulations 2017.
- The Declaration of Conformity for the V-Hush™ Go Portable Soother BC8211 is available from www.vtechphones.eu.

Disposal of batteries and products

-  The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicate they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.
- The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in

Battery Directive (2006/66/EC).



-  The solid bar indicates that the product was placed on the market after 13th August, 2005.
- Help protect the environment by disposing of your product or batteries responsibly.

Customer Support

- Find the answer to your questions and get assistance at your own pace.
- Scan the QR code to access the website or visit www.vtechphones.eu







IMPORTANT

Please retain your sales receipt as proof of the date of purchase.

- Manufacturer: VTech Telecommunications Ltd.
- 23/F., Tai Ping Industrial Centre, Block 1, 57 Ting Kok Road, Tai Po, Hong Kong.
- Importer: VTech Electronics Europe Plc.
- Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT.
- Specifications are subject to change without notice.
- © 2025 VTech Telecommunications, Ltd.
- All rights reserved. 1/25. BC8211_CIB_UK_V1

FAQ

- Below are the questions most frequently asked about the soother. If you cannot find the answer to your question, visit our website at www.vtechphones.eu

<p>The soother does not play sounds / the night light does not turn on.</p>	<ul style="list-style-type: none"> • Make sure the soother is turned on. • Make sure the battery has enough charge. Connect the soother to USB power if necessary.
<p>Why does the  Battery status light indicator flash?</p>	<p>The soother battery is low and needs charging. Connect the soother to USB power to charge the battery.</p>
<p>When I press  to turn on the auto-off timer, the soother beeps. The  light indicator doesn't turn on.</p>	<p>The auto-off timer feature has not turned on. Make sure you press  when the soother is playing a lullaby or soothing sound.</p>
<p>Why doesn't my computer detect the soother when connected via USB cable?</p>	<p>The USB port on the soother is for charging only. It does not support data transfer.</p>

Q: Can the soother be used outdoors?

A: No, the product is intended for indoor use only.

Q: How should I clean the soother?

A: Unplug the product before cleaning and use a damp cloth. Do not use liquid or

aerosol cleaners.

Q: Can I charge the product with any USB power supply?

A: No, only connect to a USB power supply bearing the specified symbol.


Q: What should I do if I notice any damage to the components?

A: Stop using the product and contact an authorized service facility for inspection and repair.

Q: Is it safe to leave the product near a heat source?

A: No, do not place the product near any heat sources or in direct sunlight.

Documents / Resources

	vtech BC8211 Go Portable Soother [pdf] Instruction Manual BC8211 Go Portable Soother, BC8211, Go Portable Soother, Portable Soother
---	--

References

- [User Manual](#)

BC8211, BC8211 Go Portable Soother, Go Portable Soother, Portable Soother,

vtech vtech

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.