



vtech Bounce & Discover Llama Instruction Manual

[Home](#) » [vtech](#) » vtech Bounce & Discover Llama Instruction Manual 

Contents

- 1 vtech Bounce & Discover Llama
- 2 INTRODUCTION
- 3 INCLUDED IN THE PACKAGE
- 4 GETTING STARTED
- 5 ASSEMBLY INSTRUCTIONS
- 6 PRODUCT FEATURES
- 7 ACTIVITIES
- 8 MELODY LIST
- 9 CARE & MAINTENANCE
- 10 TROUBLESHOOTING
- 11 Documents / Resources
- 12 Related Posts




vtech Bounce & Discover Llama



INTRODUCTION

Thank you for purchasing the Bounce & Discover Llama™. Take this cute little llama for a spin! With up-and-down and side-to-side motion, this sweet animal helps kids develop strength and balance while teaching colors, shapes and numbers.



INCLUDED IN THE PACKAGE

- Bounce & Discover Llama™



Llama



Support Base



Handle



Support Post

- Four screws
- Quick Start Guide

WARNING


All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

GETTING STARTED

Battery Removal and Installation



1. Make sure the unit is turned Off.
2. Find the battery cover located on the back of the handle. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on the side of each battery.
4. Install 2 new AAA batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.

- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

ASSEMBLY INSTRUCTIONS


With the Bounce & Discover Llama™ safety comes first. To ensure your child's safety, adult assembly is required. This package contains four screws. For your child's safety, do not let them play with this toy until it is fully assembled.



1. Insert the bottom of the Support Post into the slot on the top of the Support Base. You will hear a click to indicate that the Support Post is attached securely to the Support Base.
2. Insert the bottom of the Llama onto the top of the Support Post. You will hear a click to indicate that the Llama is attached securely to the Support Post.
3. Insert the Handle behind the Llama's ears. Insert and tighten the four included screws.

PRODUCT FEATURES

1. On/Off/Volume Selector To turn the unit On, slide the On/Off/ Volume Selector to the Low volume or High volume position. You will hear a song, a welcoming phrase and sounds. To turn the unit Off, slide the On/Off/Volume Selector to the Off position.



2. Automatic Shut-Off To preserve battery life, the Bounce & Discover Llama™ will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

NOTE If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Shape Buttons



Press the Shape Buttons to learn about numbers, colors and shapes as well as hear fun sounds, melodies and songs. When a song or melody is playing, bounce up and down on the llama to add fun sounds and phrases over the music. The lights will flash with the sounds.

2. Bouncing Llama



Bounce up and down on the llama to hear fun sounds and phrases. Bouncing up and down continuously for several seconds will activate songs or melodies. When a song is playing, bounce the llama to add fun sounds over the songs. If a melody is playing and the bouncing stops, the melody will also stop. Continue bouncing to hear the melody continue. The lights will flash with the sounds.

MELODY LIST

1. Bingo
2. Little Miss Muffet
3. The Green Grass Grew All Around
4. Yankee Doodle
5. Looby Loo
6. Ride a Cock Horse to Banbury Cross
7. Toyland
8. Skip to My Lou
9. Old MacDonald

10. Hey, Diddle, Diddle

SONG LYRICS

Song 1

Bounce, bounce, up and down, bouncing all day long!
Bouncing, bouncing, bouncing, bouncing, It's fun to bounce along!

Song 2

I'm a little llama, I love to count,
One, two, three. One, two, three!
Let's count and bounce together!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®

Model: 5477

Product Name: Bounce & Discover Llama™

Responsible Party: VTech Electronics North America, LLC

Address: 1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004

Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAUTION:

This package contains small parts.

ADULT ASSEMBLY REQUIRED.

For your child's safety, do not let your child play with the toy until it is fully assembled.

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com


vtechkids.ca

Read our complete warranty policy online at

vtechkids.com/warranty

vtechkids.ca/warranty

Documents / Resources

	<p>vtech Bounce & Discover Llama [pdf] Instruction Manual vtech, Bounce Discover, Llama</p>
---	---