



# VTech LS6405 Cordless Handset User Guide

[Home](#) » [vtech](#) » VTech LS6405 Cordless Handset User Guide 

## Contents

- 1 VTech LS6405 Cordless Handset
- 2 Important safety instructions
- 3 SAVE THESE INSTRUCTIONS
- 4 About cordless telephones
- 5 What's in the box
- 6 Charger installation
- 7 Battery installation and charging
- 8 Battery charging
- 9 Add and register a handset
- 10 To register a handset
- 11 Deregister handsets
- 12 To reset
- 13 Handset overview
- 14 IMPORTANT!
- 15 Need help?
- 16 FCC, ACTA, and IC regulations
- 17 Industry Canada
- 18 California Energy Commission battery charging testing instructions
- 19 Limited Warranty
- 20 Other limitations
- 21 Technical specifications
- 22 Documents / Resources
- 23 Related Posts

## VTech LS6405 Cordless Handset



### Important safety instructions

**When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury, including the following:**

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. **CAUTION:** Do not install the telephone base at a height above 2 meters.
5. Do not use this product near water such as near a bathtub, wash bowl, kitchen sink, laundry tub, or swimming pool, nor in a wet basement or shower.
6. Do not place this product on an unstable table, shelf, stand, or other unstable surfaces.
7. Avoid placing the telephone system in places with extreme temperatures, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids, and fumes.
8. Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.
9. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
10. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
11. Never push objects of any kind into this product through the slots in the telephone base or handset because

- they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
12. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.
  13. Do not overload wall outlets and extension cords.
  14. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
    - When the power supply cord or plug is damaged or frayed.
    - If liquid has been spilled onto the product.
    - If the product has been exposed to rain or water.
    - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to normal operation.
    - If the product has been dropped and the telephone base and/or handset has been damaged.
    - If the product exhibits a distinct change in performance.
  15. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.
  16. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle if the phone is located in an environment containing concentrations of flammable or flame-supporting gases unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
  17. Only put the handset of your telephone next to your ear when it is in normal talk mode.
  18. The power adapter is intended to be correctly oriented in a vertical or floor-mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under the table, or cabinet outlet.
  19. For pluggable equipment, the socket outlet shall be installed near the equipment and shall be easily accessible.
  20. **CAUTION:** Use only the batteries indicated in this manual. There may be a risk of explosion if the wrong type of battery is used. Use only the supplied rechargeable batteries or replacement batteries. Do not dispose of batteries in a fire. They may explode. Dispose of the used battery according to the instruction. Disconnect the telephone line from the equipment before opening the battery door.
    - **Do not use the battery under the following conditions:**
      - The high or low extreme temperature during use, storage, or transportation.
      - Replacement of a battery with an incorrect type can defeat a safeguard.
      - Disposal of a battery into a fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
      - Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
      - A battery subjected to extremely low air pressure can result in an explosion or the leakage of

flammable liquid or gas.

21. Use only the adapter included with this product. Incorrect adapter polarity or voltage can seriously damage the product.
22. The applied nameplate is located at the bottom or near the product.

## **SAVE THESE INSTRUCTIONS**

### **Battery**

- Use only the batteries provided or equivalent. To order a replacement, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [phones.vtechcanada.com](http://phones.vtechcanada.com) or call 1 (800) 267-7377.
- Do not dispose of the battery in a fire. Check with local waste management codes for special disposal instructions.
- Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- Exercise care in handling batteries in order not to create a short circuit with conductive materials.
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.

### **Precautions for users of implanted cardiac pacemakers**

**Cardiac pacemakers (applies only to digital cordless telephones):** Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, **WTR recommends to physicians that:**

#### **Pacemaker patients**

- Should keep wireless telephones at least six inches from the pacemaker.
- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

### **About cordless telephones**


- **Privacy:** The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.
- **Electrical power:** The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless

handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.

- **Potential TV interference:** Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR often reduces or eliminates the interference.
- **Rechargeable batteries:** Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.
- **Nickel-metal hydride rechargeable batteries:** Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

## What's in the box

Your telephone package contains the following items. Save your sales receipt and original packaging in case it is necessary to ship your telephone for warranty service.



Handset charger and  
charger adapter




User's manual



Handset



Battery  
compartment cover




Battery

## Charger installation

Install the charger as shown below.


Electrical outlet  
not controlled  
by a wall switch




## Battery installation and charging

Install the battery as shown below. Once you have installed the battery, you may be able to make and receive short calls. For best performance, charge the handset battery continuously for at least 10 hours.


1. Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label.



2. Place the battery with the label THIS SIDE UP facing up and the wires inside the battery compartment.




3. Slide the battery compartment cover towards the center of the handset until it clicks into place.



4. Place the handset in the telephone base or charger to charge.

**CHARGE** light  
remains on  
when charging.





## Battery charging

Once you have installed the battery, the screen indicates the battery status (see the table below).

### note

- For best performance, keep the handset in the telephone base or charger when not in use.

- The battery is fully charged after 10 hours of continuous charging.
- If you place the handset in the telephone base or the charger without plugging in the battery, the screen displays No battery.

Battery indicators	Battery status	Action
<p>The screen is blank, or displays the <b>Place in charger</b> and  flashes.</p>	<p>The battery has no or very little charge. The handset can not be used.</p>	<p>Charge without interruption (about 30 minutes).</p>
<p>The screen displays a <b>Low battery</b> and  flashes.</p>	<p>The battery has enough charge to be used for a short time.</p>	<p>Charge without interruption (about 30 minutes).</p>
<p>The screen displays <b>HANDSET X</b>.</p>	<p>The battery is charged.</p>	<p>To keep the battery charged, place it in the telephone base or charger when not in use.</p>

**When the battery is fully charged, you can expect the following performance:**

Operation	Operating time
While in handset use (talking*)	Up to seven hours
While in speakerphone mode (talking*)	Up to five hours
While not in use (standby**)	Up to seven days

- Operating times vary depending on your actual use and the age of the battery.
- The handset is not charging or in use.

After you install your telephone or power returns following a power outage, the handset will prompt you to set the date and time. To skip setting the date and time, press OFF/CANCEL.



## Add and register a handset

You can add new LS6405/LS640V handsets (purchased separately) to your LS6425/LS6426/LS6475/LS6476/LS642V telephone system. Each handset must be registered with the telephone base before use. When first purchased, each handset displays Put HS on BASE to register. You may need to charge the handset before registering it to the telephone base. For more details on battery charging, see the Battery installation and charging section.

## To register a handset

1. Make sure the handset is out of the telephone base or handset charger and shows Put HS on BASE to register

and then place the handset in the telephone base.

2. The handset displays Registering... Please wait and the red IN USE light on the telephone base turns on. It takes about 90 seconds to complete the registration process. The handset displays HANDSET X Registered (X represents the registered handset number). The IN USE light turns off and the handset beeps when registration completes.



If registration fails, the system will automatically try to register again. If registration fails after the third try, the handset displays Registration failed then Put HS on BASE to register. This may take up to five minutes to occur. To reset the handset, remove it from the telephone base. When the handset displays Put HS on BASE to register, try the registration process again.



## NOTE

After registration, the date and time need to be reset.

## Deregister handsets

If you want to replace a handset or reassign the designated handset number of a registered handset, you must deregister all handsets that are registered to the telephone base. Then register each handset individually. To make deregistration easier, read all of the instructions on this page before you begin. Make sure that all handsets are out of the telephone base and chargers before you begin deregistration.


### To deregister all handsets:

1. Press and hold /FIND HANDSET on the telephone base for about 10 seconds until the IN USE light on the telephone base turns on and starts flashing.
2. Press and release /FIND HANDSET again. You must press /FIND HANDSET while the IN USE light is still flashing. The IN USE light flashes for approximately seven seconds.
3. The deregistration process takes about 10 seconds to complete. All handsets show Put HS on BASE to

register.

If deregistration fails, you may need to reset the telephone base and try again.

## To reset

- Pick up the registered handset and then press /FLASH.
- -OR-
- Unplug the power from the telephone base, then plug it back in.

## NOTE

- You cannot deregister all handsets if any other system handset is in use.

## Handset overview

### CHARGE light

On when the handset is charging.

### /▲/VOLUME

Review the directory when the telephone is not in use.

Scroll up while in a menu.

Increase the listening volume during a call or message playback.

Move the cursor to the right when entering numbers or names in the directory.

### MUTE/DELETE

Mute the microphone during a call.

Delete the displayed entry while in the directory, caller ID log or redial list.

Silence the ringer temporarily while the handset is ringing.

Delete digits or characters while using the dialing keys.

### /FLASH

Make or answer a call.

### CID/▼/VOLUME

Review the caller ID log when the telephone is not in use.

Scroll down while in a menu.

Decrease the listening volume during a call or message playback.

Move the cursor to the left when entering numbers or names.

### MENU/SELECT

Show the menu.

Choose an item, or save an entry or setting while in a menu.

### PUSH TO TALK (PTT)

Begin a one-to-one or one-to-group broadcast.


### OFF/CANCEL

Hang up a call.

Silence the ringer temporarily while the handset is ringing.

Press and hold to delete the missed call indicator while the telephone is not in use.

Press to return to the previous menu, or press and hold to return to



Answer a call waiting call during a call.

**1**

Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the directory.

**TONE \***

Switch to tone dialing temporarily while on a call.

**🔊/SPEAKER**


Make or answer a call using the handset speakerphone.

Switch between the speakerphone and the handset during a call.

**REDIAL/ PAUSE**

Press to review the redial list.

Press and hold to insert a dialing pause while entering numbers in the directory.



Press and hold to enter the handset in idle mode without making changes.

**Dialing keys**

Enter numbers or characters.

**# (pound key)**

Press repeatedly to show other dialing options when reviewing a caller ID log entry.

Switch the name order when saving the caller ID log entries to the directory.

**↑↓EQ**

Change the audio quality to best suit your hearing during an outside call, intercom call, message or announcement playback.



**PUSH TO TALK (PTT)**

Press to begin a broadcast to one or multiple handsets.

Press and hold to broadcast to a group of handsets when the handset is not in use.

**IMPORTANT!**

If you have difficulty with your telephone, please refer to the user's manual for a full set of installation and operation instructions. For customer service, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [phones.vtechcanada.com](http://phones.vtechcanada.com) or call 1 (800) 267-7377.

## Need help?

For operations and guides to help you using your telephone, and for the latest information and supports, go and check the online help topics and online FAQs. Use your smartphone or mobile device to access our online help.

- Go to <https://help.vtechphones.com/LS6405>; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help.-
  - If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.



**LS6405 (US)**

**You can also call our Customer Support at**

1 (800) 595-9511 **[in the US]** or

1 (800) 267-7377 **[in Canada]** for help.



**LS6405 (CA)**

The RBRC seal on the Ni-MH battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives when taken out of service within the United States and Canada. The program provides a convenient alternative to placing used Ni-MH batteries into the trash or municipal waste, which may be illegal in your area.



VTech's participation makes it easy for you to drop off the spent battery at local retailers participating in the program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

**The RBRC Seal and 1 (800) 8 BATTERY® are registered trademarks of Call2recycle, Inc.**

## **FCC, ACTA, and IC regulations**

### **FCC Part 15**

**NOTE:** This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. **If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. **Operation is subject to the following two conditions:**

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this telephone.

To ensure the safety of users, the FCC/ISED has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product

has been tested and found to comply with the FCC/ISED criteria. The handset may be safely held against the ear of the user. For body-worn operation, this handset has been tested and meets the FCC/ISED RF exposure guidelines when used with the accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC/ISED RF exposure guidelines. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.

**This Class B digital apparatus complies with Canadian requirements:**

CAN ICES-3 (B)/NMB-3(B).

**FCC Part 68 and ACTA**

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, **among other things, a product identifier in the format US: AAAEQ##TXXXX**. This identifier must be provided to your telephone service provider upon request. The plug and jack used to connect this equipment to the premise's wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug are provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line. See the installation instructions in the user's manual.

The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider. This equipment must not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone service provider or a qualified installer. If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Replacement to this telephone equipment can only be made by the manufacturer or its authorized agents. For replacement procedures, follow the instructions outlined under the **Limited warranty**. If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned. If this product is equipped with a corded or cordless handset, it is hearing aid compatible. If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations.

**If you do store or test emergency numbers, please:**

- Remain on the line and briefly explain the reason for the call before hanging up.
- Perform such activities in off-peak hours, such as early morning or late evening.

**Industry Canada**

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s).

**Operation is subject to the following two conditions:**




1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device. Privacy of communications may not be ensured when using this telephone. The term "IC:" before the

certification/registration number only signifies that the Industry Canada technical specifications were met. The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five. This product meets the applicable Innovation, Science, and Economic Development Canada technical specifications.

## **California Energy Commission battery charging testing instructions**

This telephone is set up to comply with the energy-conserving standards right out of the box. These instructions are intended for California Energy Commission (CEC) compliance testing only. When the CEC battery charging testing mode is activated, all telephone functions, except battery charging, will be disabled.

### **To activate the CEC battery charging testing mode:**

1. Unplug the telephone base power adapter from the power outlet. Make sure all handsets are plugged in with charged batteries before proceeding.
2. While you press and hold  /FIND HANDSET, plug the telephone base power adapter back into the power outlet.
3. After about 20 seconds, when the IN USE light starts flashing, release  /FIND HANDSET and then press it again within two seconds. The process takes up to one minute to complete. When the phone successfully enters the CEC battery charging testing mode, the IN USE light turns off and all handsets display Put HS on BASE to register. If the phone fails to enter this mode, repeat all the steps mentioned above. The telephone base will be powered up as normal if you fail to press  /FIND HANDSET within two seconds in Step 3.

### **To deactivate the CEC battery charging testing mode:**

1. Unplug the telephone base power adapter from the power outlet, and then plug it back in. Then the telephone base is powered up as normal.
2. Place the handset in the telephone base to register it back. The handset displays Registering... Please wait and the red IN USE light on the telephone base turns on. If the registration is successful, the handset screen displays HANDSET X registered and beeps. The handset is registered with the telephone base.

## **Limited Warranty**

### **What does this limited warranty cover?**

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

## **What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period (“Materially Defective Product”)?**

During the limited warranty period, VTech’s authorized service representative will replace at VTech’s option, without charge, a Materially Defective Product. If we replace the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Replacement of the Product, at VTech’s option, is your exclusive remedy. VTech will return the replacement Products to you in working condition. You should expect the replacement to take approximately 30 days.

## **How long is the limited warranty period?**

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the replacement Product for a period of either (a) 90 days from the date the replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer.

## **What is not covered by this limited warranty?**

### **This limited warranty does not cover:**

1. The product has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water, or another liquid intrusion.
2. The product that has been subjected to contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like; but then only to the extent the damage was not caused by incorrectly securing the waterproof handset’s protective elements, for example, failing to properly close a seal), or such protective elements are damaged or missing (e.g. a cracked battery door), or subjecting a Product to conditions beyond its stated specifications or limits (e.g. 30 minutes in 1 meter of freshwater).
3. The product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech;
4. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems;
5. Product to the extent that the problem is caused by use with non-VTech accessories;
6. Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible;
7. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes);
8. Product returned without a valid proof of purchase (see item 2 below); or
9. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

## **How do you get warranty service?**

To obtain warranty service in the United States of America, please visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [phones.vtechcanada.com](http://phones.vtechcanada.com) or dial 1 (800) 267-7377.

**NOTE:** Before calling for service, please review the user’s manual – a check of the Product’s controls and features may save you a service call. Except as provided by applicable law, you assume the risk of loss or

damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of replacement prior to any further replacement activity. You must pay for the cost of replacement and return shipping costs for the replacement of Products that are not covered by this limited warranty.

### **What must you return with the Product to get warranty service?**

1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
3. Provide your name, complete and correct mailing address, and telephone number.

### **Other limitations**



This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

**State/Provincial Law Rights:** This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**Please retain your original sales receipt as proof of purchase**

### **Technical specifications**

Frequency control	Crystal-controlled PLL synthesizer
Transmit frequency	<b>Handset:</b> 1921.536MHz – 1928.448MHz <b>Telephone base:</b> 1921.536MHz – 1928.448MHz
Channels	5
Nominal effective range	Maximum power allowed by FCC and IC. The actual operating range may vary according to environmental conditions at the time of use.
  Power requirement	<b>Handset:</b> 2.4V Ni-MH battery <b>Charger:</b> DC 6V @ 0.4A
Memory	<b>Directory:</b> 50 memory locations; up to 30 digits and 15 characters <b>Caller ID log:</b> 50 memory locations; up to 24 digits and 15 characters

Telephones identified with this logo have reduced noise and interference when used with most T-coil-equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.



### Disclaimer and Limitation of Liability

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.

**Company:** VTech Communications, Inc.

**Address:** 9020 SW Washington Square Road – Ste 555 Tigard, OR 97223, United States

**Phone:** 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

Specifications are subject to change without notice.

© 2022 VTech Communications, Inc.

© 2022 VTech Technologies Canada Ltd

All rights reserved.09/22. LS6405\_CIB\_US-CAN\_V7

Go to [www.vtechphones.com](http://www.vtechphones.com) (US) to register your product for enhanced warranty support and the latest VTech product news.

Go to [phones.vtechcanada.com](http://phones.vtechcanada.com) (CA) for latest VTech product news.

### Scan the QR code for support information



LS6405 (US)



LS6405 (CA)

### Documents / Resources



[VTech LS6405 Cordless Handset](#) [pdf] User Guide  
LS6405 Cordless Handset, LS6405, Cordless Handset, Handset