



Vtech My Sleepy Sloth Soft toy Instruction Manual

[Home](#) » [vtech](#) » Vtech My Sleepy Sloth Soft toy Instruction Manual 

Vtech My Sleepy Sloth Soft toy Instruction Manual




Contents

- 1 INTRODUCTION
- 2 INCLUDED IN THE PACKAGE
- 3 INSTRUCTIONS
- 4 IMPORTANT: BATTERY INFORMATION
- 5 RECHARGEABLE BATTERIES:
- 6 Disposal of batteries and product
- 7 PRODUCT FEATURES
- 8 ACTIVITIES
- 9 MELODY LIST
- 10 SONG LYRICS
- 11 CARE & MAINTENANCE
- 12 TROUBLESHOOTING
- 13 CONSUMER SERVICES
- 14 PRODUCT WARRANTY/ CONSUMER GUARANTEES
- 15 Documents / Resources
 - 15.1 References
- 16 Related Posts

INTRODUCTION

Thank you for purchasing the **VTech® My Sleepy Sloth**.

This sleepy sloth will soothe baby to sleep with its soft glowing night light, melodies, sing-along songs, sounds, bedtime stories and loving phrases.



INCLUDED IN THE PACKAGE

- **My Sleepy Sloth**
- Quick Start Guide

WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

INSTRUCTIONS

Battery Removal and Installation



1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 3 new AA batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.

- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicate they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.


In Australia & New Zealand:

Check with your local council for kerbside collections.

PRODUCT FEATURES


1. Off / 30 Mins / 45 Mins Switch

To turn the unit ON, slide the **Off / 30 Mins / 45 Mins Switch** located on the electronic module inside the slot to the 30 Mins (**30**) or 45 Mins (**45**) position. To turn the unit OFF, slide the **Off / 30 Mins / 45 Mins Switch** to the Off (**●**) position.



2. Songs / Sounds / Story Mode Switch

Slide the **Songs / Sounds / Story Mode Switch** to select Song Mode, Sounds Mode or Story Mode. You will hear sing-along songs and gentle melodies in Song Mode, soothing sounds in Sounds Mode, and bedtime stories with background music in Story Mode.



3. Automatic Shut Off

To preserve battery life, the **VTech® My Sleepy Sloth** will automatically power-down after the selected time. The unit can be turned on again by pressing any button.

NOTE:

If the unit repeatedly powers down or the light flickers then fades out, please change the batteries

ACTIVITIES

1. Light Up Heart Button

Press the Light Up Heart Button to select one of three light & motor modes.

2. Leaf Button (Play Next Button)

Press the Leaf Button to hear soothing sounds. Some sounds are accompanied by a gentle melody. The light will fade in and out slowly with the sounds.

3. Volume Control Buttons

Press the Volume Control Buttons (+) (-) to turn the volume up or down

4. Sound Sensor

When the sloth is in sleep mode, soft melodies will play if baby's cry is detected.

MELODY LIST

1. All Through the Night
2. Brahms – Lullaby
3. Pachelbel – Canon in D
4. Schumann – Kinderszenen
5. Are You Sleeping?
6. Bach – Cello Suite No. 1 in G Major
7. Bear Went Over the Mountain
8. Hush, Little Baby
9. Rock-a-Bye Baby
10. Good Morning Merry Sunshine
11. Polly Put the Kettle On
12. Beethoven – Ode to Joy
13. Blue Danube Waltz
14. Chopin – Nocturne op.9 No.2
15. Humpty Dumpty
16. Riddle Song
17. Vivaldi – Spring
18. Winkum, Winkum
19. Row, Row, Row Your Boat
20. Lavender's Blue
21. Mozart – Eine Kleine Nachtmusik
22. Mozart – Piano Sonata in C, K545 1st Movement
23. Shannon – Irish Lullaby
24. Bicycle Built for Two
25. On Top of Old Smokey

SONG LYRICS

Song 1

I'm your sleepy sloth friend, and I like to cuddle, Would you like to cuddle, and snooze with me?

Song 2

Good night my little friend,
Are you feeling sleepy?
Well let me tell you a story,
And help you have sweet dreams.

Song 3

It is time to say goodnight,
It is time to say goodnight,
It is time to say goodnight,
Let's all fall asleep.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech

Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...


vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect ...learning to touch, reach, grasp, sit-up, crawl and toddle tk-



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting ...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain 1 develops



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind ...intelligent technology that adapts to my level of learning ...National Curriculum based content to support what I'm learning at school



Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk
www.vtech.com.au




TM & © 2022 VTech Holdings Limited.

All rights reserved.

IM-548200-000

Version:0

Documents / Resources



[Vtech My Sleepy Sloth Soft toy](#) [pdf] Instruction Manual
Sleepy Sloth, Sloth, Soft toy, toy

References

- [Support : VTech Electronics](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)