



## vtech Smash the T-Rex User Guide

[Home](#) » [vtech](#) » vtech Smash the T-Rex User Guide

### vtech Smash the T-Rex User Guide



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

Toys that will stimulate their interest in different textures, sounds and colours

**I am...**

\_responding to colours, sounds and textures -understanding cause and effect \_learning to touch, reach, grasp, sit-up, crawl and toddle

Interactive toys to develop their imagination and encourage language development

## I want...

to get ready for school by starting to learn the alphabet and counting ...my learning to be as fun, easy and exciting as can be \_to show my creativity with drawing and music so my whole brain develops

Cool, aspirational and inspiring computers for curriculum related learning

## I need...

challenging activities that can keep pace with my growing mind ...intelligent technology that adapts to my level of learning ...National Curriculum based content to support what I'm learning at school

### Contents [ [hide](#)

- 1 INTRODUCTION**
- 2 INCLUDED IN THIS PACKAGE**
- 3 GETTING STARTED**
- 4 IMPORTANT: BATTERY INFORMATION**
  - 4.1 RECHARGEABLE BATTERIES:**
- 5 Disposal of batteries and product**
- 6 PRODUCT FEATURES**
  - 6.1 Off / Low / High Volume Switch**
  - 6.2 Game Button**
  - 6.3 Crash Trigger**
  - 6.4 Automatic Shut-Off**
- 7 HOW TO SWITCH**
- 8 CARE & MAINTENANCE**
- 9 TROUBLESHOOTING**
- 10 CONSUMER SERVICES**
- 11 PRODUCT WARRANTY/ CONSUMER GUARANTEES**
- 12 Documents / Resources**
  - 12.1 References**
- 13 Related Posts**

## INTRODUCTION

Switch into fun with the Switch & Go Dinose Smash the T-Rex. Switch this ferocious T-Rex into an agile Drift Car and back in just a few simple steps. Ready to smash and crash? Here we go!



## INCLUDED IN THIS PACKAGE

- Switch & Go Dinose Smash the T-Rex
- Parent's Guide

### **WARNING:**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

### **NOTE:**


Please keep this Parent's Guide as it contains important information.

### **WARNING:**

This toy produces flashes that may trigger epilepsy in sensitised individuals.

## GETTING STARTED

### **Battery Removal and Installation**



1. Make sure the unit is turned Off.
2. Find the battery cover on the back of the unit, use a screwdriver to loosen the screw and then open the battery box.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.

**Note:** If there is no response when the dino is switched on, please install brand new batteries and try switching the dino on again.

**WARNING:**

Adult assembly required for battery installation.  
Keep batteries out of reach of children.

**IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

**RECHARGEABLE BATTERIES:**

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

## VTecho cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

### In the UK:




Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.


### In Australia & New Zealand:

Check with your local council for kerbside collections.

## PRODUCT FEATURES

### Off / Low / High Volume Switch

To turn the unit On or adjust the volume, slide the switch to the Low  or High  10 Volume position. To turn the unit Off, slide the switch to the Off  position.



Game Button

Press the Game Button to hear fun phrases and cool dinosaur sounds in Dino mode, or to hear fun phrases and great vehicle sounds in Vehicle mode.



### Crash Trigger

Hit the Crash Trigger to see crash damage with a fiery light effect and hear dino or vehicle sounds.




### Automatic Shut-Off


To preserve battery life, Smash the T-Rex will automatically turn off after approximately 40 seconds without input. Smash the T-Rex can be woken up again by pressing the Game Button, hitting the Crash Trigger, or by switching between Dino and Vehicle mode. Smash the T-Rex will also automatically turn off when battery power is very low.

## HOW TO SWITCH


1. Dino mode.




2. Rotate the dino's hands towards the dino's head. Then, rotate the feet back towards the dino's tail.




3. Pull the legs up and toward the dino's body as illustrated.



4. Flip the rear tyres back as illustrated.




5. Move the windscreen forward as illustrated.



6. Vehicle mode.





**Note:** To switch from Vehicle mode to Dino mode, follow the above steps in reverse order.

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

## CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

**Australian Customers:**

Phone: 1800 862 155

Website: [support.vtech.com.au](http://support.vtech.com.au)

**NZ Customers:**

Phone: 0800 400 785

Website: [support.vtech.com.au](http://support.vtech.com.au)

**PRODUCT WARRANTY/ CONSUMER GUARANTEES****UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

**Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED —CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

Visit our website for more information about our products, downloads, resources and more.

[www.vtech.co.uk](http://www.vtech.co.uk)

[www.vtech.com.au](http://www.vtech.com.au)

**Documents / Resources**

[vtech Smash the T-Rex](#) [pdf] User Guide  
Switch Go Dinos, Smash the T-Rex

**References**

- [Support : VTech Electronics](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)

- [!\[\]\(7e19807c61da14f515588e95cd49886c\_img.jpg\) Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [!\[\]\(8ff9e60a4b0560d7ec99179ef4779d9e\_img.jpg\) Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [!\[\]\(ab9b69bf5753a01c76b30af859454360\_img.jpg\) VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)