



vtech Sparklings Ava User Guide

[Home](#) » [vtech](#) » vtech Sparklings Ava User Guide 



Parent's Guide

Sparklings⁺ Ava⁺



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at Just the right level...

vtech Baby	Pre-School	Electronic Learning Computers
Toys that will stimulate their interest in different textures, sounds and colours	Interactive toys to develop their imagination and encourage language development	Cool, aspirational and inspiring computers for curriculum-related learning
I am... responding to colours, sounds and textures understanding cause and effect learning to touch, reach, grasp, sit-up, crawl and toddle	I want to get ready for school by starting to learn the alphabet and counting — my learning to be as fun, easy and exciting as can be — to show my creativity with drawing and music, so my whole brain develops	I need challenging activities that can keep pace with my growing mind — intelligent technology that adapts to my level of learning — National Curriculum based content to support what I'm learning at school
		
<p>To learn more about this and other VTech® products, visit www.vtech.co.uk</p>		


Contents

- 1 INTRODUCTION
- 2 INCLUDED IN THIS PACKAGE
- 3 GETTING STARTED
- 4 IMPORTANT: BATTERY INFORMATION
- 5 RECHARGEABLE BATTERIES:
- 6 PRODUCT FEATURES
- 7 ACTIVITIES
- 8 CARE & MAINTENANCE
- 9 TROUBLESHOOTING
- 10 CONSUMER SERVICES
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts

INTRODUCTION

Thank you for purchasing **Sparklings Ava!**

Hi, I'm Ava, welcome to my colourful world of magic! Press my charm to choose a colour, then touch my ears, eyes or tuft of hair to decorate them with that colour. Let's have fun together!



INCLUDED IN THIS PACKAGE

- Sparklings Ava
- Two Hair Clips
- One Comb
- Parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please keep this parent's guide as it contains important information.

GETTING STARTED

The batteries included are for demo purposes only. Please replace the low capacity Try Me batteries with new batteries for the best performance. Slide the **Demo/Off/On** Switch to the **ON** position to start.

NOTE:

Playing at close range for a prolonged period of time may cause fatigue or discomfort. We recommend that children take a 15-minute break for every hour of play.

Battery Removal and Installation



1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit, use a screwdriver to loosen the screw and open the battery box.
3. Remove old batteries by pulling up one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended)
5. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly is required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in a fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, were marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for curbside collections.

PRODUCT FEATURES

1. Demo/Off/On Switch

To turn the unit **ON**, slide the **Demo/Off/On** Switch to the **ON** position. To turn the unit **OFF**, slide the **Demo/Off/On** Switch to the **OFF** position.

2. Automatic Shut Off


To preserve battery life, Ava will automatically power down after several seconds without input. The unit can be turned on again by pressing her hair button, mouth button or charm button.

NOTE: If the unit powers down while playing, please install a new set of batteries.

ACTIVITIES

1. Colour Ava

Ava lights up in the colours you choose for her. Press Ava's **Charm Button** to choose a colour. Then, touch her eyes, hair and ears to add the selected colour to them.



2. Ava's Mood

Ava expresses her mood through colour. Press her **Light-Up Hair Button** to see how she feels. Then, touch her eyes or ears for some additional colour commentary.



3. Colour Fun

Ava likes to pick a lucky colour for you. Press her **Ear Sensor** and she'll select a lucky colour and tell you how that colour makes her feel.



4. Imagine with Ava

Ava wants you to share your imagination with her. Cover and hold one of Ava's **Eye Sensors** and she'll ask you to tell her something you've imagined. Keep her **Eye Sensor** covered as you tell her. Uncover her **Eye Sensor** and she'll tell you how much she loves your imagination.



5. Musical Ava

Ava loves to sing. Tap Ava's **Mouth Button**, and she will sing, hum or even surprise you with a kiss! Careful, sometimes she even blows raspberries!



6. Running Fun

Ava loves to run through the skies!

Help her wiggle her tail by pressing her **Leg Lever**. She'll make magical sounds and cheer as she pretends to run through a rainbow.



7. Cuddle and Care

Every fox needs love. Touch Ava's Eye Sensor or Ear Sensor to take care of her and get a fun surprise.



CARE & MAINTENANCE

1. Keep Ava clean by wiping it with a slightly damp cloth.
2. Keep Ava out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when Ava is not in use for an extended period of time.
4. Do not drop Ava on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason Ava stops working or malfunctions, please follow these steps:

1. Turn Ava **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let Ava stand for a few minutes, then replace the batteries.
4. Turn Ava **On**. She will now be ready to play with again.
5. If Ava still does not work, install a new set of new batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products are accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur.

It is important for you to know that we stand behind our products and encourage you to call our Consumer

Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

Product Warranty/ Consumer Guarantees

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech

Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk

www.vtech.com.au



TM & © 2020 VTech Holdings Limited.

All rights reserved.

Printed in China.

91-003819-011 UK

Documents / Resources



[vtech Sparklings Ava](#) [pdf] User Guide
Sparklings Ava

References

- [Support : VTech Electronics](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New](#)

Zealand

- [!\[\]\(467d80e979964f7f8c752fb22248b5b7_img.jpg\) Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [!\[\]\(b71552d33dbf62adf5e5199a70ee02bf_img.jpg\) Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [!\[\]\(03134b765d1473836ff001925b1b0550_img.jpg\) VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)

Manuals+.