



vtech Velociraptor Switch and Go Jet Instruction Manual


[Home](#) » [vtech](#) » vtech Velociraptor Switch and Go Jet Instruction Manual 



Instruction Manual



Velociraptor




Contents

- 1 Velociraptor Switch and Go Jet
- 2 INTRODUCTION
- 3 INCLUDED IN THE PACKAGE
- 4 GETTING STARTED
- 5 ASSEMBLY INSTRUCTIONS
- 6 HOW TO SWITCH
- 7 EGG SHELL DINO STORAGE
- 8 PRODUCT FEATURES
- 9 CARE & MAINTENANCE
- 10 TROUBLESHOOTING
- 11 CONSUMER SERVICES
- 12 PRODUCT WARRANTY/CONSUMER GUARANTEES
- 13 Documents / Resources
 - 13.1 References

Velociraptor Switch and Go Jet


VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



To learn more about this and other VTech ® products, visit www.vtech.co.uk

INTRODUCTION

Assemble this wild Velociraptor and switch it into a fast car and back again in just a few simple steps! Enjoy cool dino and vehicle sound effects, as well as light effects as you play! Let's stomp, chomp and roar!



INCLUDED IN THE PACKAGE

- Switch & Go Dinos® Eggs Velociraptor
- 15 Pieces for Assembly
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

GETTING STARTED


Exit Try-Me Mode:

The product is in Try Me mode in the packaging. To exit try-me mode, just slide the "Off/Dino Mode/Vehicle Mode" Switch from Vehicle mode to Dino mode/Off.

Battery Removal and Installation

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).

5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.
Help protect the environment by disposing of your product or batteries responsibly.

VTech ® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:


Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:




Check with your local council for kerbside collections.




ASSEMBLY INSTRUCTIONS



1. Identify the following pieces for assembly:




2. Separately install the A, B, C, D, E, F, G and H parts as shown in the illustrations.









HOW TO SWITCH




1. Dino mode.



2. Close the Dino's mouth, then flip up the front claws. Ne



3. Rotate the feet towards the Dino's head.




4. The Dino is now in Vehicle mode. Slide the Off/Dino m
o
Vehicle mode to play Vehicle responses.


Note: To switch from Vehicle mode to Dino mode, follow the above steps in reverse order.

EGG SHELL DINO STORAGE

Velociraptor can be dismantled and stored back inside the egg shell.
Follow the below steps to store Velociraptor:



Place the battery module and the 2 larger dino pieces into the egg shell as illustrated.




Put the remaining dino pieces into the other half of the egg shell.
Then, connect the first half of the egg shell to seal.

PRODUCT FEATURES

1. OFF / DINO MODE / VEHICLE MODE SWITCH

Slide the Off / Dino Mode / Vehicle Mode Switch to Dino Mode or Vehicle Mode to play. Slide the switch to the Off position to turn the unit Off.



2. Talk Button

Press the Talk Button to hear fun phrases and cool dinosaur sounds in Dino mode, or hear fun phrases and great vehicle sounds in Vehicle mode.



3. Automatic Shut-Off

To preserve battery life, the Velociraptor will automatically shut off after a few seconds without input. The unit can be turned on again by pressing the Talk Button or by switching between Dino and Vehicle modes.

Note: If the unit powers down or if the light flashes 3 times without sounds during play, please install a new set of batteries.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services

Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech

Electronics (Australia) Pty Limited. Please refer to vtech.com.au/ consumer guarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk

www.vtech.com.au



TM & © 2022 VTech Holdings Limited.

All rights reserved.

IM-559200-001

Version:0

Documents / Resources



[vtech Velociraptor Switch and Go Jet](#) [pdf] Instruction Manual
Velociraptor Switch and Go Jet, Velociraptor, Switch and Go Jet, Go Jet

References

- [Support : VTech Electronics](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
- [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)