



80-178000
STARSHINE
THE
BRIGHT
LIGHTS
UNICORN



VTech 80-178000 Starshine the Bright Lights Unicorn User's Guide

[Home](#) » [vtech](#) » VTech 80-178000 Starshine the Bright Lights Unicorn User's Guide 

Contents

- [1 VTech 80-178000 Starshine the Bright Lights Unicorn](#)
- [2 INTRODUCTION](#)
- [3 GETTING STARTED](#)
- [4 PRODUCT FEATURES](#)
- [5 ACTIVITIES](#)
- [6 SONG LYRICS](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PRODUCT WARRANTY](#)
- [10 FREQUENTLY ASKED QUESTIONS](#)
- [11 VIDEO – PRODUCT OVERVIEW](#)
- [12 References](#)




VTech 80-178000 Starshine the Bright Lights Unicorn



INTRODUCTION

Thank you for purchasing Starshine the Bright Lights Unicorn™. This enchanting unicorn features three modes of play, colorful charms and a light-up horn. Place the charms on the magic heart recognition points to decorate the unicorn and hear colors and fun phrases in English and Spanish, plus whimsical sounds. Squeeze her tail to flap her wings as she rolls along!




INCLUDED IN THIS PACKAGE

- One Starshine the Bright Lights Unicorn™
- One charm storage dish
- Seven charms
- One parent's guide

WARNING: All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.

Unlock the packaging locks:



1. Rotate the packaging locks counterclockwise 90 degrees.
2. Pull out the packaging locks.

Release the Charm:

1. Make sure the unit is OFF.
2. Carefully pull the Charm away from Starshine and cut the strings as illustrated.




3. Remove the strings from Starshine and throw them away.



GETTING STARTED

BATTERY INSTALLATION



1. Make sure the unit is turned OFF.

2. Locate the battery cover on the side of the unit.
3. Use a screwdriver to loosen the screw and open the battery cover.
4. Install 2 new AA (AM-3/LR6) batteries into the battery box as illustrated. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. Off/Mode Selector

- To turn the unit ON, slide the selector from OFF to Charms & Colors, Charms & Colors in Spanish or Music Time.
- To turn the unit OFF , slide the selector to the OFF position.

2. Volume Switch

The Volume Switch is located on the side of the unicorn. To adjust the volume, slide the Volume Switch to the Low Volume or High Volume position.

3. Seven Charms

Place the Seven Charms on the Magic Heart Recognition Points to hear fun responses about the charms.

4. Magic Heart Recognition Points

Place a Charm on any of the three Magic Heart Recognition Points on Starshine to trigger fun responses and lights. She has Magic Heart Recognition Points on her crown, bracelet and side.

5. Magical Light-Up Horn

The Magical Light-Up Horn will light-up in multiple colors with the voice responses, songs and melodies.



6. **Magical Tail**

Squeeze her Magical Tail to flap her beautiful wings and hear fun responses and songs.

7. **Blue Heart Button**

Press the Blue Heart Button to hear questions, fun phrases about the unicorn and to play melodies.

8. **Necklace Button**

Press the Necklace Button to hear fun sounds and see the unicorn's horn light up.

9. **Rolling Wheels**


Starshine's hooves feature wheels so you can push her along.

10. **Charm Storage Dish**

Store the Seven Charms in the heart-shaped Charm Storage Dish.

11. **Automatic Shut Off**

To preserve battery life, Starshine the Bright Lights Unicorn™ will automatically power down after several minutes of no input. The unicorn can be turned on again by sliding the Off/Mode Selector to Charms & Colors, Charms & Colors in Spanish or Music Time.



NOTE: If the unicorn powers down while playing, we suggest replacing with a new set of batteries.

ACTIVITIES

Charms & Colors

- Place a Charm on any of the three Magic Heart Recognition Points to hear about colors, beginning letters and fun phrases.
- Press the Blue Heart Button to hear questions about the charms, then place the charms on one of the Magic Heart Recognition Points to answer the questions.

Charms & Colors in Spanish

- Place a Charm on any of the three Magic Heart Recognition Points to hear colors and phrases in Spanish.
- Press the Blue Heart Button or squeeze the Magical Tail to hear fun responses about the unicorn in Spanish.

Music Time

- Place a Charm on any of the three Magic Heart Recognition Points to hear fun sounds.
- Press the Blue Heart Button to play melodies, or squeeze the Magical Tail to play songs, then press the Necklace Button or place any of the Seven Charms on a Magic Heart Recognition Point to add sounds into the melodies and songs.

SONG LYRICS

Song 1:

- I'm Starshine the unicorn,
- Won't you come and shine with me! Let's Go!

Song 2:

- Let's play with all these colorful charms.
- There's purple, orange and blue, yellow, green and red too. So won't you
- Put in the perfect charm for me?
- Is it a star or lovely cherries?
- They're so much fun for you and me!

Song 3:

- ¡Ponme mis adornos de color
- (y) brillaré como el sol!
- Diamante verde, morado corazón
- Arco iris multicolor.
- Adórname con tu imaginación
- ¡para divertirnos tú y yo!

Song 4:

- Flying from here to there,
- Got wings on my back and colors in my hair! Oh Yeah! And magic under my feet!
- It's really sweet!
- I'm Starshine the unicorn,
- Won't you come and shine with me!
- Let's Go!

Song 5:

- Fly with me, my best friend,
- To a magical world of colorful fun.

MELODY LIST

1. Twinkle, Twinkle Little Star
2. Sing a Song of Sixpence
3. Little Miss Muffet

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit ON. The unit should now be ready to play again.
5. If the product still does not work, replace it with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-[800-521-2010](tel:800-521-2010) in the U.S. or 1-[877-352-8697](tel:877-352-8697) in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call our Consumer Services Department at 1-[800-521-2010](tel:800-521-2010) in the U.S. or 1-[877-352-8697](tel:877-352-8697) in Canada.

IMPORTANT NOTE: Creating and developing Infant Learning products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-[800-521-2010](tel:800-521-2010) in the U.S., or 1-[877-352-8697](tel:877-352-8697) in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PRODUCT WARRANTY

- This Warranty is applicable only to the original purchaser, is non-transferable and applies only to "VTech" products or parts. This product is covered by a 3-month Warranty from the original purchase date, under normal use and service, against defective workmanship and materials. This Warranty does not apply to (a) consumable parts, such as batteries; (b) cosmetic damage, including but not limited to scratches and dents; (c) damage caused by use with non-VTech products; (d) damage caused by accident, misuse, unreasonable use, immersion in water, neglect, abuse, battery leakage, or improper installation, improper service, or other external causes; (e) damage caused by operating the product outside the permitted or intended uses described by VTech in the owner's manual; (f) a product or part that has been modified (g) defects caused by normal wear and tear or otherwise due to the normal aging of the product; or (h) if any VTech serial number has been removed or defaced.
- Prior to returning a product for any reason, please notify the VTech Consumer Services Department, by sending an email to vtechkids@vtechkids.com or calling 1-800-521-2010. If the service representative is unable to resolve the issue, you will be provided instructions on how to return the product and have it replaced under Warranty. Return of the product under Warranty must adhere to the following rules:
- If VTech believes that there may be a defect in the materials or workmanship of the product and can confirm the purchase data and location of the product, we will at our discretion replace the product with a new unit or product of comparable value. A replacement product or parts assumes the remaining Warranty of the original product or 30 days from the date of replacement, whichever provides longer coverage.
- THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. IF VTECH CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY AND TO THE REPLACEMENT SERVICE AS DETERMINED BY VTECH IN ITS SOLE DISCRETION.
- To the extent permitted by law, VTech will not be responsible for direct, special, incidental or consequential damages resulting from any breach of Warranty.
- This Warranty is not intended to persons or entities outside the United States of America. Any disputes resulting from this Warranty shall be subject to the final and conclusive determination of VTech .

To register your product online at www.vtechkids.com/warranty

FREQUENTLY ASKED QUESTIONS

What is the VTech 80-178000 Starshine the Bright Lights Unicorn?

The VTech 80-178000 Starshine the Bright Lights Unicorn is a toy designed for young children that features interactive lights, sounds, and music. It's intended to engage and entertain while promoting sensory

development.

What are the dimensions of the VTech 80-178000 Starshine the Bright Lights Unicorn?

The VTech 80-178000 Starshine the Bright Lights Unicorn measures 4.6 inches in length, 10.59 inches in width, and 11.81 inches in height.

How much does the VTech 80-178000 Starshine the Bright Lights Unicorn weigh?

The VTech 80-178000 Starshine the Bright Lights Unicorn weighs 2.49 pounds.

What is the recommended age range for the VTech 80-178000 Starshine the Bright Lights Unicorn?

The VTech 80-178000 Starshine the Bright Lights Unicorn is recommended for children aged 18 months to 4 years.

What type of batteries does the VTech 80-178000 Starshine the Bright Lights Unicorn use?

The VTech 80-178000 Starshine the Bright Lights Unicorn requires 2 AA batteries.

What is the price of the VTech 80-178000 Starshine the Bright Lights Unicorn?

The VTech 80-178000 Starshine the Bright Lights Unicorn is priced at \$27.99.

What is the warranty period for the VTech 80-178000 Starshine the Bright Lights Unicorn?

The VTech 80-178000 Starshine the Bright Lights Unicorn comes with a 3-month warranty.

Who is the manufacturer of the VTech 80-178000 Starshine the Bright Lights Unicorn?

The manufacturer of the VTech 80-178000 Starshine the Bright Lights Unicorn is VTech.

What interactive features does the VTech 80-178000 Starshine the Bright Lights Unicorn have?

The VTech 80-178000 Starshine the Bright Lights Unicorn features interactive lights, sounds, and music, designed to engage young children and stimulate their senses.

How does the VTech 80-178000 Starshine the Bright Lights Unicorn promote learning?

The VTech 80-178000 Starshine the Bright Lights Unicorn promotes learning by introducing children to cause and effect, encouraging sensory exploration, and providing auditory and visual stimulation.

Why is my VTech 80-178000 Starshine the Bright Lights Unicorn not turning on?

Ensure that the batteries are correctly inserted and have sufficient charge. Replace the batteries with new ones if needed. Also, make sure the power switch is turned on.

Why is there no sound coming from my VTech 80-178000 Starshine the Bright Lights Unicorn?

Check if the volume switch is set to an audible level. Ensure the batteries are properly installed and have enough power. If the problem persists, try replacing the batteries.

Why are the lights on my VTech 80-178000 Starshine the Bright Lights Unicorn not working?

Confirm that the batteries are inserted correctly and are not depleted. If the lights still do not work, replace the batteries with new ones. Check for any loose connections inside the battery compartment.

Why does my VTech 80-178000 Starshine the Bright Lights Unicorn keep turning off by itself?

The toy may have an auto-off feature to conserve battery life. Ensure the batteries are not weak or depleted. If the toy continues to turn off, try replacing the batteries.

What should I do if the buttons on my VTech 80-178000 Starshine the Bright Lights Unicorn are unresponsive?

Check that the batteries are properly installed and have sufficient power. If the buttons remain unresponsive, gently clean around the buttons with a dry cloth to remove any dirt or debris.

VIDEO – PRODUCT OVERVIEW



[Download the PDF Link: VTech 80-178000 Starshine the Bright Lights Unicorn User's Guide the-Bright-Lights-Unicorn-Users-Guide.mp4](#)

REFERENCE: [VTech 80-178000 Starshine the Bright Lights Unicorn User's Guide-Device.Report](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.