



VULCAN VUL-MT M Heated Gloves User Manual

[Home](#) » [Vulcan](#) » VULCAN VUL-MT M Heated Gloves User Manual 

Contents

- 1 VULCAN VUL-MT M Heated Gloves
- 2 How to install the batteries
- 3 How do I control the heat settings and switch on and off
- 4 WHAT IS INCLUDED
- 5 WASHING INSTRUCTIONS
- 6 HOW TO USE
- 7 ATTENTION
- 8 WARRANTY
- 9 Documents / Resources
- 10 Related Posts

VULCAN

VULCAN VUL-MT M Heated Gloves



How to install the batteries

Type 1

Outer Zipper Pocket



Type 2

Inside Zipper Pocket



How do I control the heat settings and switch on and off

TYPE 1



High Level



Medium Level



Low Level

TYPE 2



- High level with Red LED – Press power button for 3 seconds 1st Time to turn on
- Medium level with White LED – Press power button 2nd Time
- Low level with Blue LED – Press power button 3rd Time
- Turn Off – Hold power button for 3 seconds until light switches off

WHAT IS INCLUDED

- A pair of heated gloves
- A pair of 7.4V 2200MAH Polymer Lithium Rechargeable Batteries
- 1pc 8.4V dual battery charger
- 1 piece carry bag
- 1 user manual

HEATING TIME







- High Level: 100% Heat 2-2.5 Hours
- Medium Level: 66% Heat 3-3.5 Hours
- Low Level: 33% Heat 6-6.5 Hours

HEATING AREA

- Heating elements cover the whole of the back of the hand and fingers to the fingers tips

WASHING INSTRUCTIONS

- Remove batteries while cleaning and storing your gloves and close zips before washing
- Use Mild Detergent to clean where required and Air dry lying flat
- Hand wash is recommended for safety
- If Machine Washing is required, it is recommended to wash in a mesh wash bag
- Do not Machine Dry or use Bleach
- Ensure fully dry before use

					
Machine Wash at 30°	Do not Bleach	Do Not Twist / Wring	Do not Tumble Dry	Do not Iron	Do not Dry Clean

HOW TO USE

- Charge Up – Fully Charge the batteries with provided charger before using
- Plug-In – Carefully connect the batteries with the power wire located in the pocket
- Press Power button for 3 seconds to switch on with high heat setting and press again to adjust heat modes. To switch off hold power button for 3 seconds until lights not illuminated
- It is recommended to recharge the batteries at least once in every six months to keep useable (If product is not in use)

ATTENTION


- Always remove the batteries from your gloves when charging

- For safety, do not drop, short circuit, or operate under high-temperature conditions
- Ensure product is fully dry following washing/use before reusing and connecting the batteries
- If the device or the battery swells or becomes malformed, please stop using it immediately

WARRANTY

- Lithium-ion batteries, charger and gloves covered for 12 months from date of purchase

Documents / Resources

 <small>For any question please email: info@vulcanperformance.com</small>	VULCAN VUL-MT M Heated Gloves [pdf] User Manual VUL-MT M Heated Gloves, VUL-MT M, Heated Gloves
---	--

Manuals+.