

WA Library 6167 Big Book Display Box Instruction Manual




WA Library 6167 Big Book Display Box Instruction Manual



Contents

- [1 Parts Supplied](#)
- [2 ASSEMBLY INSTRUCTION](#)
- [3 Documents / Resources](#)

Parts Supplied


									2 x End Panels 380mm x 420mm 1 x Base Panel 725mm x 385mm 2 x Metal Castor Rod 2 x Side Panels 725mm x 385mm 2 x Internal Divider Panels 725mm x 390mm 1 x Centre Panel 725mm x 400mm 2 x swivel castors & 2 x locking castors 18 x Cam Pins 1 x Nut & Bolt Set
---	---	---	---	---	--	---	---	---	--

ASSEMBLY INSTRUCTION


Step 1: screw all cam pins (H) into metal screw holes in (A) & (D)




Step 2: Put bolt (I) through top of base board (B) and rail (C), secure with bolt. Attach castors (G) to rail.




Step 3: Push centre panel (F) into centre of base panel (B)




Step 3: Push internal dividers panels (E) into base panel (B)




Step 4: Push side panels (D) into base panel (B). Lock cam pins in by turning cam locks 90 degrees.



Step 5: Finish unit by adding end panels (A). Lock cam pins in by turning cam locks 90 degrees



Documents / Resources



[WA Library 6167 Big Book Display Box](#) [pdf] Instruction Manual
6167 Big Book Display Box, 6167, Big Book Display Box, Book Display Box, Display Box, Box