

Wagner GRV96MKT Touch Screen Hd Mirror Display Instructions

Home » Wagner » Wagner GRV96MKT Touch Screen Hd Mirror Display Instructions

Wagner GRV96MKT Touch Screen Hd Mirror
Display Instructions

GRV96MKT Firmware Instructions

** Please confirm BEFORE carrying out the firmware update that the "MIRROR" option is missing from the mirror settings

& the device is currently on version 20220709_V0.1.**

Once confirmed the MIRROR option is indeed missing please follow these instructions. Please download the following file <a href="https://great.org/great/configuration-con

- 1. Copy the file SD CarDV.bin onto a formatted SD card.
- 2. With the mirror switched OFF please insert the SD card.
- 3. Power ON the mirror, then wait for the firmware to load.
- 4. When the firmware has updated, the mirror will shut down.
- 5. Please now remove the SD card.
- 6. Power up the mirror once again and confirm the "MIRROR" option is located in the settings.

Contents

1 Documents / Resources

1.1 References

Documents / Resources



<u>Wagner GRV96MKT Touch Screen Hd Mirror Display</u> [pdf] Instructions 20220709_V0.1, 20220820, GRV96MKT Touch Screen Hd Mirror Display, GRV96MKT, Touch Screen Hd Mirror Display, Screen Hd Mirror Display, Display

References

- Index of /firmware/Gator/GRV96MKT/FIRMWARE TO ADD MISSING MIRROR FUNCTION ON FW VERSION 20220709_V0.1/GRV96MKT FW 20220820
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.