

# Walker Edison B48IV3D Assembly Instruction Manual

Home » Walker Edison » Walker Edison B48IV3D Assembly Instruction Manual






#### **Contents**


- 1 Walker Edison B48IV3D
- **Assembly**
- **2 General Assembly Guidelines**
- **3 PARTS LIST**
- **4 HARDWARE LIST**
- **5 STEP OF INSTALLATION**
- 6 Documents / Resources
- 7 Related Posts

Walker Edison B48IV3D Assembly





#### **General Assembly Guidelines**

- 1. Ensure that all parts and hardware are available before beginning assembly.
- 2. Follow each step carefully to ensure the proper assembly of this product.
- 3. Two people are recommended for ease in the assembly of this product.
- 4. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- 5. A Phillips head screwdriver is required for the assembly of this product.




6. Power tools should not be used to assemble this product.






# **HARDWARE LIST**




## **STEP OF INSTALLATION**


## Step 1




Step 2




Step 3



Step 4



Step 5



Please visit our website for the most current instructions, assembly tips report damage, or request parts. <a href="https://www.walkeredison.com">www.walkeredison.com</a>

#### **Documents / Resources**



Walker Edison Walker Edison B48IV3D Assembly [pdf] Instruction Manual Walker Edison, B48IV3D, Assembly

Manuals+,