



WATTS BLK01 RF Leak Sensor Installation Guide

[Home](#) » [WATTS](#) » WATTS BLK01 RF Leak Sensor Installation Guide 

Contents

- [1 WATTS BLK01 RF Leak Sensor](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 What's In The Box](#)
- [5 Application](#)
- [6 Safety warnings and operating instructions](#)
- [7 Installation](#)
- [8 Commissioning](#)
- [9 Pairing](#)
- [10 Dimensions](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



WATTS BLK01 RF Leak Sensor



Product Information

Product Name	Wireless Leak Sensor
Product Website	Wireless Leak Sensor
Dimensions	43 mm x 85 mm
Quick Installation Guide	Download Quick Installation Guide
Contact Information	T: +33(0) 471 57 40 49 F: +33(0) 471 57 40 90 wattswater.eu

Product Usage Instructions


To install the Wireless Leak Sensor, follow the steps below:

1. **Ensure you have received all the necessary components:**
 - Wireless Leak Sensor x1
 - Installation manual x1
 - Safety warnings and operating instructions (available in multiple languages)
2. Refer to the Quick Installation Guide for detailed installation instructions. The guide can be downloaded [here](#).
3. Pair the Wireless Leak Sensor with your compatible device using the following steps:
 - Press and hold the pairing button on the sensor for 3 seconds.
 - The green LED will flash once and then blink orange for 30 seconds.
 - Refer to the specific language instructions for the LED indications during pairing:

Language	LED Indication
English (EN)	Green LED flashes once and blinks orange for the 30s.
French (FR)	La led verte clignote une fois et clignote en orange pendant 30s.
Italian (IT)	Il led verde lampeggia una volta e lampeggia in arancione per 30s.

If you encounter any issues during installation or usage, please refer to the provided safety warnings and operating instructions for troubleshooting steps. If further assistance is required, please contact our support team at the provided contact information.

What's In The Box



Application




<https://wattswater.eu/catalog/regulation-and-control/watts-vision-smart-home/wireless-leak-sensor/>.


Safety warnings and operating instructions

This product should be installed preferably by a qualified professional. All instructions in this Installation & Operation manual should be observed when working with the controller. Failures due to improper installation, improper use or poor maintenance are voiding manufacturer liability. Batteries may explode or leak, and cause burn injury, if recharged, disposed of fire, mixed with a different battery type, inserted backward, or disassembled. Replace all used batteries at the same time. Do not carry batteries loose in your pocket or purse. Do not remove the battery label. Keep batteries away from children. If swallowed, consult a physician at once.


Installation




Commissioning



Pairing



Dimensions



The descriptions and photographs contained in this document are supplied by way of example and illustration only. Watts Industries reserves the right to carry out any technical and design improvements to its products without prior notice. Watts hereby objects to any term, different from or additional to Watts terms, contained in any buyer communication in any form, unless agreed to in writing and signed by an officer of Watts.

2012/19/EU:

Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points.

- For more information see: www.recyclethis.info.

2006/66/EC:

This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg).

For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

Vision® Wireless wattswater.eu

**Watts Electronics S.A.S**

- **Add:** B.P. N°10 – Z.A. des Tourettes, 43800 ROSIERES, France.
- **T:** +33(0) 471 57 40 49
- **F:** +33(0) 471 57 40 90,
- **Web:** wattswater.eu.

© 2023 Watts



[WATTS BLK01 RF Leak Sensor](#) [pdf] Installation Guide
BLK01 RF Leak Sensor, BLK01 RF, Leak Sensor, Sensor

References

- [W WATTS EUROPE](#)
- [HOME](#)
- [W Smart Home and Controls | WATTS EUROPE](#)