



WeCool G1 1-Axis Gimbal Stabilizer with Wireless Remote User Manual

[Home](#) » [WeCool](#) » WeCool G1 1-Axis Gimbal Stabilizer with Wireless Remote User Manual 






Contents


- [1 REMOVE AND REPLACE THE REMOTE](#)
- [2 HOW TO CONNECT TO PHONE](#)
- [3 SELFIE STICK MODE](#)
- [4 SPECIFICATION](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

REMOVE AND REPLACE THE REMOTE



CHANGING BATTERY

Pull Out from the groove on the left to open the remote control cover




HOW TO CONNECT TO PHONE

1. Turn on: Long press the camera button for 3 seconds to turn it on.
2. Bluetooth pairing: the indicator light flashes for 4 seconds to enter the pairing state, and the blue indicator light of the pairing state flashes, use the mobile phone to search for "We cool G1" to match, and the blue indicator light will go out after the pairing is successful.
3. Take a photo: When the "Wecool G1" is connected to the mobile phone, short press the camera button, and the blue light flashes.
4. Auto Turn Off: After booting, in the state of no pairing connection, it will automatically shut down after 5 minutes of no operation.
5. Pairing: After turning on the phone, when the Selfie is connected to the phone, it will enter the dormant state if there is no operation for 10 minutes, and it will automatically shut down after another 10 minutes.
6. Power off: power on and sleep mode, press and hold the camera button for 3 seconds to power off, and the indicator light flashes and goes out.

TRIPOD MODE




Open towards the bottom of the handle, change into a tripod in seconds



COMPATIBLE




HOW TO USE PAN, TILT, AND ZOOM HEAD

	<p>Clamp the phone and maintain a natural balance Long press the PTZ power button for 5 seconds to turn it on, Long press it for 3 seconds to shut down</p>
	<p>After booting, the green light flashes to enter Steady shooting mode, shake the handle left and right, The pan/tilt always keeps the same horizontal direction.</p>
	<p>Click the power button of the gimbal stand, Horizontal and vertical shooting Manually dial left (right) more than 45° For 2 seconds, The pan/tilt automatically rotates 90° to the left (right).</p>

SELFIE STICK MODE


When the gimbal is turned off, slide the unlock button to Change to selfie stick mode.



HOW TO CHARGE

Use a Normal 5V Charger to charge the gimbal. One is provided along with the product.

Micro USB Interface



SPECIFICATION

- Main Material: Premium Aluminium Alloy
- Mount Holder: 70-100mm
- Collapsed Length: 190mm
- Extended Length: 420mm
- Product weight: 201g
- Battery: CR1632 (Replaceable)
- Please keep the battery away from direct sunlight, fire, or heating elements.

WARRANTY & AFTER-SALES SERVICES

To Avail of the warranty, register your purchase on our website www.wecool.in within 10 days of purchase. Feel free to contact our customer support on 90362 28529 (Whatsapp or Call) or Write to us at


support@wecoolimports.com

Scan here to register now.



<https://www.wecool.in/pages/warranty-registration>

Documents / Resources

	<p>WeCool G1 1-Axis Gimbal Stabilizer with Wireless Remote [pdf] User Manual G1 1-Axis Gimbal Stabilizer with Wireless Remote, G1 1-Axis, Gimbal Stabilizer with Wireless Remote, Stabilizer with Wireless Remote, Wireless Remote, Remote</p>
---	--

References

-  [WeCool - Buy True Wireless Earbuds, Mobile Accessories at Best Prices](#)