WEIMEI **DS** S Card **Find My Tracker**



Weimei DS Card Find My Tracker User Manual

Home » WEIMEI » Weimei DS Card Find My Tracker User Manual

Contents

- 1 Weimei DS Card Find My
- **Tracker**
- 2 Specifications
- 3 FAQs
- **4 Operating Instructions**
- **5 PRODUCT USING**
- **INSTRUCTION**
- **6 Limited warranty**
- 7 FCC
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



Weimei DS Card Find My Tracker



- Compliance: Part 15 of FCC Rules
- Radiation Exposure: FCC Limits for Uncontrolled Environment
- Minimum Distance: 0cm between radiator and body

FAQs

- Q: Can I modify the device on my own?
 - A: No, any changes or modifications not approved by the manufacturer can void your authority to operate the equipment.
- Q: What are the FCC compliance conditions for the device?
 - **A:** The device must not cause harmful interference and must accept any received interference, even if it causes undesired operation.
- Q: How far should the equipment be from my body during operation?
 - **A:** The equipment should be operated with a minimum distance of 0cm between the radiator and your body to comply with FCC radiation exposure limits.

Operating Instructions

- Operating Instructions on Apple Find My App
 - To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.
- How to set up the locator
 - First, make sure WiFi and Bluetooth are turned on







PRODUCT USING INSTRUCTION

Make the DS Card discovered following the steps


1. Press the power button seconds, after the ringtone rings and the Controlling light blinks in white, and the DS Card is ready.




2. Turn on the Apple "Find My" App, Click "Add Item", then click "Other Supported Item"




- 3. Bring the DS Card close to the iPhone, identify the locator, and then click "Connect"
- 4. Customize the "name" and "emoji" of the DS Card, then the setting is complete.



1. Turn on the Apple "Find My" App, Click "Items", then Swipe left on the item you want to remove.T




2. After removal, the Card will sound a tone and a white light will flash.



DS Card supports a wireless charging function, you can use a wireless charger to charge it.

- 1. Align the DS Card's battery coil position with the wireless charger.
- 2. When the DS Card starts charging, it will sound a bell and light a red light.
- 3. When the DS Card is fully charged, it lights green, so please remove it from the charger.



Safe electronic disposal

- The earth is our common home and DISIDUW attaches great importance to protecting the cleanliness of the environment and avoiding its pollution.
- When your device reaches the end of its useful life, please dispose of it at your locale-waste center to be recycled and properly discarded.

How to restore the factory setting

- Click the power button four times, and then press the power button for some seconds long;
- When the ringtone sounds, the light flashes in white quickly. That is completed.

Warning

- 1. This product is not a toy or edible.
- 2. Obstacles or large metal objects can interfere with the Bluetooth signal.
- 3. This product has a built-in lithium battery. Please do not put this product directly on fire or any place near heat or fire. Otherwise, the product may be damaged malfunctioned, or even be dangerous.

Disclaimer

• This is neither an anti-theft nor an anti-lost device.

• This device provides the last detected location.

Limited warranty

- DISIDUW offers a one-year limited warranty against product defects, effective from the time of delivery.
- Product defects do not include those resulting from accidents, product modification, or failure to follow instructions for use.

FCC

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used following the instructions, maycause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0cm between the radiator and your body.

Documents / Resources



Weimei DS Card Find My Tracker [pdf] User Manual KP01, 2BHWU-KP01, 2BHWUKP01

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.