

wemfg

**RH705 RC Remote
Control Boats**



Wemfg RH705 RC Remote Control Boats User Manual

[Home](#) » [WEMFG](#) » Wemfg RH705 RC Remote Control Boats User Manual 

Contents

- [1 Wemfg RH705 RC Remote Control Boats](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 How to Install](#)
- [7 Usage](#)
- [8 Care and Maintenance](#)
- [9 Troubleshooting](#)
- [10 Pros and Cons](#)
- [11 Contact Information](#)
- [12 Warranty](#)
- [13 FAQs](#)
- [14 Video-Wemfg RH705 RC Remote Control Boats](#)
- [15 References](#)
- [16 Related Posts](#)

wemfg

Wemfg RH705 RC Remote Control Boats



Launch Date: August 11, 2023.

Price: \$19.99

Introduction

The Wemfg RH705 RC Remote Control Boat is the best toy for having fun in the water. This boat is made for kids and can go up to 18 mph on water, making it very exciting. The boat is great for pools, lakes, and ponds because it is sturdy and waterproof. There are simple features on the Wemfg RH705 that make it easy for kids to use, even if they have never been on a boat before. It comes with a recharging battery that lets you play for up to 20 minutes on a single charge. This boat has extra features like a 2.4 GHz frequency for racing without any disturbance. It will keep people of all ages entertained for hours.

Specifications

- **Brand Name:** Wemfg
- **Model Number:** RH705
- **Model Name:** RH701
- **Color:** Shark
- **Material Type:** Plastic
- **Theme:** Boat
- **Toy Vehicle Form:** Boat
- **Maximum Speed:** 18 Miles per Hour

- **Operation Mode:** Manual
- **Power Source:** Battery Powered
- **Battery Type:** Lithium-Ion (Rechargeable)
- **Number of Batteries:** 2 AA Batteries required (not included)
- **Included Components:** RC Boat, Lithium Battery, Transmitter Controller, USB Charger, Propeller, User Manual
- **Dimensions:** 3.94 x 4.72 x 10.24 inches
- **Item Weight:** 0.2 kg
- **Age Range:** 36 months to 48 months
- **UPC:** 791507072569
- **Unit Count:** 1.0 Count

Package Includes



- 1 x Wemfg RH705 RC Boat
- 1 x 2.4 GHz Remote Control
- 1 x 7.4V 1500mAh Li-ion rechargeable battery
- 1 x USB Charging Cable
- 1 x Spare Propeller
- 1 x Boat Stand
- 1 x User Manual

- 1 x Screwdriver for assembly

Features

1. Fast Speed

The Wemfg RH705 RC Boat can go as fast as 20 km/h, making it a thrilling choice for water activities. The high-speed powers of the boat let you enjoy the thrill of moving quickly on the water, whether you're racing across a lake, pond, or pool.

2. Rotation of 360 degrees

This boat is one of a kind because it can turn 360 degrees. It's easy to flip and spin, which makes the experience fun and lively. These flips and spins make water racing even more exciting, whether you want to show off your fishing skills or impress other people.

3. Built to be waterproof

The RH705 is built to last, even when it's covered in water, because it is waterproof. The construction of this boat makes it perfect for lakes, pools, and ponds because it can handle the water. The waterproof technology makes sure that water doesn't damage the electronics inside the boat, which makes it last longer.



4. 2.4 GHz Signal Height

The boat uses a 2.4 GHz frequency, which makes control exact and free of interference. You can race more than one boat at the same time on this frequency without any signal problems. This makes it perfect for both competitive races and joint play. Long-range control is important for bigger areas of water, and this system gives you that.

5. **Strong Construction**

The Wemfg RH705 is constructed from premium ABS plastic and metal, which gives it a strong and long-lasting structure. The boat can handle bumps, crashes, and the normal wear and tear of use thanks to its long-lasting material. This makes it a great buy for both new and experienced users.

6. **Battery That Can Be Charged**

The RH705 has a 7.4V 1500mAh Li-ion battery that can be charged and gives you up to 20 minutes of play time without stopping. Many other RC boats only last 8–10 minutes, but this one's battery life is longer, so you can have more fun for longer. The boat also comes with two batteries so you can play for longer and more easily.

7. **Easy-to-Use Controls**

The remote control is simple to use and was made for both new and experienced users. The boat is easy for both kids and adults to steer because it has simple controls. The easy-to-use method lets you move forward and backward and turn precisely left and right.

8. **LED Lights**

The LED lights that are built into the boat make it look cool and make it easier to see at night. Because these lights make the boat stand out at night, it is safe to play even when the sun goes down.

9. **Kid-Friendly 2.4 GHz Remote**

The 2.4 GHz radio control makes sure everything works smoothly and is made to be easy for kids to use. The range of the remote control is up to 164 feet, which gives kids plenty of room to play without being interrupted. It's also easy enough for them to use without any problems.



10. **Technology for Finding Water**

The engine will only start when the boat is in the water, thanks to technology that detects water. This feature keeps the engine from getting damaged and makes the boat last longer, which makes it a better choice for long-term use.

11. **Twice-Useful Batteries**

The RH705 comes with two batteries that can be charged and used again and again. The given USB cable makes charging them easy, making them convenient and making sure you're always ready for more fun on the water.

12. **High Speed to Play All the Time**

Unlike other RC boats, which often run for shorter periods, the RH705 boat provides 20 minutes of playtime per battery—thanks to its larger rechargeable battery. Since it comes with two batteries, you can play for even longer or longer.

13. **Range of 164 Feet for Remote Control**

With a range of up to 164 feet, the 2.4 GHz infrared remote control lets you precisely steer the boat. This extended range allows you to control the boat even from a distance, making it perfect for larger areas like lakes or spacious pools.

14. **Can be changed the top cover**

The top cover of the RH705 is designed to be securely fitted onto the boat. Make sure the top cover is locked properly before use to prevent water from entering the boat's interior, ensuring both safe operation and prolonging the boat's lifespan.



15. **Protective Measures**

After each play session, remember to remove the battery and open the boat's top cover to allow the interior to

dry. This helps prevent water damage and keeps the boat in top working condition for future use.

How to Install



1. Shark Assembly:

- The shark fin is separate from the boat body.
- Align the fin with the slots on the boat's back.
- Press the fin firmly into place until it clicks.

2. Battery Installation:

- Locate the battery compartment on the underside of the boat.
- Remove the cover.
- Insert the batteries, ensuring they are placed in the correct polarity.
- Replace the cover.

3. Remote Control Battery Installation:

- Open the battery compartment on the remote control.
- Insert the batteries, ensuring they are placed in the correct polarity.
- Replace the cover.

4. Turning On the Boat:

- There is usually a power switch on the boat.
- Slide the switch to the “On” position.

5. Pairing the Remote Control:

- Some remote controls may require pairing with the boat.
- Refer to the specific instructions for your model to complete the pairing process.

Additional Notes:

- The images show a boat with a shark-shaped fin. If your boat doesn't have a fin, skip step 1.
- Always refer to the specific instructions that came with your remote control boat model for accurate assembly and operation.

Usage

- **Outdoor Fun:** Perfect for use in pools, ponds, and small lakes, offering hours of fun for kids and adults alike.
- **Easy to Control:** With its manual control mode, the boat is suitable for young children, allowing them to easily learn how to navigate the boat across water.
- **Ideal for Racing:** The **18 mph maximum speed** and durable design make it a great option for racing across the water with friends or family.

Care and Maintenance

- **Battery Care:** Always fully charge the battery before use. Avoid overcharging and store the battery in a cool, dry place.
- **Cleaning:** After each use, rinse the boat with fresh water to remove any dirt or saltwater. Wipe it down with a dry cloth to prevent corrosion.
- **Storage:** Store the boat in a cool, dry place when not in use. Ensure the battery is removed if storing for long periods.
- **Propeller Care:** Inspect the propeller regularly for wear and tear. Replace it if damaged.
- **Remote Control:** Store the remote in a dry place and avoid dropping it to ensure long-term functionality.

Troubleshooting

The boat won't start:

- **Solution:** Ensure the battery is fully charged and properly inserted. Check the boat's power switch to ensure it's in the 'ON' position.

Boat not responding to the remote control:

- **Solution:** Make sure the remote control is powered on and the frequency is synchronized with the boat. Check

if the boat's battery is running low.

Boat flips over frequently:

- **Solution:** Try to drive the boat in calmer water, as waves may affect its balance. Ensure the boat is not carrying too much weight.

Remote control out of range:

- **Solution:** Ensure you are within the 80-meter range. Move closer to the boat for better signal strength.

Battery draining too fast:

- **Solution:** Check the battery's health, as older batteries may deplete faster. Recharge the battery fully before use and ensure it is not left unused for too long.

Boat moving erratically:

- **Solution:** Check the propeller for obstructions. Clean any debris or dirt around the propeller to ensure smooth movement.

Pros and Cons

Pros:

- High-speed performance is suitable for all ages.
- Durable construction ensures longevity.
- User-friendly design makes it accessible for beginners.

Cons:

- Limited control distance may restrict usage in larger areas.
- Battery life may vary based on usage conditions.

Contact Information

For inquiries or support, please contact Wemfg customer service at support@wemfg.com or call +1 [800-555-0199](tel:800-555-0199).

Warranty

The Wemfg RH705 RC Remote Control Boat comes with a one-year warranty covering manufacturing defects. Please retain your proof of purchase for warranty claims.

FAQs

What is the maximum speed of the Wemfg RH705 RC Remote Control Boat?

The Wemfg RH705 can reach a maximum speed of 18 miles per hour, providing exciting high-speed action on water.

How long does the battery last in the Wemfg RH705 RC Boat?

The Wemfg RH705 provides up to 20 minutes of playtime per battery when fully charged, ensuring long-lasting fun.

What is the control distance of the Wemfg RH705?

The Wemfg RH705 has a control range of up to 164 feet, allowing you to navigate it across large bodies of water.

What is included in the package with the Wemfg RH705?

The package includes the RC boat, a lithium-ion battery, a transmitter controller, a USB charger, a propeller, and a user manual.

What material is the Wemfg RH705 made from?

The Wemfg RH705 is made from durable plastic, ensuring that the boat can withstand bumps and splashes during play.

How do you maintain the Wemfg RH705 RC Boat?

To maintain the Wemfg RH705, remove the battery after each use, ensure the boat is thoroughly dried, and clean the exterior to prevent water damage.


Can the Wemfg RH705 be used in saltwater?

While the Wemfg RH705 is waterproof, it's recommended to clean the boat after using it in saltwater to prevent long-term damage.

What type of batteries are required for the remote controller of the Wemfg RH705?

The Wemfg RH705 remote controller requires 2 AA batteries (not included) to operate.

Video-Wemfg RH705 RC Remote Control Boats



[Referencesals.plus/wp-content/uploads/2024/12/Wemfg-RH705-RC-Remote-Control-Boats.mp4](#)

- [User Manual](#)

ul>

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.