



# WGCV 2K Wireless Security Camera User Guide

[Home](#) » [WGCV](#) » WGCV 2K Wireless Security Camera User Guide 

## Contents

- [1 WGCV 2K Wireless Security Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 What's Included](#)
- [5 What's Included](#)
- [6 Product Overview](#)
- [7 MOUNTING THE CAMERA](#)
- [8 What is required](#)
- [9 Register an Account](#)
- [10 Set up Wifi for the camera](#)
- [11 Function Introduction](#)
- [12 Multi-Camera Management](#)
- [13 FAQ](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)

# WGCV

**WGCV 2K Wireless Security Camera**



## Product Information

The product is a camera that can be connected to a network for remote monitoring. It comes with a 3-year warranty, which can be registered by sending the Amazon Order ID to [support@wgvtech.com](mailto:support@wgvtech.com). The camera supports a maximum of 128GB micro SD card for local storage. It has an IR light, a status light, an SD card slot, a microphone, a speaker, and a reset button. The camera can be mounted on a flat surface using the included mounting bracket.

## Product Usage Instructions

- **Warranty Registration**

- To register the 3-year warranty, send the Amazon Order ID to [support@wgvtech.com](mailto:support@wgvtech.com).

- **Frequently Asked Questions (FAQ)**

- **Q: Failed to add during network configuration?**

**A:** Please make sure your phone is connected to a router in the 2.4GHz band and ensure that the Wi-Fi password is correct.

- **Q: After scan adding is still unsuccessful?**

**A:** Reset the device or power off the device after scan adding is still unsuccessful, and then try to add it again.

- **Q: The device cannot preview normally.**

**A:** Please check if the network signal is too weak. Place the camera close to the router. If the issue persists, reset the camera and add it again.

- **Q: How to switch the camera network to another router?**

**A:** First remove and reset the device on the app, and then configure the network for the device again.

through the app.

• **Q: Why does the device not recognize the TF card?**

**A:** Please remove and insert the TF card after powering off. Check if the TF card is working normally and whether it is in FAT32 format. In unstable network conditions, the TF card might not be recognized.

• **Q: How to get the latest user manual?**

**A:** If the app interface is not in accordance with the instructions, visit the WGV website at <https://wgvtech.com/manual> to download the latest instructions.

• **Product Setup**

- Camera
- Screw Packs
- Power Adapter
- Mounting Bracket
- USB Cable
- Quick Guide

• **Product Overview**

- IR light
- Status light
- SD card slot
- Microphone
- Reset button
- Speaker
- Micro USB
  - **CAUTION:** Please insert the Micro SD Card according to the direction shown in the diagram. Micro SD Card might jam if inserted incorrectly, and the device could be damaged.
  - **SD Card Slot:** Supports micro SD cards for local storage with a maximum capacity of 128GB.
  - **Reset Button:** Used to restore the camera to factory settings. Press and hold for 5-8 seconds.
  - **Status Light:** Blinking Red Light – Wait for network connection (slow) Solid Blue Light – Connecting the network (fast) Solid Red Light – Camera is working correctly Camera is malfunctional

• **App Installation and Setup**

- To operate the camera, the WGV App needs to be installed.
- Search for “WGV” on the Apple Store or Google Play Store to install the app.
- Alternatively, scan the QR code below to download the WGV App to your Android or Apple device.

• **Mounting the Camera**

- Put the camera on a flat surface.
- Use the included mounting bracket to attach the camera to a flat surface.

• **What is required:**

- Power Drill (not provided)
- 15/64 6(mm) Drill Bit

• **Register an Account**


- Open the App to register an account. Go to the login interface and click “Sign Up”.
- Sign up with your email address and click “Next”.
- Set up a nickname and password for your App, then click “Done” to complete.

- **Set up WiFi for the Camera**


- Bring both your mobile phone and WGV camera close to your router (maximum distance of 5 meters / 16 feet).

**Note:** The WGV camera can only connect to a 2.4GHz Wi-Fi signal and does not support using a 5GHz signal. Please connect to a 2.4GHz signal on your network.


**What's Included**




Camera



Screw Packs



Power Adapter



Mounting Bracket




USB Cable




Quick Guide


**What's Included**




Camera




Screw Packs



Power Adapter



Mounting Bracket




USB Cable



Quick Guide

## Product Overview



**CAUTION:** Please insert the Micro SD Card according to the direction shown in the diagram. Micro SD Card might JAM if inserted incorrectly and device could be damaged.

**SD Card Slot:** Support micro SD card for local storage (Max 128GB).

**Reset Button:** Used to restore the camera to factory settings (Press and hold for 5-8s).

**Status Light:**

Blinking Red Light	Wait for network connection (slow) Connecting the network (fast)
Solid Blue Light	Camera is working correctly
Solid Red Light	Camera is malfunctional

### WGV App Installation and Setup

Search for “WGV” on Apple Store or Google Play Store to Install the App.



Or please scan below QR code below to download the “WGV” App to your Android or Apple device.




### MOUNTING THE CAMERA

1. Put the camera on a flat surface.
2. Use the included mounting bracket to attach the camera to a flat surface.

#### Mounting the Camera

1. Put the camera on a flat surface.
2. Use the included mounting bracket to attach the camera to a flat surface.




### What is required





2-1




2-2



2-3

3. "Nextet the device and wait for a flashing RED indicator light, then tap







4-1



4-2

4. Selecting the Wi-fi the Camera needs to be connected to. Type in the password and click "Next"



5-1



5-2

5. Use the WGV camera to scan the QR code on your mobile phone as noted below. When the scan is complete you will hear a tone then click "Next"

4. When connecting , you should make sure that the router, mobile phone and the WGV camera and are as close together as possible ( max
5. meters / 16 feet ) When a successful connection occurs a “click” will be heard and a check mark will be shown like in the image below. The WGV camera will show with a numerical name that can be changed to your liking such as Baby Camera, Pet Camera, or any other name.



6-1



6-2




6-3

## Function Introduction



1. Time of the device	8. Full screen preview
2. Sound of the device	9. Definition of the picture
3. Live	10. Cloud
4. Screenshot	11. History
5. Intercom	12. Record
6. Motion detection	13. Lens switch
7. Camera settings	14. PTZ method

## Multi-Camera Management



## Multi-user Sharing

The camera can be shared with others in two Ways:

1. Let her/him view but cannot control the camera
2. Let her/him view and control the camera

## Share steps

1. download the App to his/her phone and register his new account in App
2. Click Add in App on A's phone
3. A scan B'S QR Code or input B's account ID
4. accept share

## FAQ

1. **Q:** Failed to add during network configuration?  
**A:** Please make sure your phone is connected to a router in the 2. 4GHZ band and make sure that the WI-FI password is correct.
2. **Q:** After the scan adding is still unsuccessful?  
**A:** Reset the device or power off the device after scan adding is still unsuccessful, and then try to add it again
3. **Q:** The device cannot preview normally.  
**A:** Please check if the network signal is too weak, please put the camera Close to the router, if still cannot preview, reset the camera and add it again.
4. **Q:** How to switch the camera network to another router?  
**A:** First remove and reset the device on the APP, and then configure the network for the device again through the APP.
5. **Q:** Why does the device not recognize the TF card?  
**A:** Please remove and insert the TF card after power off, please check if the TF card is working normally and whether it is in FAT32 format, when the mobile phone or the device is working in an unstable network the TF card might not be recognized.
6. **Q:** How to get the latest user manual?

**A:** We keep improving the app, if the app interface is not in accordance with the instructions. Please go to the WGV website <https://wgvtech.com/manual>. download the latest instructions.


- Please send your Amazon Order # to
- [support@wgvtech.com](mailto:support@wgvtech.com).
- to extend 3 Year Unlimited Replacement Service



- <https://wgvtech.com/>.
- [support@wgvtech.com](mailto:support@wgvtech.com).

Register 3 year Warranty by sending an Amazon Order ID to [support@wgvtech.com](mailto:support@wgvtech.com).

**Documents / Resources**

	<p><a href="#">WGV 2K Wireless Security Camera</a> [pdf] User Guide 2K Wireless Security Camera, 2K, Wireless Security Camera, Security Camera, Camera</p>
---	--

**References**

- [wgvtech.com/](https://wgvtech.com/)
- [Manual](#)
- [User Manual](#)