


WHADDA WPI474 Logic Level Shifter Module User Manual

Home » WHADDA » WHADDA WPI474 Logic Level Shifter Module User Manual



MANUAL LOGIC LEVEL SHIFTER MODULE WPI474



Contents

- 1 Introduction
- 2 Safety Instructions
- 3 General Guidelines
- 4 What is Arduino®
- **5 Product overview**
- **6 Specifications**
- 7 Wiring description
- 8 Documents /

Resources

- 8.1 References
- 9 Related Posts

Introduction

To all residents of the European Union



Important environmental information about this product

This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

If in doubt, contact your local waste disposal authorities.

Thank you for choosing Whadda! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer.

Safety Instructions



Read and understand this manual and all safety signs before using this appliance.



For indoor use only.

This device can be used by children aged 8 years and above, and persons with reduced physical, sensory or
mental capabilities or lack of experience and knowledge if they have been given supervision or instruction
concerning the use of the device in a safe way and understanding the hazards involved. Children shall not play
with the device. leaning and user maintenance shall not be made by children without supervision.

General Guidelines

- Refer to the Velleman ® Service and Quality Warranty on the last pages of this manual.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorized way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer

will not accept responsibility for any ensuing defects or problems.

- Nor Velleman NV nor its dealers can be held responsible for any damage (extraordinary, incidental, or indirect)
 of any nature (financial, physical...) arising from the possession, use, or failure of this product.
- Keep this manual for future reference.

What is Arduino®

Arduino® is an open-source prototyping platform based on easy-to-use hardware and software. Arduino® boards are able to read inputs – light-on sensor, a finger on a button, or a Twitter message – and turn them into an output – activating a motor, turning on an LED, or publishing something online. You can tell your board what to do by sending a set of instructions to the microcontroller on the board. To do so, you use the Arduino programming language (based on Wiring) and the Arduino® software IDE (based on Processing).

Additional shields/modules/components are required for reading a Twitter message or publishing online.

Surf to www.arduino.cc for more information

Product overview

The Whadda Logic Level Shifter module provides 8 logic conversion channels to enable microcontrollers, sensors, and modules with different logic level voltages to communicate with each other. Each channel is fully bidirectional and is compatible with both open-drain and push-pull logic drivers. The module can be used to convert 3.3 V to 5 V, 1.8-3.3. V and other common logic levels.

It is recommended to pull the Output Enable pin high with a pullup resistor to ensure the outputs are properly enabled. If the different logic level data lines need to be isolated, the Output Enable line can be pulled low. This will put all of the I/O channels in a high-impedance state.

Specifications


IC type: TI TXS0108E

Low-level voltage range: 1.4 - 3.6 VHigh-level voltage range: 1.65 - 5.5 V

Dimensions (W x L x H): 22,4 x 26,7 x 12,5 mm


Wiring description

Pin	Name	Description
VA	Low voltage supply (1,4 – 3,6 V)	The voltage supply of the low-level side should always be lower than the voltage on the VB pin
A1	Low voltage I/O channel 1	Input-Output channel 1 of the low-level side
A2	Low voltage I/O channel 2	Input-Output channel 2 of the low-level side
A3	Low voltage I/O channel 3	Input-Output channel 3 of the low-level side
A4	Low voltage I/O channel 4	Input-Output channel 4 of the low-level side
A5	Low voltage I/O channel 5	Input-Output channel 5 of the low-level side
A6	Low voltage I/O channel 6	Input-Output channel 6 of the low-level side
A7	Low voltage I/O channel 7	Input-Output channel 7 of the low-level side
A8	Low voltage I/O channel 8	Input-Output channel 8 of the low-level side
OE	Output Enable	Disables the device when set low, which places all I/O chan nels in the high-impedance state.
VB	High voltage supply (1,65 – 5,5 V)	The voltage supply of the high-level side should always be higher than the voltage on the VA pin
B1	High voltage I/O channel 1	Input-Output channel 1 of the high-level side
B2	High voltage I/O channel 2	Input-Output channel 2 of the high-level side
В3	High voltage I/O channel 3	Input-Output channel 3 of the high-level side
B4	High voltage I/O channel 4	Input-Output channel 4 of the high-level side
B5	High voltage I/O channel 5	Input-Output channel 5 of the high-level side
B6	High voltage I/O channel 6	Input-Output channel 6 of the high-level side
B7	High voltage I/O channel 7	Input-Output channel 7 of the high-level side
B8	High voltage I/O channel 8	Input-Output channel 8 of the high-level side
GND	Ground	Ground, 0 V



Modifications and typographical errors reserved – © Velleman Group NV. WPI474 Velleman Group NV, Legen Heirweg 33 – 9890 Gavere.

Documents / Resources



References

- Whadda Exciting Electronics
- Arduino Home
- Arduino Home

Manuals+,