

WHISTLER WS1010 Handheld Radio Scanner User Guide

Home » Whistler » WHISTLER WS1010 Handheld Radio Scanner User Guide 🖫



Contents

- 1 WHISTLER WS1010 Handheld Radio
- Scanner
- **2 Product Information**
- **3 Package Contents**
- **4 Product Usage Instructions**
- **5 Find Frequencies**
- 6 Documents / Resources
 - **6.1 References**



WHISTLER WS1010 Handheld Radio Scanner



Product Information

The WS1010 is a handheld radio scanner with 400 channels. It comes with a rechargeable battery holder, an alkaline battery holder, a scanner antenna, an AC adapter, and a belt clip.

Package Contents



Product Usage Instructions

1. Installing Batteries:

- 1. Slide open the battery compartment.
- 2. Place the battery holder into the battery compartment. Make sure it fits in the correct orientation and do not force it.
 - 1. Black Alkaline (non-rechargeable)

- 2. Yellow Rechargeable Ni-MH or Ni-Cd
- 3. Place the battery holder into the battery compartment. The battery holder fits only one way. Do not force it.
- 4. Replace the cover.



1. Connecting the Antenna:

1. Align the antenna slots with the tabs on the antenna jack.



2. Press the antenna over the jack and turn the base of the antenna clockwise to secure it.

1. Programming Frequencies:

- 1. Preset the squelch between the 10 and 12 o'clock position.
- 2. Press the PGM button to enter the program mode.
- 3. Enter the channel number (1-400) where you want to store a frequency and press PGM again.
- 4. Use the number keys and the period (.) key to enter the frequency.
- 5. Press ENT to store the frequency into the channel.
- 6. Press PGM to move to the next channel.
- 7. Press SCAN to begin scanning.



Find Frequencies

Go to <u>www.radioreference.com/db/browse</u>. Select your state/country and county/region to locate a list of frequencies in your area.

For more detailed instructions, please refer to the User Guide provided with the product.

If you need additional help, you can visit our FAQs on our website at www.whistlergroup.com.

Still need help?

visit our FAQs on our website at www.whistlergroup.com

Documents / Resources



WHISTLER WS1010 Handheld Radio Scanner [pdf] User Guide WS1010 Handheld Radio Scanner, WS1010, Handheld Radio Scanner, Radio Scanner, Scanner

References

- RRDB | United States
- st The Whistler Group, Inc.

Manuals+,