



## Wikipedia Remote Controller User Guide

[Home](#) » [Wikipedia](#) » Wikipedia Remote Controller User Guide 

Wikipedia Remote Controller User Guide

# 3D Lamp User Guide

Please read all instructions and warnings before use.


These instructions are for your safety and to ensure you obtain the best performance from this product. Save these instructions for future reference.

### Contents

- [1 Product Specifications:](#)
- [2 Safety Instructions](#)
- [3 How to Use](#)
- [4 Cleaning Instructions](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)

### Product Specifications:

- Input Voltage: 4.5V-5V
- Power Input: USB Cable (included) or 3 x AA Batteries (not included)
- Output Power: 2-2.5W



## Safety Instructions

- This product is for indoor use only.
- Before inserting the acrylic design into the base, please remove the yellow paper from one side.
- Do not touch acrylic plate surface with your fingers as this will leave marks and may affect the 3D illusion.



- To insert batteries, slide off battery cover, insert new batteries and replace cover.
- Rechargeable batteries are to be removed from the product before being recharged and should be recharged under adult supervision.
- Do not mix standard and rechargeable batteries or new and old batteries.
- Always insert batteries with the correct polarity.
- Exhausted batteries are to be removed from the product immediately.
- Always switch the lamp off overnight or if left unattended.

## How to Use

- Remove the yellow paper from one side of the acrylic plate.
- Place acrylic plate in base.
- Plug in USB cable to power supply/computer or insert batteries.
- Press the power button to turn on.
- Press the power button to change colour. Each time the power button is pressed, the lamp will change colour. There are 7 colours (red, green, blue, yellow, cyan, purple and white) plus an alternating option.
- Press the power button for 2 seconds to turn lamp off.

- Pull the plastic sheet under the bottom of remote controller before using remote function.

## Cleaning Instructions

Wipe acrylic with a clean soft cloth. Do not use abrasive cleaners as will damage surface.

## Documents / Resources

	<a href="#">Wikipedia Remote Controller</a> [pdf] User Guide Remote Controller, Remote, Controller
-----------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.