




WIMIUS P62 Projector with WiFi 6 and Bluetooth 5.2 User Manual

[Home](#) » [Wimius](#) » WIMIUS P62 Projector with WiFi 6 and Bluetooth 5.2 User Manual 

WIMIUS

P62 Projector with WiFi 6 and Bluetooth 5.2
User Manual



Contents

- 1 P62 Projector with WiFi 6 and Bluetooth 5.2
- 2 Safety Precautions
- 3 Accessories
- 4 Product Overview
- 5 How to clean the Black Spots?
- 6 Specifications
- 7 Operating Instructions
- 8 Other Connections
- 9 Main Menu Function
- 10 FAQ
- 11 Documents / Resources
 - 11.1 References

P62 Projector with WiFi 6 and Bluetooth 5.2

Thank you for your purchase with WiMiUS P62 video projector. Please read this manual carefully before using the projector.

If you have questions about the projector, please contact us at support01@wimius.com

We sincerely hope this projector can make your life more colorful.

Warnings

High brightness lamp! Don't look straight into the lens when the projector is on.










Safety Precautions

1. Clean When clean this projector, please pull out the power cable. Use a wet cloth to clean, don't use any detergent that may damage the unit.
2. Accessory Please use our recommended accessory. Or it will damage the projector.
3. Correct environment
Do not place the projector in a wet environment, like damp basement or near the swimming pool, etc.
4. Ventilation
The ventilation is equipped for the projector to work stably. Do not put anything around the vents. Or it will cause the projector heating up. To ensure the stability of heat dissipation, please open the height bracket in the bottom of the projector before starting.
5. Power Please make sure the power is within the required power range.
6. Thunder For thunder day, please unplug the power cable from the projector.
7. Repair Due to high voltage inside, please do not open or try to repair the projector by yourself. Please ask a professional technician to repair the projector.
8. Keep away from heat device Please make sure the projector is far away from any heat devices which will damage the projector.

Accessories


- Projector x 1
- Projector Case x 1
- Remote Control x 1
- Power Cable x 1



- AV Cable X 1
- HDMI Cable X 1
- Lens Cover x 1
- Cleaning Kit X 1
- User Manual x 1

 Projector x 1			
 Remote Control x 1	 Power Cable x 1	 AV Cable x 1	 HDMI Cable x 1
 Lens Cover x 1	 Cleaning Kit x 1	 User Manual x 1	 Projector Bag x 1


Product Overview

Projector can input high-definition video signal and composite video signal, and support stereo audio signal input and output. Please refer to the following figure to connect the projector and other audio equipment according to your own needs.






Note: For Ceiling mount, please slowly remove the 4 black rubbers, then you can find the holes for ceiling mount. The screw size is M5*12mm.




How to clean the Black Spots?

Open the dusting mouth cover rotation with a screwdriver.




Method 1

Extort yourself to flap the body of projector.




Method 2

Use the cold wind to blow the dusting mouth.



Remote Control



1. Signal indicator light
2. Power
3. Signal source
4. Arrow keys
5. Menu
6. Auto focus and keystone correction
7. Volume +
8. Volume
9. Mute
10. Homepage
11. Confirm key
12. Return key
13. Manual focusing +
14. Manual focusing

Note: Batteries are not supplied in the package, you must purchase two additional AAA batteries by yourself. To avoid battery leakage corrosion, please take the batteries out if not use it for a long time.

Specifications

Model No.: P62			
Imaging System	LCD	Power	AC100-240V/50-60Hz
Light Source	LED	Dimension	25.7*20*10.3CM
Color	16.8M Full Color	Resolution	Native 19201080 Full HD
Projection Distance	1.5-7m	Input Interface	HDMI2/ VGA/AV/ USB2
Projection Size	50-300	Zoom Function	100%-50%
Aspect Ratio	16:9 / 4:3/ Auto	Output Interface	AUDIO OUT
Keystone Correction	Auto/Manual	Focus	Auto/Manual

Projection Size Chart

Distance	Screen Size	Distance	Screen Size
1.5m	35°	3.9m	120
1.7m	50	5.5m	180°
2.4m	72	7.0m	300
3.3m	100		

Please refer to the following table to adjust your picture size and distance.

Optimum projection distance: 3m


Please allow $\pm 3\%$ to the image sizes in the table above. If the distance is less than min data and more than max data, the image could be blurry.

Operating Instructions

- To get a better watching, please use this projector while drawing the curtain or in a dark room.
- Please use the projector carefully, dropping or crashing may damage parts or result in blurred images and abnormal displaying.


Getting Started

- Remove the lens cap, connect the projector with the power through power supply cable, it starts work.
- Then boot screen appears, like the picture.




- **Focus and Auto Keystone Correction**


(1) Auto Focus and Keystone Correction.

Please place the projector horizontally face to wall first, turn on and then it will automatically focus the picture based on the projection distance from the screen and adjust the picture to a rectangle. Or press " "  : "Auto focus and keystone correction key directly.

If the picture is blurry, press the focus button "F+" "F-" on the remote control to adjust the lens focus, tap or long press the adjustment button until the picture is clear.



(2)How to Use Projection Settings


Select the settings icon in the upper right corner  of the main interface, and then press the "OK" key on the remote control to enter the settings interface and select "Projection Image Setting". After entering the interface, select the mode you want in the projection settings, then adjust the keystone as you want.



- **Manual Keystone**

After going into 'Manual Keystone 'you can set 4-point Keystone's your need: Horizontal Value ± 96 , Vertical Value from ± 54

Just click "OK button to pick the point you want adjust at first, and then press the button "  "or"  to set the value needed as shown below.



- Digital Zoom

With the zoom value at 100%-50%, Just click OK button enter, and then press the button 'A' or 'y' to set the value needed as shown below. (Note: The zoom value will be affected by the value of four-point keystone correction)

- Correction setting


Trapezoidal Correction Reset: Press "OK" the image will restore to the original keystone correction settings.



Connect input devices and then choose signal source button to choose corresponding signal source (HDMI, HDMI2, AV, etc)

For the USB devices, no need to choose the signal source. The machine will detect them automatically.

Just operate through the remote control: Press '@' and then press "◀▶" or "▲▼" to choose the corresponding signal input channel, then press OK to confirm.



Connecting with Smartphones and iPad

Note: This projector support only Wireless Connection, wired connection is not possible.

PS: The fluency of screen mirroring with wireless connection will be affected by the network environment. A

bandwidth of 100Mbit or more is recommended when using screen mirroring. Make sure your mobile device is closed to the projector when using wireless connection. A distance within 1 meter is recommended.


How to Use WiFi Settings


Select the settings icon in the upper right corner of the main interface, and then press the “OK” key on the remote control to enter the settings interface and select “WiFi Setting”.

For IOS System

Setting with Home Wi-Fi

Attention: Your device and the projector should be in the same Home WiFi.


1. Turn on the WiFi Setting of projector.
2. Choose your Home WiFi to connect and enter the right password, then click “Done” to Connect, please wait 3-5 seconds to establish the connection. Once connected, it will remember the password of the connected WiFi.
3. Turn on the WiFi setting of your iOS device, then connect it the same Home WiFi as the projector.
4. Then click iOS Cast'  as the Input Source of your projector.
5. Swipe up the screen of your iOS mobile device and tap “Airplay” to search for the projector, then select “WiMiUS P62Projector” from the searching results to connect.
6. Succeed.



For Android System

To activate this function, your android device must support Multi-Screen/ Wireless Display. Name of “Multi-Screen” may vary depending on various brands of Android devices.

Method 1: Setting with mobile internet


1. Turn on the projector, select “Miracast”  as the Input Source.
2. Turn on the “Multi-Screen/Wireless Display of your Android device.
3. Select “WiMiUS-P62Projector” from the searching results to connect.
4. Succeed.



Connecting with Bluetooth Speaker

1. Turn on your Bluetooth Speaker.

2. Turn on the Bluetooth Setting of your projector.
3. Select your Bluetooth speaker to connect.
4. Succeed.



Compatible with Bluetooth speakers, Bluetooth Headphones, iPhone Airpods, Bluetooth Earbuds, Bluetooth Earphones.

Other Connections

Supported multimedia playback formats

Picture Format	JPG, PNG, BMP, JPEG
Audio Format	MP3, AAC, WAV, WMA, M4A, OGG, FLAC
Video Format	MP4, MKV, WMV, 3GP MPG, TP, TS, F4V, DAT, FLV, TRP
File Format	TXT, EXCEL, WORD, PPTX

1. Connecting with PC

- Connect projector with PC by HDMI cable.
- Choose the media signal channel : "HDMI"

2. USB Multimedia Connecting

For the USB devices, no need to choose the signal source. The machine will detect them automatically.

- Select the required category 'movie', 'music', 'photo' or 'Office Suite' in the main interface, and press the "OK" key on the remote control to enter the corresponding category.
- According to the programs to choose : 'photos music "movie" or "Office Suite'.
- Choose the file you want to play, press the key "OK" to play or pause the file. (You cannot enter the required category without connecting a USB disk.)
- Note: For the "Office Suite" option. you can play, demo PPT files.

3. Connecting with MacBook or Mac Book Air

- Choose the media signal channel : "HDMI"
- Use a Type-C to HDMI adapter to connect your MacBook, or a Mini Display to HDMI adapter to connect with your MacBook Air (adapter not included).


4. Connecting with Sound bar

- Use the 3.5mm audio cable coming with the projector to connect with sound bar.
- Turn on the projector and the sound bar, select [AV] as the signal source

- More details, please contact seller at support01@lwimius.com.

5. Connecting with DVD

- Use the 3-in-1 AV cable. connect the colorful female connectors to your DVD player's RCA cable.
- Connect the black connector to the AV port of the projector, enter the home page to select [AV I as the signal source.



6. Connecting with fire TV Stick



- Plug the TV stick into HDMI port of the projector.
- Choose the media signal channel :HDMf
- P.S: It only supports 1080P TV stick. not 4K TV stick.


7. Connecting with XBOX/PS4

- Choose the media signal channel :HDMI
- Use HDMI cable connect to XBOX/PS4

Main Menu Function

1. Picture Mode


Only when you play the video, you can set the “Picture Mode”. Press “” and then select the setting  on the remote control to make some personal settings.



Menu	Menu included	16:9/4:3/Auto/Full
Picture Mode	User/Standard/ vivid/sport/ Movie/Game/Energy Saving	To adjust the Brightness/ Contrast/ Saturation/ Sharpness” of the image
Color Temperature	User/Cool/Standard/ warm	To adjust Red/Blue/Green gain
Display Mode	16:9/4:3/Auto/Full	To adjust Aspect ratio


Sound Mode

Only when you play the video, you can set the Sound Mode’.




Sound Mode	Menu included	Function
Sound Mode	User/Standard/ Vivid/Sport/ Movie/Music/News	Adjust the mode of sound
Equalizer Detail	120/500/1.5K/5K/10K Hz	Adjust the tone

Projection Image setting 




Projection	Menu included	Function
Projection Mode	Front-Desktop / Rear-Desktop / Front-Ceiling / Rear-Ceiling	Choose the projection methods,flip the image
Manual Keystone	4-point Keystone correction	Adjust 4 corners of the projection image
Digital Zoom	Reduce Display 100%-50%	Reduce the size of image size
Correction Setting	Trapezoidal Correction Reset	Auto trapezoidal correction
	Power on Auto Keystone correction	On/off
	Power on Auto Focus	On/off

System Update



System Update	Menu included	Function
Picture Mode	User/Standard/Vivid/Sport/ Movie/ Game/Energy Saving	To adjust the °Brightness/Contrast/ Saturation/Sharpnessof the image
Color Temperature	User/Cool/Standard/Warm	To adjust Red/Blue/Green gain
Display Mode	16:9/4:3/Auto/Full	To adjust Aspect ratio

other setting



Other Setting	Menu included	Function
Boot Source Option	HDMI 1/HDMI2/AV/OFF	Default signal source of Power on
Power On Option	Direct/Standby	Choose the mode of Power On
Language Setting	English, French, German, Italian, S panish, Japanese.20 several langu ages	Choose a language
Scheduled Shutdown	OFF/10min/20min/30min/60min/ 120min	Set the sleep time of the projector

About(system Info)



FAQ

Can't play video in App Netflix, Hulu

Those APPs are limited with HDCP. This model doesn't support this function. So it can't support these APPs.

Indicator light is off when plug into power supply

1) The power cable not connected well. 2) The power button on the back of the projector is off.

Press the power button on the remote control and the projector does not turn on

1) The remote control's batteries are depleted. 2) Something obstructing the signal between the remote and IR. 3) strong light on IR directly.

Picture right, no sound

1) Input cables connected right? 2) volume at minimum or on Mute? 3) Turn off the dolby of the input devices.

It will shut off automatically after turn on for a while

1) Is there a barrier around the ventilation? 2) Low voltage or big voltage fluctuations. 3) Check the over-heat protection system.

Can't find devices when connected with hard drive or flash drive?

1) Re-plug the device. 2) Check if the device is broken.

Can't play the movies

1) The format of the video is right? 2) Files are broken? 3) Device is broken?

Not compatible with your bluetooth speaker?

1) The projector may not compatible with some version bluetooth speaker of JBL. 2)Contact our after-sales service support01@wimius.com immediately and tell us the version of your bluetooth speaker.

Black spot on the picture

Contact seller for a video to remove them.

Contact us:

✉ Email: support01@wimius.com


🌐 Website: www.wimius.com



Enjoy Every Moment

✉ supporto@wimius.com

Documents / Resources

	<p>WIMIUS P62 Projector with WiFi 6 and Bluetooth 5.2 [pdf] User Manual</p> <p>P62 Projector with WiFi 6 and Bluetooth 5.2, P62, Projector with WiFi 6 and Bluetooth 5.2, WiFi 6 and Bluetooth 5.2, Bluetooth 5.2</p>
---	---

References

- [User Manual](#)