



## WINGS Phantom 550 Earbuds With Low Latency Game Mode User Manual

[Home](#) » [WINGS](#) » WINGS Phantom 550 Earbuds With Low Latency Game Mode User Manual 

WINGS Phantom 550 Earbuds With Low Latency Game Mode User Manual



## Contents

- 1 INTRODUCTION
- 2 WHAT'S IN THE BOX
- 3 PRODUCT LAYOUT
- 4 HOW TO PAIR
- 5 TAP CONTROL USAGE
- 6 CALL CONTROLS
- 7 CHARGING THE CASE
- 8 RESETTING THE DEVICE
- 9 TECHNICAL SPECIFICATIONS
- 10 SAFETY AND MAINTENANCE
- 11 Documents / Resources
- 12 Related Posts

## INTRODUCTION

### BE THE SICKEST IN THE GAME !


It's not just a tagline , it's who we are . Esports and Gaming has truly arrived in India and at Wings, we celebrate the modern Indian gamer with products that reflect the some drive and finesse that goes into the sport. We are a community of passionate of gaming enthusiasts with the highest standards and the ambition to be the best. It is the some passion with which we add style and performance to every Wings product so you can elevate your game and enjoy the rush of that perfect headshot.

But more than anything – We are PROUD to be gamers. Just like you.  
Let's Go!

## WHAT'S IN THE BOX



## PRODUCT LAYOUT




1. CHARGING CASE
2. TYPE-C INPUT
3. CASE LIGHTS
4. TOUCH SENSOR
5. MICROPHONE

## HOW TO PAIR

Before queue-ing up with your squad, Pair up with us to ensure maximum victories. Please make sure that the device is fully charged before using it

**Step 1:** Make sure your charging case is powered up. Simply open the lid of the charging case, the earbuds will turn ON and will automatically enter the pairing mode.

**Step 2:** Tap "Phantom 550" from the smartphone's Bluetooth menu. There is a voice prompt after successful connection. This indicates earbuds are successfully connected to your device.



**Step 3:** Congratulations! You are now connected and can start playing media.

**Note:** In case you do not connect to any device within 180 seconds of entering pairing mode, then both earbuds will automatically turn OFF. Please put the earbuds back into the case and repeat the process to pair.

## **TAP CONTROL USAGE**

For better access and functionality during matches, use our tap controls to save on those crucial moments between games.

**Play/Pause:** Double Tap the sensor on any one earbud to pause music. Double tap on any sensor again, on any one earbud to resume playing music.

**Changing Songs:** Triple Tap on the right earbud to go to next song. Triple Tap on the left earbud to go to previous song.

**Adjusting Volume:** Single Tap on the right earbud to increase Volume. Single Tap on left earbud to decrease Volume.

**Siri/Google Assistant:** Long Press for 2 seconds on left earbud to activate voice assistant.

**Gaming Mode:** Long press for 2 seconds on the right earbud to turn Gaming mode ON, The earbuds will do a breathing light effect .Long press for 2 sec on the right earbud again to turn Gaming Mode OFF.

**Changing EQ:** Tap 4 times on the touch sensor of any earbuds to switch between the EQ's.

## **CALL CONTROLS**

Use our Call control features to make swift decisions in game and clutch up without breaking your focus.

**Answer Incoming Call:** Double Tap the sensor on any earbud to answer an incoming call.

**Hang up Ongoing call:** While on call, Double Tap the sensor on any earbud to hang up the call.

**Reject Incoming Call:** Long press the touch sensor on any earbud for 2 seconds to reject incoming call.



## CHARGING THE CASE

Our Charging Speed makes sure to leave your enemies in the dust! So Charge up and get going!!

**Note:** Please only use a 5V/1A adapter to charge the case as higher voltage adapters can destroy the battery of the case and earbuds.

**Charging the Case:** When charging the case, the charging indicator lights on the case will do a blinking effect.

**Fully Charged:** When the case is completely charged, the case light will stay steady ON.

## CHARGING THE EARBUDS

Tired from defeating your rivals? Well our earbuds need a quick break too before they are back on the field with you.

**Note:** Please peel off the protective film on the earbuds charging points before charging the earbuds.

**Earbuds Charging:** When earbuds are placed inside the charging case, the lights on the earbuds will turn ON indicating that the earbuds are being charged.

**Earbuds Completely Charged:** When the earbuds are completely charged, the lights on the earbuds will go OFF.

## RESETTING THE DEVICE

On the rare occasion you might need to reset the earbuds, here's a quick guide after which you can get back into the grind! Please follow the below steps when you see 2 "Phantom 550" in your Bluetooth device menu on your mobile or you can hear music through only 1 earbud. This means the left and right earbuds have not auto paired with each other:

**Step 1:** Disconnect the earbuds and remove "Phantom 550" from the list of paired devices on your mobile.

**Step 2:** Tap the sensor on either of the earbuds for 5 times quickly to clear the pairing data, the LED on both the earbuds will turn ON and then OFF after 3 seconds.

**Step 3:** Put them back into the charging case, and “Phantom 550” is ready to use as it automatically turns on and pairs again.

The Reset process is now complete and you will be able to hear music through both earbuds.

## TECHNICAL SPECIFICATIONS

For all the tech geeks and audiophiles, here's a full set of . specs for you to brag about with your fellow tribe.

### PARAMETERS VALUES

**Bluetooth Version:** V5.3

**Effective Distance:** 15M

**Impedance:** 320

**Product Weight:** 44g

**Speaker Size:** 13mm

**Total Play Time:** About 45 Hours

**Eorbuds Play Time:** About 10 Hours

**Talk Time:** About 40 Hours

**Standby Time:** About 300 Hours

**Complete Charging Time:** 1.5 Hours

**Eorbuds Charing Time:** 1 Hour

**Rated Input:** 5V/1A

**Frequency:** 20Hz– 20KHz

**Sweat and Water Resistant:** IPXS

**Charging Port:** Type-C

## SAFETY AND MAINTENANCE

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Gamers need to hydrate after a long match. That is not the case with our earphones, so, Keep the product dry, do not put it in humid conditions to avoid a short circuit.
- We understand you carry the fire of a gamer within you, but please, Do not expose it to the peak sun or high heat for extended periods of time as this will shorten lifespan of electronic components, damage battery and deform some plastic parts.
- You may be Captain Cool leader of your squad but our products work best without a cold environment, so, Do not put it in cold circumstances to avoid damage to the KB board.
- We know you are tech geeks and can build your own gaming PC from scratch, but, Do not attempt to dismantle the product, as it may be unsafe especially for non-professionals.
- Gamers are tough and our earphones are tougher, but please Do not use chemical products, detergent, oily liquids to clean the item.
- In game, the bullets and knives are the norm however, Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- We understand your passion for power, but in this case, Less is More, so, Do not charge the product for more than 5 hours to avoid loss in battery life.
- Being immersed in the game is one thing, yet Avoid hearing music at maximum volume for long periods as this can affect our hearing and is not advisable.

## Documents / Resources



[WINGS Phantom 550 Earbuds With Low Latency Game Mode](#) [pdf] User Manual  
Phantom 550 Earbuds With Low Latency Game Mode, Phantom 550, Earbuds With Low Latency Game Mode, Low Latency Game Mode, Latency Game Mode, Game Mode, Mode