



Wise Memory Card Reader User Guide

[Home](#) » [Wise](#) » Wise Memory Card Reader User Guide

Wise Memory Card Reader



Contents [[hide](#)]

- [1 Components](#)
- [2 How to connect](#)
- [3 Tech Specs](#)
- [4 Caution](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Components

- Wise Dual SD UHS-II Card Reader
- USB 3.2 Gen 2 Type C to C Cable

- Quick Start Guide

How to connect

Use the Wise USB cable included with your device.

Connect one end of the cable to the device and the other end to the card reader.

Tech Specs

Model	WA-DSD05
Interface	USB 3.2 Gen 2
Maximum read ¹	10 Gbps
Size	65.5 x 70 x 20 mm
Weight	55 g

¹ Speeds based on internal testing. Actual performance may vary.

Caution

- Wise shall not be responsible for any damage to or loss of recorded data.
- Transferred data may be damaged or lost in the following situations.
 - If you eject this device while formatting, reading or writing data.
 - If you use this device in locations subject to static electricity or electrical noise.
- Connecting the Wise Dual SD UHS-II card readers to non-compatible devices may result in unexpected interference or malfunction of both products.
- Do not touch the terminal with your hand or any metal object.
- Do not expose the unit to rain or moisture.
- All Wise memory card readers have a 2-year warranty. If you register your product here online, you can extend it to 3 years at no additional charge: www.wise-advanced.com.tw/we.html
- Any damage caused by customers through neglect or incorrect operation may result in the warranty being void.
- For more information, please visit www.wise-advanced.com.tw



Documents / Resources

References

- **W Wise Advanced**
- **W Wise Advanced**