

Wise RD-40 Series Card Reader Instructions

Home » Wise » Wise RD-40 Series Card Reader Instructions





RD-40 Series

Contents

- 1 How to Use Wise Card Reader
- 2 Tech Specs
- 3 Documents / Resources
 - 3.1 References

How to Use Wise Card Reader

Before operating this media, please read this manual thoroughly, and retain it for future reference.

Components

- · Wise Card Reader
- USB-C to C Cable (40 Gbps)

How to connect

Use the Wise USB cable included with your device.

Connect one end of the cable to the device and the other end to the card reader.

Tech Specs

Model	RD-40CXA	RD-40CXB
Max Transfer Speed1	40 Gbps	
Media Type	CFexpress Type A	CFexpress Type B
Interface	USB4	
Port	USB Type-C	
Size	69.8 x 62 x 21 mm	
Weight	108 g (0.24 lbs)	

1 Speeds based on internal testing. Actual performance may vary.

Caution

- Wise shall not be responsible for any damage to or loss of recorded data.
- Transferred data may be damaged or lost in the following situations.
 - If you eject this device while formatting, reading or writing data.
 - If you use this device in locations subject to static electricity or electrical noise.
- Connecting Wise card reader to non-compatible devices may result in unexpected interference or malfunction of both products.
- Do not touch the terminal with your hand or any metal object.
- Do not expose the unit to rain or moisture.
- All Wise memory card readers have a 2-year warranty. If you register your product here online, you can extend
 it to 3 years at no additional charge: www.wise-advanced.com.tw/we.html
- Any damage caused by customers through neglect or incorrect operation may result in the warranty being void.
- For more information, please visit www.wise-advanced.com.tw

Wise Advanced is an authorized licensee of the CFexpress trademark, which may be registered in various jurisdictions. Information, products, and/or specifications are subject to change without notice. The Wise logo is a trademark of Wise Advanced Co., Ltd.



© 2024 Wise Advanced Co., Ltd. All rights reserved.

Design and contents of this manual are subject to change without notice

All other trademarks are property of their respective owners.

Documents / Resources



<u>Wise RD-40 Series Card Reader</u> [pdf] Instructions RD-40CXA, RD-40CXB, RD-40 Series Card Reader, RD-40 Series, Card Reader, Reader

References

- W Wise Advanced
- W Wise Advanced
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.