

# **WIZCHARK LC0092 9 Inch Lighted Mirror Instruction Manual**

Home » WIZCHARK » WIZCHARK LC0092 9 Inch Lighted Mirror Instruction Manual

#### **Contents**

- 1 WIZCHARK LC0092 9 Inch Lighted
- **Mirror**
- **2 FEATURED**
- **3 How to Maintenance the mirror**
- **4 Components**
- **5 Specifications:**
- 6 How to use
- 7 Charging the Battery
- **8 Safety Precautions**
- 9 Documents / Resources
  - 9.1 References
- **10 Related Posts**

## **WIZCHARK**

**WIZCHARK LC0092 9 Inch Lighted Mirror** 



#### **FEATURED**









**How to Maintenance the mirror** 

- 1. Please ensure the power is turned off when you clean the mirror.
- 2. Please do not immerse the product in water when you clean the mirror.
- 3. Please use a cleaning cloth to clean the mirror.
- 4. Please do not use alcohol to wipe the mirror.

## Warning

- 1. Please avoid putting the product under the sunlight.
- 2. Please clean the mirror regularly to extend the service life.
- 3. Please use the original USB cable when recharging the battery.



Attachments: 1 X Type C Charging Cable

Notice: Adaptor is not included

**Attachments:** 1 X Type C Charging Cable

Notice: Adaptor is not included

## **Components**



## **Specifications:**

• Material: Metal+Glass

• Glass Mirror Diameter: 7 inches

• Charging Time: 4Hours


Color Temperature: 3100K-6400K
Built-in Battery Capacity: 2000mAh


• **LED**: 60PCS

Working Time: 3-5 HoursMagnification: 1X/10X

#### How to use

Fully charge the mirror before the first use.





to adjust the brightness.

## **Charging the Battery**

- Plug the end of the cable into the charging port on the mirror.
- Plug the end of the cable into a USB adapter, power bank, or computer.

• When the mirror begins to charge, the power light will turn on. A red light indicates that the battery is currently charging and a green light indicates that the charging is complete.

## **Safety Precautions**

- 1. When charging, please use an adapter with a rated output, of 5V=2A; an inappropriate adapter may cause product damage
- 2. During the use of the product, if the light wobbles or becomes abnormal, please try to charge it ASAP; if the abnormal phenomenon does not improve after charging, please stop using it immediately.
- 3. Please do not use it in unstable places(such as easy-to-fall or easy-to-dump places).
- 4. It is strictly forbidden to put the product close to or throw it into a fire source to avoid the risk of fire and explosion.
- 5. Please do not use it in the bathroom or any other wet conditions; this product is not specially waterproof.

#### **Documents / Resources**



<u>WIZCHARK LC0092 9 Inch Lighted Mirror</u> [pdf] Instruction Manual LC0092 9 Inch Lighted Mirror, LC0092, 9 Inch Lighted Mirror, Lighted Mirror, Mirror

#### References

• User Manual

Manuals+, Privacy Policy