



WOLFVISION VZ-3neo.UHD Document Camera User Guide

[Home](#) » [WOLFVISION](#) » WOLFVISION VZ-3neo.UHD Document Camera User Guide 

Contents

1 WOLFVISION VZ-3neo.UHD Document Camera User Guide

1.1 First Steps

1.1.1 Before Starting

1.1.2 Power Key

1.1.3 Basic Menu Settings

1.1.4 Accessories

1.1.5 Authentication – Password Protection

2 Documents / Resources

2.1 References

3 Related Posts

WOLFVISION VZ-3neo.UHD Document Camera User Guide





VZ-3neo.UHD / VZ-8neo.UHD Quick Start Guide

First Steps



Before Starting

When using the version with the Swivel feature, mount the Visualizer onto a table top according to the mounting instructions first.

Fold the arm down and remove the cable cover.

Connect the power supply and establish all needed cable connections. Fix all cables by mounting the supplied cable holder (Torx 10). Note thickness of used cables.

Raise the arm up and the Visualizer will start automatically.



Power Key



The Visualizer will be switched on and off by moving the arm up and down. Additionally, the Visualizer can be switched on and off by pressing the POWER key on the camera head quickly.

Basic Menu Settings



When the Visualizer is switched on for the first time, basic settings should be performed by accessing the on-screen menu (gear symbol). Use the built-in touch screen to navigate through the menu.

Some of the most important settings are :

Ethernet Settings

Setup the network interface according your infrastructure.

Time Settings

Set time and date.

Manuals, Firmware, Apps, Software, Dimension Drawings,... @ www.wolfvision.com /SUPPORT

Accessories

The Visualizer can be equipped with an infrared remote control, a lightbox, and with dry-erase working surfaces

for quick annotations during a presentation.

This Visualizer is not automatically supplied with a remote control. If you wish to use the remote control, please check our homepage, or use the direct link <https://bit.ly/3RoAH9l> for further details.*

For dry-erase working surfaces, lightboxes, and other accessories, please contact your WolfVision dealer.

** for VZ-8neo.UHD only*

Authentication – Password Protection

The built-in touch screen and the web-interface of the Visualizer can be accessed without any credentials.

System relevant topics in the settings of the on-screen menu are password protected.

The default password of the accounts is: “Password” (case sensitive). In case you change this password, we recommend to write them down below:

In case the user-defined administrator password is lost, please contact your WolfVision dealer or WolfVision support.



www.wolfvision.com/green



Manufacturer / Worldwide Distribution

WolfVision GmbH

A-6833 Klaus

AUSTRIA

www.wolfvision.com

E-Mail: wolfvision@wolfvision.com / support@wolfvision.com

International Distribution Offices

USA

WolfVision Inc.

E-Mail: sales@wolfvision.us / support@wolfvision.us

Asia

WolfVision Pte Ltd

E-mail: wolfvision.asia@wolfvision.net

Middle East

WolfVision Representation Office Middle East

E-Mail: wolfvision.mideast@wolfvision.com

Germany

WolfVision Germany

E-mail: wolfvision.deutschland@wolfvision.com

Northern Europe

WolfVision Nordic

E-mail: wolfvision.nordic@wolfvision.net

Japan

WolfVision Co. Ltd.

E-mail: wolfvision.japan@wolfvision.com

United Kingdom

WolfVision UK Ltd.

E-Mail: wolfvision.uk@wolfvision.com

Printed in Austria – August 2021

Documents / Resources

	WOLFVISION VZ-3neo.UHD Document Camera [pdf] User Guide VZ-3neo.UHD, VZ-8neo.UHD, VZ-3neo.UHD Document Camera, VZ-3neo.UHD, Document Camera, Camera
---	--

References

-  [Presentation, Collaboration & Visualizer Systems - WolfVision GmbH](#)
-  [Naturally Green: Innovation, quality & sustainability - WolfVision GmbH](#)
-  [Remote Controls: Free-of-charge option - WolfVision GmbH](#)