



Woox R4294 Smart Universal IR remote User Guide

[Home](#) » [woox](#) » Woox R4294 Smart Universal IR remote User Guide 



WOOX

Smart Universal IR remote
R4294
Quick Start Guide





Contents

- 1 R4294 Smart Universal IR remote
- 2 Description
- 3 Use
- 4 Safety
- 5 Cleaning and maintenance
- 6 Support
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

R4294 Smart Universal IR remote



Description

1. Reset button
2. USB port (Micro USB)
3. Status indicator LED

Use

1. Download and install the app “WOOX Home” from Apple App Store or Google Play Store on your mobile device.
2. Launch the app “WOOX Home”.
3. Create a new account or log in to your existing account.
4. Tap “+” to add the device.
5. Select the applicable product type from the list of products.
6. Use the USB cable to connect your power adapter to the device. Insert the mains plug of the power adapter into the wall socket.
7. If the status indicator does not flash: Press and hold the reset button for 6 seconds.
If the status indicator flashes: Confirm in the app.
8. Confirm the Wi-Fi network and password.
9. Enter the device name.

Note: The device name will also be used by Amazon Alexa and Google Home.

Safety



- To reduce risk of electric shock, this product should only be opened by an authorized technician when service is required.
- Disconnect the product from the mains and other equipment if a problem should occur.
- Read the manual carefully before use. Keep the manual for future reference.
- Only use the device for its intended purposes. Do not use the device for other purposes than described in the manual.
- Do not use the device if any part is damaged or defective. If the device is damaged or defective, replace the device immediately.
- The device is suitable for indoor use only. Do not use the device outdoors.
- Do not expose the product to water or moisture.
- Do not touch the device with wet hands.

Cleaning and maintenance

Warning!


- Do not use cleaning solvents or abrasives.

- Do not clean the inside of the device.
- Do not attempt to repair the device. If the device does not operate correctly, replace it with a new device.
- Clean the outside of the device using a soft, damp cloth.

Support

If you need further help or have comments or suggestions please visit www.wooxhome.com

Documents / Resources

	<p>Woox R4294 Smart Universal IR remote [pdf] User Guide</p> <p>R4294 Smart Universal IR remote, R4294, Smart Universal IR remote, Universal IR remote</p>
---	--

References

-  [Connecting your home to a smarter future; WOOX Home](#)