



wopet FT70 Castle Automatic Feeder User Guide

[Home](#) » [WOPET](#) » wopet FT70 Castle Automatic Feeder User Guide 



QUICK OPERATION GUIDE
Castle Automatic Feeder




Model: FT70 & FT70 Plus

Contents


- 1 DISPLAY OVERVIEW:
- 2 BUTTONS OVERVIEW:
- 3 SCREEN PANEL
- INTRODUCTION:
- 4 INSTRUCTION MANUAL:
- 5 Documents / Resources
- 5.1 References







DISPLAY OVERVIEW:








BUTTONS OVERVIEW:

NOTE:

Will lock automatically after 2 min of inactivity. Hold  for 2s to unlock.

Button	Description	Operable Mode Function
	Set /Save Unlock button	<ul style="list-style-type: none"> • Press to save and move to the next step. • Press and hold for 2s to lock/unlock other buttons and screen.
	Return / Cancel button	<ul style="list-style-type: none"> • Return to the previous step. • Return to interface after setting up.
	Number Increase button	<ul style="list-style-type: none"> • Press to increase the value.
	Number Decrease button	<ul style="list-style-type: none"> • Press to decrease the value.
	Manual button	[Must be Unlocked] Press to feed 1 portion.
	Recording button	<ul style="list-style-type: none"> • [Must be Unlocked] Hold for 3s and start recording after a beep is heard {max 10s}. • Recoding saved after a double beep is heard.

SCREEN PANEL INTRODUCTION:

ICON	Function of ICON
 Lock	<ul style="list-style-type: none"> • Locks automatically after 2 min of inactivity. • Hold  button for 2 seconds to unlock.
 Clock indicator	Flash Indicates: <ul style="list-style-type: none"> • Powered by adapter or battery. Note: when flashing, press  button to set up/ modify the current time.
02:25 Timing 【24-hours format】	<ul style="list-style-type: none"> • Local time.
1 2 3 4 5 6 Meal	<ul style="list-style-type: none"> • Number of meals.
 Battery Level	<ul style="list-style-type: none"> • Lights up when running on battery power. Turns red to indicate low battery.

INSTRUCTION MANUAL:

STEP 1 — Setting Current Time

Note:

Clock icon flashes when powered as shown in fig.(01).

[If Screen is Locked]

Press  and hold for 2s to unlock screen as shown in fig.(02).



fig.(01)




fig.(02)




TIP: Please note the conversion between 24-hour format and 12-hour format.
Example: 9:00AM = 9:00; 10:00PM = 22:00 More as below:


12-hour Clock 24-hour Clock Comparison Chart

00:00 (Midnight)	00:00 (Beginning of the day)
01:00AM	1:00
02:00AM	2:00
03:00AM	3:00
04:00AM	4:00
05:00AM	5:00
06:00AM	6:00
07:00AM	7:00
08:00AM	8:00
09:00AM	9:00
10:00AM	10:00
11:00AM	11:00
12:00AM (noon)	12:00
01:00PM	13:00
02:00PM	14:00
03:00PM	15:00
04:00PM	16:00
05:00PM	17:00
06:00PM	18:00
07:00PM	19:00
08:00PM	20:00
09:00PM	21:00
10:00PM	22:00
11:00PM	23:00
12:00PM (Midnight)	24:00 (End of the day)

STEP 1.1— HOUR SETTING





[Must be Unlocked]

Press  to set the “hour” of the time. The two hour digits flash, press / to set the “hour”.




STEP 1.2— MINUTE SETTING

[Must be Unlocked]

After setting hour, press  to move to set the “minute” of the time. press / to set the “minute”. Press  to save.


Note:

Press  to modify if needed.



STEP 2 —Setting Meal


STEP 2.1

Press  then “1” flashes to set up the first meal.



STEP 2.2

Press to set the “hour” of the time, Press / to set the “hour”. Press to move to set the “minute” of the time. Press to save.




STEP 2.3

Press / to set up portion then press button to save.

Note:


Press to modify if needed.



STEP 2.4

Press ⏸ to move to set other meals.

Repeat above step to set up meal time and portion.



STEP 3 —Return to Interface

STEP 3.1

Press ⏸ to return to interface when setting up as shown in fig.(01).

(Numbers NOT displayed when portion set to 0 as shown in fig.(02)).




fig.(01)






fig.(02)



STEP 3.2


Press  to modify local time, feeding time and portion if needed.



STEP 4 — Locking & Unlocking


Lock:

Press  to return to interface when setting up, press  for 2s to lock the screen, the lock icon will display.
(Note: Locks automatically after 2 min of inactivity).




Unlock:

Press and hold for 2s to unlock the  screen, the lock icon will disappear.




STEP 5 —Recording


[Must be Unlocked]


Hold  for 3s and start recording after a beep is heard (max 10s).

Double beep indicates recording is saved.






STEP 6 —Manual Feed
[Must be Unlocked]

Press  to feed 1 portion.




STEP 7 —Reset to Factory Default
[Must be Unlocked]

Press  and  hold and at the same time for 3s until a beep is heard.



Documents / Resources

	<p>wopet FT70 Castle Automatic Feeder [pdf] User Guide FT70 Castle Automatic Feeder, FT70, Castle Automatic Feeder, Automatic Feeder, Feeder</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.