

MANGATALITES LED LIGHT INFORMATION

For use in all MangataLites, SLING, PolarLites, RunLites, and CycleLites products.

PRODUCT & WARRANTY INFORMATION

Limited Warranty

The MangataLites product is guaranteed for 1 year from the date of purchase against manufacturing defects. This guarantee does not cover normal wear, damage caused by accident, unreasonable or incorrect use, product modification or any kind of battery leakage.

ATTENTION:

Please address all warranty correspondence to: Mangata, LLC.


416 Market Street, Lewisburg, PA 17837 USA

Phone: 570-428-2255

Info@gorunlites.com




Type	SH622533
Battery Capacity	530mAh
Input	300mA
Output	90mA(Low) 180mA(High)



The LED Unit comes pre-charged. Some of the battery May have been discharged during transit. CHARGE the LED units before first use. The LED will be fully charged when the RED Indicator light goes out.

POWER TEST: Perform test by pressing the Power button. The indicator Light will be off when the light is fully charged.



BATTERY STRENGTH TEST:


To check the strength of the battery in the LED units

Press and hold the POWER Button.

The LED lights will turn on, the numbers of lights indicate the battery strength remaining.
4 lights, there is approximately 75% battery life remaining.
3 lights, there is approximately 50% battery life remaining.
2 lights, there is approximately 25% battery life remaining.
1 light, there is less than 25% battery life remaining.

TO CHARGE:

A.Via **Wall Charger:** Use the provided USB Cable. Connect the Light Unit (Micro USB port) to AC Adapter With USB Port.




B. Via **Computer:** Use the provided USB Cable. Connect the Light Unit (Micro USB port) to the computer/LaptopUSB Port.

OPERATION GUIDE for LOW/HIGH MODE:

- Press the power button **one time** for **LOW** power
- Press the power button **two times** for **HIGH** power
- Press the power button **three times** for **OFF**.

INSERT THE LED UNIT INTO GLOVE/SLING POCKET



EXPERIENCING AN LED ISSUE?

- Make sure your LED units are charged before use. Often the unit's power is discharged in transit. Connect the provided cable to a power block, powered USB port, or vehicle USB to charge.
- A small RED indicator charging light will appear in the LED bar when the *unit* is charging. When charging is complete the red indicator light will turn off. UNPLUG WHEN FULLY CHARGED.
- If the LED unit is still not working, consider switching cables, repeat above process. The LED unit will charge on any micro (Android type) USB cable.
- If the LED still does not work, contact our Mangata LED Team for further assistance at customerservice@gorunlites.com

See our Demo video or additional information at www.mangatalites.com



WARNINGS:

LED's are extremely bright and direct exposure to eyes may cause injury.

Do not use this unit for anything other than its intended use.

Do not use this unit if it has been damaged or broken in any way.

This unit is not a toy.

Keep out of reach of small children. If they are swallowed, call your local poison control center or call 911.

Do not dispose of batteries in fire as they may explode or leak.

Remove LED unit before laundering Glove.

Battery Disposal:

This product contains a lithium ion battery. Lithium ion Batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.



Distributed by Mangata, LLC
Lewisburg, PA 17837 USA,
All Rights Reserved.
US and International patents pending. "Patent www.goRunLites.com/patents"
Made in China

MANGATALITES LUZ LED INFORMACIÓN

Para usar en todos los productos de MangataLites, SLING, PolarLites, RunLites y CycleLites.

INFORMACIÓN DEL PRODUCTO Y GARANTÍA

Garantía ilimitadas

La MangataLites producto es garantizado por un año a partir de la fecha de compra contra defectos de fabricaión. La garantía no cubre el desgaste normal, el daño causado por accidente, uso incorrecto o irrazonable, la modificación de los productos de cualquier tipo de fuga de la batería.

ATENCIÓN:

Por favor dirija toda la garantía la correspondencia a: Mangata, LLC.


416 Market Street, Lewisburg, PA 17837 USA

Phone: 570-428-2255

Info@gorunlites.com



Type	SH622533
Battery Capacity	530mAh
Input	300mA
Output	90mA(Low) 180mA(High)




Su unidad de Luz MangataLites, viene preparada. Algunas baterías pueden descargarse durante el transito.

CARGAR las unidades LED antes del primer uso.

El LED se cargará completamente cuando se apgue la luz indicadora ROJO.

PRUEBA DE POTENCIA: Pruebe la potencia apretando el botón. El indicador de Luz estada apagado cuando la luz esta totalmente cargada.



PRUEBA DE RESISTENCIA DE LA BATERÍA:

Para verificar la potencia de la batería en las unidades LED.

Mantenga presionado el botón de ENCENDIDO.

Las luces LED se encenderán, el número de luces encendidas indicará la restante de la batería.

4 luces, queda aproximadamente el 75% de la vida útil de la batería.

3 luces, queda aproximadamente el 50% de la vida útil de la batería.

2 luces, queda aproximadamente el 25% de la vida útil de la batería.

1 luz, queda menos del 25%.

PARA CARGAR:

A. **CARGADOR A PARED:** Use el cable USB, conectelo a la unidad del LED (micro USB port) al adaptador de corriente.




B. **VIA COMPUTADORA:** Use e cable USB que tiene, conecte la unidad de luz a la computadora o el lap top.

GUIA PARA OPERAR: corriente **BAJA/ALTA:**

- Precione el botón **una** vez para corriente **BAJA**
- Precione el botón **dos** veces para corriente **ALTA**
- Precione el botón **tres** veces para **APAGAR**.

INSERTE LA UNIDAD LED EN GUANTES/SLING BOLSILLOS

Vea el video que muestra información adicional en www.mangatalites.com



¿TIENE ALGUN PROBLEMA CON EL LED?

- Asegúrese de que ses unidades de LED estén cargadas antes de usarse. Con frecuencia la batería se descarge en uso. Conecte el cable a un enchufe, a un puerto USB, o al puerto USB de su vehículo para cargarlo.
- Un pequeño indicador ROJO aparecerá en la barra LED cuando la unidad se esté cargando. Cuando la carga estécompleta, la luz roja se apagará. RETIRE CUANDO COMPLETO.
- Si la unidad de LED todavía no funciona, considerecambiar los cables y repita toda el procesoanteriormente mencionado. La unidad de LED cargará en cualquier dispositivo micro (tipo Android) o cable USB.
- Si el LED sigue sin funcionar, contacte a nuestro equipo MangataLites LED para mayor asistencia al customerservice@gorunlites.com

Vea el video que muestra información adicional en www.mangatalites.com



ADVERTENCIA:

LA LUZ LED es extremadamente brillante, si no atiende la AVERTENCIA, podria causar dano a la vista.

No apunte la luz directamente a los ojos.

No use esa unidad para algo que sea indicado.

Esta unidad no es un juguete.

No deje que lo tengan los niños. Si llegaran a tragarlo, llame inmediatamente al departamento de venenos o al 911.

No descarte las baterías al fuego, porque pueden explotar.

Retire la unidad LED antes de lavar el guante o SLING.

COMO DESHACERSE DE LAS BATERIAS:

Estas bateris contienen Litio ION, el litio es seguro para el ambiente cuando las baterías están totalmente descargadas. Antes de botarlas averigüe las leyes de su estado para ese fin.



Distributed by Mangata, LLC

Lewisburg, PA 17837 USA,

All Rights Reserved.

US and International patents pending. "Patent www.goRunLites.com/patents"

Made in China