


Astroni



GL-0819

**DIGITAL
TIRE PRESSURE GAUGE
USER MANUAL**

INTRODUCTION

Thank you for purchasing the AstroAI 230 PSI Digital Tire Pressure Gauge.

We hope you enjoy your new tire pressure gauge!

If you have any questions or issues with your new product, you are welcome to contact us via **support@astroai.com**

We're happy to help!

Please fully read and understand this manual before using this product and keep this manual for future reference.

WARNING

Do not use this product for unintended purposes.

INSTRUCTIONS

1. Press the ON/UNIT/OFF Button to turn on the tire pressure gauge. The gauge will display "0.0" on its LCD Screen.
2. Place the gauge's nozzle on the tire valve you wish to measure. Press firmly to ensure a good seal and prevent air from leaking.
3. Hold the gauge on the valve until the pressure reading stabilizes. It should only take a second if the seal is good.
4. Remove the gauge to easily read the pressure reading.
5. To change units, simply press the ON/UNIT/OFF Button to rotate through the four available pressure units.
6. The tire pressure gauge will automatically turn off shortly after use. Manually turn off the gauge by pressing and holding the ON/UNIT/OFF Button for a few seconds.

CHANGING THE BATTERY

1. Locate the battery compartment on the back of the tire pressure gauge and remove the back cover.

2. Locate the 2 x AAA batteries. Remove them from their place and replace with new batteries.
3. Take special care to place the batteries with the correct polarity. Replace the back cover.

SPECIFICATIONS

Range: 0-230 PSI, 0-16 bar, 0-16 kg/cm², 0-1600 kPa

Display: LCD display

Power: 2 x AAA batteries

Operating Temperature Range: -5~50 °C/23~122 °F

HELPFUL HINTS

In order to get a strong seal, place the nozzle directly onto the tire valve. Putting the gauge on the nozzle from an angle may result in an inaccurate reading. Once the gauge is placed, firmly press the gauge straight down.

WARRANTY PERIOD

1-Year Limited Warranty from AstroAI.

Each AstroAI Digital Tire Pressure Gauge is free from defects in material and workmanship. This warranty does not cover damage from negligence, misuse, contamination, alteration, accident, or abnormal conditions of operation or handling. This warranty covers the original purchaser only and is not transferable.

AstroAI always wants to provide our customers with excellent products and customer service.

If you have any issues or concerns, feel free to contact us via **support@astroai.com**

AstroAI

Web: www.astroai.com

E-mail: support@astroai.com