


HUB FIRST USB-A/USB-C



4 IN 1

Manuel d'utilisation
User's Guide
Guida del usuario
Bedienungsanleitung
Gebruikershandleiding
Guida all'uso
Guia do utilizador



FR

Le HUB FIRST de Bluestork a un design unique, une petite taille et un poids de seulement 40 g grâce à sa structure en ABS.
Le HUB FIRST est facile à installer, ne nécessite aucun driver, il suffit de le brancher et il est prêt à l'emploi.

CARACTÉRISTIQUES TECHNIQUES:

Contenu	1 x HUB FIRST
Matériau	ABS
Poids net	40 g
Dimensions	107 x 34,5 x 11 mm
Vitesse de transfert	5Gbps
Intensité	0.5A (USB-A) 0.9A (USB-C)

CONNECTIVITÉ :

- ① 1 x USB-C
- ② 1 x adaptateur USB-A
- ③ 4 x USB-A 3.0

UTILISATION :

Branchez le câble USB-C sur le port USB-C de votre ordinateur.
Si votre ordinateur ne possède pas de port USB-C, utilisez l'adaptateur USB-C/USB-A et branchez-le sur votre ordinateur.
Branchez ensuite une clé USB, une souris, un clavier ou tout autre équipement sur l'une des prises USB.

EN

Bluestork's HUB FIRST has a unique design, a small size and a weight of just 40 g thanks to its ABS structure.
The HUB FIRST is easy to install, requires no driver, just plug it in and it's ready to use.

TECHNICAL FEATURES:

Package content	1 x HUB FIRST
Material	ABS
Net weight	40 g
Dimensions	107 x 34.5 x 11 mm
Transfer speed	5Gbps
Intensity	0.5A (USB-A) 0.9A (USB-C)

CONNECTIVITY:

- ① 1 x USB-C
- ② 1 x USB-A adapter
- ③ 4 x USB-A 3.0

USE:

Plug the USB-C cable into your computer's USB-C port.
If your computer doesn't have a USB-C port, use the USB-C/USB-A adapter and plug it into your computer.
Then connect a USB flash drive, mouse, keyboard or other equipment to one of the USB sockets.

ES

El HUB FIRST de Bluestork tiene un diseño único, es de tamaño reducido y pesa sólo 40 g gracias a su estructura de ABS.
El HUB FIRST es fácil de instalar, no requiere driver, simplemente conéctalo y está listo para usar.

ESPECIFICACIONES TÉCNICAS:

Contenido del paquete	1 x HUB FIRST
Material	ABS
Peso neto	40 g
Dimensiones	107 x 34.5 x 11 mm
Velocidad de transferencia	5Gbps
Intensidad	0.5A (USB-A) 0.9A (USB-C)

CONECTIVIDAD:

- ① 1 x USB-C
- ② 1 x adaptador USB-A
- ③ 4 x USB-A 3.0

USO:

Conecta el cable USB-C al puerto USB-C de tu ordenador.
Si tu ordenador no tiene puerto USB-C, utiliza el adaptador USB-C/USB-A y conéctalo al ordenador.
A continuación, conecta una memoria USB, un ratón, un teclado u otro equipo en una de las tomas USB.

IT

L'HUB FIRST di Bluestork ha un design unico, è di dimensioni ridotte e pesa solo 40 g grazie alla sua struttura in ABS.
L'HUB FIRST è facile da installare, non richiede driver, basta collegarlo ed è pronto all'uso.

SPECIFICHE TECNICHE:

Contenuto della confezione	1 x HUB FIRST
Materiale	ABS
Peso netto	40 g
Dimensioni	107 x 34.5 x 11 mm
Velocità di trasferimento	5Gbps
Intensità	0.5A (USB-A) 0.9A (USB-C)

CONNETTIVITÀ:

- ① 1 x USB-C
- ② 1 adattatore USB-A
- ③ 4 x USB-A 3.0

UTILIZZO:

Collegare il cavo USB-C alla porta USB-C del computer.
Se il computer non dispone di una porta USB-C, utilizzare l'adattatore USB-C/USB-A e collegarlo al computer.
Quindi collegare una chiavetta USB, un mouse, una tastiera o un altro dispositivo a una delle prese USB.

EN

BLUESTORK HUB FIRST ©2024

Made in China

Distributed by :

AXS - 1 Rue de la Garenne ZI Le Vert Galant

95310 SAINT OUEEN L'AUMONE - France

EU DECLARATION OF CONFORMITY

AXS declares under its sole responsibility as manufacturer that the product below :
HUB FIRST BLUESTORK EAN 3760162050950

Conforms to the following essential requirements and standards:

EU Directives	Conforms to
2014/53/EU – RED	EN 62368-1:2014+A11:2017 EN 62479:2010 EN 55032:2015+A11:2020 EN 55035:2017+A11:2020 EN 301 489-1 V2.2.3 EN 301 489-17 V3.2.4
2011/65/UE - RoHS with amendement 2015/863/UE	EN 300 328 V2.2.2 EN IEC 63000: 2018

Signed at SAINT OUEEN L'AUMONE, the 21 march 2024

By Stefan Riesser

President AXS



PRECAUTIONS:

Product safety instructions. Keep these safety instructions for future reference:

Read the safety and operating instructions carefully before operating this product.

Observe all warnings on the product and in the operating instructions.

Do not place this product in direct sunlight or near a heat source.

Do not use in a damp environment.

Do not drop or subject this product to shock/vibration. Violent shocks may damage components. Before cleaning an electrical product, switch it off and unplug it. Use a soft cloth to clean the product. Do not use liquid cleaners or glass cleaners.

If an unusual odor or heat escapes from this product, or if you notice any other sign of malfunction, immediately disconnect the product from the power supply and contact your dealer for inspection or repair.

If a foreign substance or water enters the product, immediately turn off the power and unplug the power cord. Then remove the foreign substance or water, if possible.

Do not disassemble or attempt to repair this product yourself:

Opening or removing the product exposes you to various risks, including electric shock.

Repairs should be carried out by a specialist. Send the product to your nearest service center.

Do not attempt to disassemble or modify this product. Unauthorized modifications will void the warranty.

If your product uses rechargeable batteries, please read the specific precautions below:

WARNING ON BATTERY-OPERATED PRODUCTS:

When handling batteries:

- Always keep batteries out of the reach of children. If swallowed, contact a doctor immediately.
- Do not charge batteries intended for single use (alkaline or saline). Charging non-rechargeable batteries causes gas and/or heat emissions which may lead to explosions and/or fires.
- Do not dispose of batteries in a fire. Do not touch the same poles of batteries.
- Do not deform, crush or puncture batteries. Do not disassemble batteries. Do not dispose of batteries with ordinary household waste. You may create a short-circuit if the positive and negative terminals come into contact. This can damage the battery and cause leakage.

WARNING ON RECHARGEABLE BATTERY PRODUCTS:

If the battery does not work properly within the warranty period, please send the product to your nearest service center to have the battery replaced. Do not attempt to replace the battery yourself.

WARNING: There is a danger of explosion if the battery is incorrectly replaced. Only replace the battery with the same or equivalent type recommended by the manufacturer. Batteries must not be exposed to excessive heat such as sunshine, fire or similar sources. Dispose of used batteries in accordance with the manufacturer's instructions.

WARNING: Use of non-original batteries may present a risk of fire, explosion, leakage or other hazards. Improperly handled batteries may explode. Never disassemble them. Do not allow children to handle batteries.

WARRANTY:

- AXS offers a 2-year warranty from the date of purchase on new, unused products with undeniable material or manufacturing defects. The warranty does not apply in the following cases: improper use, electrical or mechanical damage resulting from improper use, damage resulting from force majeure, bad weather or natural disasters, or improper repairs carried out by non-approved workshops.
- The warranty is only valid in the country of purchase.
- Batteries and normal wear and tear are not covered by the warranty.
- The warranty is only valid on presentation of the invoice. Shipment of a defective product for warranty repair is at the customer's risk. The warranty is reserved for the first end-user purchaser. AXS reserves the right to repair or exchange the defective product at its sole discretion.
- Any legal provisions in force in your country which go beyond the cases set out here shall prevail over the present provisions.

ENVIRONMENT:

THE PRODUCT:



The crossed-out garbage can on the product (including accessories) means that it belongs to the electrical and electronic equipment family. To promote the recycling and recovery of Waste Electrical and Electronic Equipment (WEEE) and protect the environment, European regulation 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE) requires that used household appliances are not disposed of in the normal municipal waste stream. Used appliances must be collected separately in order to optimize the recovery and recycling rate of the materials of which they are made, and to reduce the impact on the environment and on human health. The crossed-out wheeled garbage can symbol is displayed on all products to remind consumers of their separate collection obligations. Consumers should contact their local authority or retailer to find out how to dispose of their appliance.

BATTERIES: Batteries must be disposed of at designated collection points in accordance with local regulations. This device contains batteries covered by European Directive 2006/66/EC, which must not be disposed of with household waste. Find out about the regulations in force in your area concerning the separate collection of batteries. Correct disposal of batteries helps protect the environment and your health.

PACKAGING:



AXS is committed to respecting the environment. Our packaging is to be placed in the recycling garbage can and does not contain any single-use plastic. To facilitate the recycling of packaging, please respect the sorting rules in place locally for this type of waste.



Pour plus d'informations, rendez-vous sur :

For more information, visit us on :

Para más información visite:

Per maggiori informazioni visita:

Für weitere Informationen besuchen Sie:

Voor meer informatie bezoek:

www.bluestork.eu

Ou contactez-nous à :

Or contact us at :

O contáctenos en:

Oppure contattaci a:

Oder kontaktieren Sie uns unter:

Of neem contact met ons op via:

support@axs-group.com